

The power behind competitiveness

# Delta UPS Ultron Family

HPH Series, Three Phase  
160/ 200 kVA

User Manual

# SAVE THIS MANUAL

This manual contains important instructions and warnings that you should follow during the installation, operation, storage and maintenance of this product. Failure to heed these instructions and warnings will void the warranty.

Copyright © 2023 by Delta Electronics Inc. All Rights Reserved. All rights of this User Manual ("Manual"), including but not limited to the contents, information, and figures are solely owned and reserved by Delta Electronics Inc. ("Delta"). The Manual can only be applied to the operation or the use of this product. Any disposition, duplication, dissemination, reproduction, modification, translation, extraction, or usage of this Manual in whole or in part is prohibited without the prior written permission of Delta. Given that Delta will continuously improve and develop the product, changes may be made to the information in this Manual at any time without obligation to notify any person of such revision or changes. Delta will make all possible efforts to secure the accuracy and the integrity of this Manual. Delta disclaims any kinds or forms of warranty, guarantee, or undertaking, either expressly or implicitly, including but not limited to the completeness, faultlessness, accuracy, non-infringement, merchantability or fitness for a particular purpose of the Manual.

# Table of Contents

<b>1.</b>	<b>Important Safety Instructions</b>	<b>1-1</b>
1.1	Installation Warnings	1-2
1.2	Connection Warnings	1-2
1.3	Usage Warnings	1-3
1.4	Storage Warnings	1-5
1.5	Standard Compliance	1-5
<b>2.</b>	<b>Introduction</b>	<b>2-1</b>
2.1	General Overview	2-2
2.2	Package Inspection	2-2
2.3	Functions & Features	2-4
2.4	Exterior and Dimensions	2-6
2.5	Front View	2-7
2.6	Internal View	2-8
2.7	Rear View	2-11
2.8	Tri-color LED Indicator & Buzzer	2-13
<b>3.</b>	<b>Operation Modes</b>	<b>3-1</b>
3.1	Single Input	3-3
3.1.1	Online Mode_ Single Input_ Single Unit	3-3
3.1.2	Battery Mode_ Single Input_ Single Unit	3-4
3.1.3	Bypass Mode_ Single Input_ Single Unit	3-4
3.1.4	Manual Bypass Mode_ Single Input_ Single Unit	3-5
3.1.5	ECO Mode_ Single Input_ Single Unit	3-6
3.1.6	Frequency Conversion Mode_ Single Input_ Single Unit	3-7
3.1.7	Green Mode_ Single Input_ Single Unit	3-8
3.1.8	Energy Recycle Mode_ Single Input_ Single Unit	3-9
3.1.9	Online Mode_ Single Input_ Parallel Units	3-10
3.1.10	Battery Mode_ Single Input_ Parallel Units	3-11
3.1.11	Bypass Mode_ Single Input_ Parallel Units	3-12

3.1.12	Manual Bypass Mode_ Single Input_ Parallel Units -----	3-13
3.1.13	ECO Mode_ Single Input_ Parallel Units -----	3-15
3.1.14	Frequency Conversion Mode_ Single Input_ Parallel Units-----	3-16
3.1.15	Green Mode_ Single Input_ Parallel Units-----	3-17
3.2	Dual Input-----	3-18
3.2.1	Online Mode_ Dual Input_ Single Unit-----	3-18
3.2.2	Battery Mode_ Dual Input_ Single Unit-----	3-19
3.2.3	Bypass Mode_ Dual Input_ Single Unit -----	3-19
3.2.4	Manual Bypass Mode_ Dual Input_ Single Unit-----	3-20
3.2.5	ECO Mode_ Dual Input_ Single Unit-----	3-21
3.2.6	Frequency Conversion Mode_ Dual Input_ Single Unit -----	3-22
3.2.7	Green Mode_ Dual Input_ Single Unit-----	3-23
3.2.8	Online Mode_ Dual Input_ Parallel Units -----	3-24
3.2.9	Battery Mode_ Dual Input_ Parallel Units-----	3-25
3.2.10	Bypass Mode_ Dual Input_ Parallel Units -----	3-26
3.2.11	Manual Bypass Mode_ Dual Input_ Parallel Units-----	3-27
3.2.12	ECO Mode_ Dual Input_ Parallel Units-----	3-29
3.2.13	Frequency Conversion Mode_ Dual Input_ Parallel Units-----	3-30
3.2.14	Green Mode_ Dual Input_ Parallel Units-----	3-31
3.3	Hot Standby Redundancy (Only For Dual Input & At Least Two UPSs)----	3-32
3.4	Common Battery (Only for Parallel UPSs connecting to the Same External Battery Cabinet(s)) -----	3-33

## **4. Communication Interfaces ----- 4-1**

4.1	Communication Interfaces on the Front of the UPS with Front Door Open-----	4-2
4.1.1	Display Port-----	4-3
4.1.2	REPO Dry Contacts -----	4-4
4.1.3	External Battery Temperature Dry Contacts-----	4-5
4.1.4	External Switch/ Breaker Status Dry Contacts -----	4-6
4.1.5	Output Dry Contacts-----	4-7
4.1.6	Input Dry Contacts -----	4-10
4.1.7	Parallel Communication Card-----	4-11



4.1.8	Parallel Ports	4-13
4.1.9	SMART Slot	4-13
4.1.10	USB Port & RS-232 Port	4-13
4.1.11	Auxiliary Power Cards	4-14
4.1.12	Battery Start Buttons	4-14
4.2	Communication Interfaces at the Rear of the Touch Panel	4-15
<b>5.</b>	<b>Installation and Wiring</b>	<b>5-1</b>
5.1	Before Installation and Wiring	5-2
5.2	Installation Environment	5-2
5.3	UPS Transportation	5-4
5.4	Fixing the UPS	5-5
5.5	Wiring	5-6
5.5.1	Pre-wiring Warnings	5-6
5.5.2	Single Input/ Dual Input Modification	5-9
5.5.3	Single Unit Wiring	5-12
5.5.4	Parallel Unit Wiring	5-23
5.6	External Battery Cabinet Connection Warnings	5-27
5.7	STS Module	5-33
5.7.1	STS Module Installation	5-34
5.7.2	STS Module Removal	5-36
5.7.3	STS Module's LED Indicator	5-38
5.8	Power Module	5-39
5.8.1	Power Module Installation	5-40
5.8.2	Power Module Removal	5-42
5.8.3	Power Module's LED Indicator	5-44
<b>6.</b>	<b>UPS Operation</b>	<b>6-1</b>
6.1	Pre Start-up & Pre Turn-off Warnings for Single Unit and Parallel Units	6-2
6.2	Start-up Procedures	6-4
6.2.1	Online Mode Start-up Procedures	6-4
6.2.2	Battery Mode Start-up Procedures	6-8


6.2.3	Bypass Mode Start-up Procedures -----	6-11
6.2.4	Manual Bypass Mode Start-up Procedures -----	6-14
6.2.5	ECO Mode Start-up Procedures -----	6-19
6.2.6	Frequency Conversion Mode Start-up Procedures-----	6-23
6.2.7	Green Mode Start-up Procedures -----	6-27
6.2.8	Energy Recycle Mode Start-up Procedures-----	6-31
6.3	Turn-off Procedures -----	6-35
6.3.1	Online Mode Turn-off Procedures -----	6-35
6.3.2	Battery Mode Turn-off Procedures-----	6-36
6.3.3	Bypass Mode Turn-off Procedures -----	6-38
6.3.4	Manual Bypass Mode Turn-off Procedures-----	6-39
6.3.5	ECO Mode Turn-off Procedures-----	6-40
6.3.6	Frequency Conversion Mode Turn-off Procedures-----	6-43
6.3.7	Green Mode Turn-off Procedures-----	6-46
6.3.8	Energy Recycle Mode Turn-off Procedures -----	6-49

## **7. LCD Display & Settings ----- 7-1**

7.1	LCD Display Hierarchy -----	7-2
7.2	How to Turn on the LCD -----	7-3
7.3	ON/ OFF Button-----	7-5
7.4	Introduction of Touch Panel and Function Keys -----	7-6
7.5	Password Entry -----	7-11
7.6	Main Screen -----	7-12
7.7	Main Menu -----	7-16
7.8	Power Flow, Summary, System Status & EMS -----	7-17
7.9	Check System Readings -----	7-20
7.9.1	Main Input-----	7-20
7.9.2	Bypass Input -----	7-20
7.9.3	Inverter Output-----	7-21
7.9.4	Power Module Summary-----	7-21
7.9.5	UPS Output-----	7-22
7.9.6	Battery Status -----	7-22

7.9.7	EMS	7-23
7.9.7.1	Connecting the optional EMS 1000 (EnviroProbe)	7-27
7.10	UPS Settings	7-28
7.10.1	Bypass Setting	7-28
7.10.2	Mode Setting	7-29
7.10.3	Output Setting	7-30
7.10.4	Battery & Charging Setting	7-31
7.10.5	Parallel Setting	7-33
7.10.6	Dry Contact Setting	7-34
7.10.7	General Setting	7-36
7.10.8	IP Setting	7-39
7.10.9	Control	7-40
7.10.10	EMS Setting	7-41
7.10.11	Network Service	7-43
7.10.12	Remote User Setting	7-43
7.11	System Maintenance	7-44
7.11.1	Alarm Warning	7-44
7.11.2	Historical Event	7-45
7.11.3	Statistics	7-46
7.11.4	Test	7-46
7.11.5	Clear	7-47
7.11.6	Advanced Diagnosis	7-48
7.11.7	Version & S/N	7-49
<b>8.</b>	<b>Optional Accessories</b>	<b>8-1</b>
<b>9.</b>	<b>Maintenance</b>	<b>9-1</b>
<b>10.</b>	<b>Troubleshooting</b>	<b>10-1</b>
<b>Appendix 1 : Technical Specifications</b>		<b>A1-1</b>
<b>Appendix 2 : Warranty</b>		<b>A2-1</b>





## **Important Safety Instructions**

- 1.1 Installation Warnings
- 1.2 Connection Warnings
- 1.3 Usage Warnings
- 1.4 Storage Warnings
- 1.5 Standard Compliance

## 1.1 Installation Warnings

- This is a three-phase four-wire on-line uninterruptible power supply (hereafter referred to as 'UPS'). It can be used for commercial and industrial applications.
- Install the UPS in a well-ventilated indoor area, away from excess moisture, heat, dust, flammable gas or explosives.
- Leave adequate space around all sides of the UPS for proper ventilation and maintenance. Please refer to **5.2 Installation Environment**.
- Only authorized Delta engineers or service personnel can perform installation and maintenance. If you want to install the UPS by yourself, please install it under the supervision of authorized Delta engineers or service personnel.
- Follow the IEC 60364-4-42 standard to install the UPS.

## 1.2 Connection Warnings

- Before applying electrical power to the UPS, make sure the UPS is grounded to avoid a possible risk of current leakage.
- You can parallel at maximum eight UPS units.
- The UPS must be connected with an external battery cabinet (user-supplied and handled and configured by Delta service personnel). Please refer to **5.6 External Battery Cabinet Connection Warnings** for relevant information.
- The installation of protective devices is highly recommended when the UPS is connected to power sources and critical loads.
- The protective devices connecting to the UPS must be installed near the UPS and must be easily accessible for operation.
- Protective Devices:
  1. For single input, please install (1) a protective device between the main AC source and the UPS and (2) a protective device between the connected critical loads and the UPS.
  2. For dual input, please install (1) a protective device between the main AC source and the UPS, (2) a protective device between the bypass source and the UPS and (3) a protective device between the connected critical loads and the UPS.

3. Each protective device could be a breaker or a fuse. For the protective device's rating current, please refer to the table below.

160kVA	200kVA
690V/ 300A	690V/ 400A

4. Each protective device should have the functions of over current protection, short circuit protection, insulating protection and shunt trip feature.
5. When selecting the protective devices, please take each power cable's current capacity and the system's overload capacity (please refer to **Appendix 1: Technical Specifications**) into consideration. Besides, the short-circuit capacity of the upstream protective devices must be equal to or larger than the capacity of the UPS's input protective devices.
6. If the UPS is supplied by a power source whose neutral is grounded, the backfeed protective device installed as UPS input protection must be a 3-pole type. If the UPS is supplied by a power source whose neutral is not grounded, the backfeed protective device installed as UPS input protection must be a 4-pole type.
7. The recommended electrical rating of the backfeed protective device is as follows.

160kVA	200kVA
690V/ 300A	690V/ 400A

## 1.3 Usage Warnings

- Only qualified service personnel can upgrade the UPS's firmware.
- Before installation, wiring and working on the UPS's internal circuits, please completely cut off all power supplying to the UPS, including the input power and battery power.
- The UPS is specifically designed for information technology equipment and used to power computers, servers, and associated peripheral devices. If you want to connect any capacitive loads or non-linear loads (that have serious surge current) to the UPS, it needs to be de-rated according to on-site applications. For such special applications, please contact Delta service personnel for the accurate UPS sizing. The UPS is not suitable for connecting with any asymmetrical loads.
- The external slits and openings in the UPS are provided for ventilation. To ensure reliable operation of the UPS and to protect the UPS from overheating, these slits and openings must not be blocked or covered. Do not insert any object into the slits and openings that may hinder ventilation.

- Before applying electrical power to the UPS, you must allow the UPS to adjust to room temperature 20°C ~ 25°C for at least one hour and ensure that there is no moisture condensing inside the unit.
- Do not put beverages on the UPS, external battery cabinet(s) or any other accessory associated with the UPS.
- Do not open or remove the covers or panels of the UPS to avoid high voltage electric shock. Only authorized Delta engineers or service personnel can do so for installation or maintenance. If you want to open or remove the covers or panels, do it only under the supervision of authorized Delta engineers or service personnel.
- It is not recommended that you connect the UPS to any regenerative loads. For the load suitability, please contact Delta customer service before purchasing.
- The risk of dangerous high voltage is possible when batteries are still connected to the UPS even though the UPS is disconnected from the power sources. Before maintenance, please turn off each external battery cabinet's circuit breaker to completely cut off the battery power from the UPS.
- Do not dispose of the battery or batteries in a fire. The batteries may explode.
- Do not open or damage the battery or batteries. The released electrolyte is harmful to the skin and eyes and may be toxic.
- The UPS is electronic equipment that runs 24 hours continuously. To ensure its normal lifetime, regular maintenance of the UPS and batteries is of vital importance and necessary.
- Some components like batteries, power capacitors, and fans will become worn-out due to long-term usage, and this will increase the risk of UPS failure. To replace and maintain the components, please contact Delta service personnel.
- A battery can present a risk of electric shock and high short-circuit current. The following precautions should be observed before replacement of batteries:
  1. Remove watches, rings, or other metal objects.
  2. Use tools with insulated handles.
  3. Wear insulating gloves and boots.
  4. Do not lay tools or metal parts on the top of batteries.
  5. Disconnect the charging source prior to connecting or disconnecting the batteries' terminals.
- You must contact Delta customer service if either of the following events occurs:
  1. Any liquid is poured or splashes on the UPS.
  2. The UPS does not run normally after you carefully followed the instructions in this ***User Manual***.




## 1.4 Storage Warnings

- Use the original packing material to pack the UPS to prevent any possible damage from rodents.
- If the UPS needs to be stored prior to installation, it should be placed in a dry indoor area. The allowable storage temperature is below 70°C and relative humidity is below 95%.

## 1.5 Standard Compliance

- EN 62040-1
- EN 62040-2 Category C3
- EN 61000-4-2 Level 4
- EN 61000-4-3 Level 3
- EN 61000-4-6
- EN 61000-4-4 Level 4
- EN 61000-4-5 Level 4





## **Introduction**

- 2.1 General Overview
- 2.2 Package Inspection
- 2.3 Functions & Features
- 2.4 Exterior and Dimensions
- 2.5 Front View
- 2.6 Internal View
- 2.7 Rear View
- 2.8 Tri-color LED Indicator  
& Buzzer

## 2.1 General Overview

The HPH series UPS, a three-phase four-wire online uninterruptible power supply, provides reliable and stable sine-wave power to your electronic devices. The UPS not only adopts the advanced IGBT technology to provide high quality, low noise, pure and uninterruptible output power to the connected loads, but also applies the latest design of DSP digital control technology and highest quality components.

Its output power factor is up to unity, and the efficiency of the entire system can reach up to 96.5% in online mode and up to 99% in ECO mode. With these outstanding features, the UPS not only provides safe, reliable and uninterruptible power to your sensitive electronic equipment at all times, but also produces greater electric power efficiency at less cost.

You can parallel at maximum eight UPS units to increase the system capacity and redundancy and enhance the unit's availability and reliability. Moreover, its communication interfaces and built-in SNMP card and MODBUS card facilitate remote control, monitoring and management.

The HPH series UPS provides two different rated power levels, 160kVA and 200kVA, for your selection.

## 2.2 Package Inspection


- External

During UPS transportation, some unpredictable situations might occur. It is recommended that you inspect the UPS exterior packaging. If you notice any damage, please immediately contact the dealer from whom you purchased the unit.

- Internal

1. Check the rating label attached to the UPS and make sure the device No. and capacity match what you ordered.
2. Examine if any parts are loose or damaged.

3. The UPS package contains the following items. Please check if any items are missing.



No.	Item	Q'ty
①	UPS (a 50ppi dust filter has been installed on the inner side of the UPS's front door before shipment)	1 PC
②	User Manual	1 PC
③	RS-232 Cable (1.8 meters)	1 PC
④	Parallel Cable (3 meters)	1 PC
⑤	Test Report	1 PC
⑥	Key	1 PC (two copies placed inside the UPS cabinet)
⑦	M10 Screw (used for input/ output/ battery/ grounding wiring)	18 PCS
⑧	USB Cable	1 PC
⑨	4-Pin Dry Contact Terminal Block (used for REPO dry contacts; please refer to <b>Figure 4-3</b> )	1 PC

No.	Item	Q'ty
⑩	6-Pin Dry Contact Terminal Block (used for MODBUS and BMS ports located at the rear of the touch panel; please refer to <b>Figure 4-18</b> )	1 PC
⑪	8-Pin Dry Contact Terminal Block (used for (1) external battery temperature dry contacts and (2) external switch/ breaker status dry contacts; please refer to <b>Figure 4-3</b> )	2 PCS
⑫	10-Pin Dry Contact Terminal Block (used for input and output dry contacts; please refer to <b>Figure 4-3</b> )	2 PCS

4. If there is any damage or anything missing, please immediately contact the dealer from whom you purchased the unit.
5. If the UPS needs to be returned, carefully repack the UPS and all of the accessories using the original packing material that came with the unit.

## 2.3 Functions & Features

- Hot swappable STS module and communication interfaces realize on-line maintenance and reduce the MTTR (Mean Time to Repair).
- Input power factor > 0.99 and input THDi < 3% save on installation cost and diminish power contamination.
- Efficiency > 96% saves on operation cost.
- Automatic input frequency detection enables operation at 50Hz or 60Hz.
- Automatic restart:
  1. The UPS will restart in normal mode automatically right after the AC line resumes following a low battery shutdown.
  2. The UPS returns automatically to normal mode from bypass mode after an overload condition is cleared.
- Automatically detects whether bypass voltage is out of rating voltage (default: voltage  $\pm 15\%$  & frequency  $\pm 3\text{Hz}$ ). If yes, the UPS will stop supplying power to the critical loads to protect your electronic equipment.
- Supports ECO mode: when input voltage and frequency are within the range of rating voltage  $\pm 10\%$  and rating frequency  $\pm 3\text{Hz}$ , the UPS will transfer to bypass mode; otherwise, the UPS will transfer to normal mode to reach higher efficiency.

- Both auxiliary power and control circuit adopt redundancy design, which doubly enhances UPS reliability.
- Suitable for top and bottom wiring.
- Suitable for top and front maintenance for power modules and system components.
- Generator compatible
- Surge protection and EMI filter functions.
- Remote emergency power off.
- Single input and dual input functions.
- Supports external switch/ breaker status detection.
- Wide AC input voltage range (full load: 176~276/ 305~477 Vac; <70% load: 132~176/ 228~305 Vac) reduces frequent transfer from normal mode to battery mode to save battery consumption and prolong battery life.
- Cold-start function when there is no AC power.
- AC start-up function when the UPS is not connected to the batteries.


**WARNING:**

Please note that when the UPS is not connected to the batteries, it will not protect your equipment if the utility power is lost.

- Connects at maximum four external battery cabinets to extend backup time.
- Schedulable battery test and battery replacement alarm.
- Battery temperature monitoring and compensation.
- Battery monitoring system allows measurement of per battery cell's voltage and current.
- Smart battery charger design allows auto-charging or manual charging to shorten charging time.
- Provides communication interfaces and a smart slot (where you can install the optional Relay I/O card for dry contact expansion). Please refer to **4. Communication Interfaces**.
- Provides a parallel communication card slot (where you can install the optional parallel communication card to increase two redundant parallel ports for parallel communication). Please refer to **4.1.7 Parallel Communication Card** for more information.
- Built-in SNMP card and MODBUS card located at the rear of the touch panel provide network communication and MODBUS communication respectively.

- Built-in SNMP card located at the rear of the touch panel allows remote monitoring, management and event log download of the UPS.
- Built-in SRAM records at maximum 10000 event logs.
- 10-inch graphic and color touch panel enables the user to easily operate the UPS and understand the UPS's status.
- Fan speed auto adjustment prolongs fan life and reduces noise when the critical loads decrease. Moreover, fan failure detection circuit is established.
- State-of-the-art microprocessor technology performs self-detection and monitors fan speed in real time, which provides complete and detailed operating status of the UPS.


## 2.4 Exterior and Dimensions



*(Figure 2-1: Exterior & Dimensions)*




## 2.5 Front View



(Figure 2-2: UPS Front View)

On the front of the UPS, there are a 10" color touch screen, a tri-color LED indicator, a door switch, four casters and four leveling feet. Please see **Figure 2-2**.

1. For information about the 10" color touch panel, please refer to **7. LCD Display & Settings**.
2. For information about the tri-color LED indicator, please refer to **2.8 Tri-color LED Indicator & Buzzer**.
3. The casters at the bottom of the UPS can be used to move over short distances, and the leveling feet fix and stabilize the UPS on the ground. Please refer to **5.3 UPS Transportation** for relevant information.
4. Please refer to **Figure 2-3** for how to open the UPS front door.



(Figure 2-3: How to Open the UPS Front Door)


## 2.6 Internal View



### **WARNING:**

Only authorized Delta engineers or service personnel can perform installation, wiring, panel & cover removal, maintenance and operation. If you want to execute any action mentioned above by yourself, the action must be under the supervision of authorized Delta engineers or service personnel.

After you open the UPS's front door, you will see the internal mechanisms including communication interfaces, 3 power modules (for 160kVA)/ 4 power modules (for 200 kVA), an STS module and four switches (Input/ Bypass/ Manual Bypass/ Output). Please refer to **Figure 2-4**.



(Figure 2-4: UPS Internal View (Front View with Door Open))

No.	Description
①	The communication interfaces are located at two areas, (1) on the front of the UPS with front door open and (2) at the rear of the touch panel. For relevant information, please refer to <b>4. Communication Interfaces</b> .
②	There are 3 power modules and 4 power modules for 160kVA UPS and 200kVA UPS respectively. For information about the power module, please refer to <b>5.8 Power Module</b> .
③	There is one STS module. For the STS module information, please refer to <b>5.7 STS Module</b> .

No.	Description				
4	<p>The UPS has four switches, which are Input Switch (Q1), Bypass Switch (Q2), Manual Bypass Switch (Q3) and Output Switch (Q4). Please refer to <b>Figure 2-5</b> for the location of the four switches.</p> <div data-bbox="401 382 1125 1049"> <p style="text-align: center;"><b>Internal View (Front View with Door Open)</b></p> </div> <p style="text-align: center;"><b>(Figure 2-5: Location of the Four Switches)</b></p> <p>For how to turn on/ off each switch, please refer to <b>Figure 2-6</b>.</p> <div data-bbox="344 1221 1177 1491"> <table border="1"> <thead> <tr> <th data-bbox="344 1221 760 1263">Turn on the Switch :</th> <th data-bbox="760 1221 1177 1263">Turn off the Switch :</th> </tr> </thead> <tbody> <tr> <td data-bbox="344 1263 760 1491"> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>(ON)</p> </div> <div style="text-align: center;"> <p>(OFF)</p> <p>90°</p> </div> </div> </td> <td data-bbox="760 1263 1177 1491"> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>(ON)</p> </div> <div style="text-align: center;"> <p>(OFF)</p> <p>90°</p> </div> </div> </td> </tr> </tbody> </table> </div> <p style="text-align: center;"><b>(Figure 2-6: Turn on/ off the Switch)</b></p>	Turn on the Switch :	Turn off the Switch :	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>(ON)</p> </div> <div style="text-align: center;"> <p>(OFF)</p> <p>90°</p> </div> </div>	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>(ON)</p> </div> <div style="text-align: center;"> <p>(OFF)</p> <p>90°</p> </div> </div>
Turn on the Switch :	Turn off the Switch :				
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>(ON)</p> </div> <div style="text-align: center;"> <p>(OFF)</p> <p>90°</p> </div> </div>	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>(ON)</p> </div> <div style="text-align: center;"> <p>(OFF)</p> <p>90°</p> </div> </div>				


## 2.7 Rear View




### WARNING:

Only authorized Delta engineers or service personnel can perform installation, wiring, panel & cover removal, maintenance and operation. If you want to execute any action mentioned above by yourself, the action must be under the supervision of authorized Delta engineers or service personnel.


The rear view of the UPS is shown in **Figure 2-7**. Please remove the rear panel (there are 6 screws (see **Figure 2-8**)) to see the wiring terminals shown in **Figure 2-9 ~ Figure 2-11**.




(Figure 2-7: UPS Rear View)



(Figure 2-8: UPS Rear Panel and Screw Location)




(Figure 2-9: Wiring Terminals\_ AC Input & Bypass Input )



(Figure 2-10: Wiring Terminals\_ Battery Input & UPS Output)


(Rear View after  
Rear Panel Removal)



(Figure 2-11: Wiring Terminals\_ Grounding )

## 2.8 Tri-color LED Indicator & Buzzer


Please see **Figure 2-12** for the location of the tri-color LED Indicator. For information about the tri-color LED indicator, please refer to **Table 2-1**.



(Figure 2-12: Tri-color LED Indicator Location )

The buzzer is located at the rear of the UPS's front door. Please see **Figure 2-13**.

(UPS Front View with Door Open)



(Figure 2-13: Buzzer Location )

Please refer to the table below for the status of the tri-color LED indicator and the buzzer.




Table 2-1: Tri-color LED Indicator &amp; Buzzer

Tri-color LED Indicator	Green	Yellow		Red
Status	ON	ON		ON
UPS Operation Mode & Screen Display <sup>*1</sup>	'On-Line' 'ECO' 'Frequency Conversion' 'Green'	'Bypass' 'Battery' 'Standby' 'Softstart' 'Energy Recycle'		N/A
Warning Level <sup>*2</sup>	N/A	Minor	Medium	Major
Buzzer Frequency <sup>*2</sup>	N/A	The buzzer beeps 0.5 second for every 3 seconds.	The buzzer beeps 0.5 second for every second.	Long beep

**NOTE:**

1. <sup>\*1</sup>: The text appears in the upper right corner of the screen.
2. <sup>\*2</sup>: To clear the warning and buzzer, please refer to **10. Troubleshooting**.





## Operation Modes

3.1 Single Input

3.2 Dual Input

3.3 Hot Standby Redundancy  
(Only For Dual Input & At  
Least Two UPSs)

3.4 Common Battery (Only for  
Parallel UPSs connecting to  
the Same External Battery  
Cabinet(s))

The UPS runs in eight basic operation modes, which are online mode, battery mode, bypass mode, manual bypass mode, ECO mode, frequency conversion mode, green mode and energy recycle mode. Besides these eight operation modes, the UPS is also designed for common battery application and hot standby redundancy. Please see the following sections for relevant information.



**NOTE:**

1. In this user manual, the meaning of Q1, Q2, Q3, Q4 and Q5 represents the following.


Code	Meaning
Q1	Input Switch
Q2	Bypass Switch
Q3	Manual Bypass Switch
Q4	Output Switch
Q5	External Battery Cabinet's Breaker

2. Up to eight UPS units can be paralleled for redundancy and capacity expansion. Only UPSs with the same capacity, voltage and frequency can be paralleled. Please only use the provided parallel cable to parallel the UPS units. Otherwise, parallel functions will fail.

## 3.1 Single Input

### 3.1.1 Online Mode\_ Single Input\_ Single Unit


In online mode, the main AC source supplies AC power via the Input Switch (Q1) to the rectifier, and the rectifier converts the AC power to DC power and supplies the DC power to the inverter. In the meantime, the rectifier provides charging power to the batteries. After receiving the DC power, the inverter converts it into clean and stable AC power to the connected critical loads via the Output Switch (Q4). Please refer to **Figure 3-1**. During online mode, the UPS's tri-color LED illuminates green and the text 'On-Line' appears in the upper right corner of the screen.



(Figure 3-1: Online Mode Diagram\_ Single Input Single Unit)

### 3.1.2 Battery Mode\_ Single Input\_ Single Unit


The UPS transfers to battery mode automatically if the main AC source cannot supply power, for example, when unstable voltage or a power outage occurs. In battery mode, the batteries provide DC power and the UPS converts it into AC power and supplies it to the connected critical loads via the Output Switch (Q4). During the conversion process, output voltage remains the same. Please see **Figure 3-2** for battery mode diagram. During battery mode, the UPS's tri-color LED illuminates yellow and the text '**Battery**' appears in the upper right corner of the screen.



(Figure 3-2: Battery Mode Diagram\_ Single Input Single Unit)

### 3.1.3 Bypass Mode\_ Single Input\_ Single Unit


When the inverter encounters abnormal situations such as over temperature, overload, short circuit, abnormal output voltage or low battery, it will automatically shut itself down. If the UPS detects the bypass AC source is normal, it will automatically switch to bypass mode to protect the connected critical loads from power interruption. Please refer to **Figure 3-3**. After the above-mentioned abnormalities are eliminated, the UPS will switch back to online mode from bypass mode. During bypass mode, the UPS's tri-color LED illuminates yellow and the text '**Bypass**' appears in the upper right corner of the screen.



(Figure 3-3: Bypass Mode Diagram\_ Single Input Single Unit)

### 3.1.4 Manual Bypass Mode\_ Single Input\_ Single Unit

When the UPS needs maintenance, you can manually switch the UPS to manual bypass mode. To let the UPS run in manual bypass mode, please follow the procedures below:


- 1 Confirm that the bypass AC source and the STS module are normal.
- 2 Press the LCD's ON/ OFF button (  ) once and the 'POWER OFF?' screen will pop up to ask you if you want to power off the UPS's inverter. Please select 'YES'.
- 3 Turn on the Manual Bypass Switch (Q3).
- 4 Turn off the Bypass Switch (Q2).
- 5 Turn off the Input Switch (Q1) and Output Switch (Q4).
- 6 Turn off each external battery cabinet's breaker (Q5).

In manual bypass mode, all power inside the UPS is completely cut off and maintenance personnel can perform maintenance safely. Please see **Figure 3-4** for manual bypass mode diagram. During manual bypass mode, the UPS's tri-color LED and LCD are both off.



#### WARNING:

1. In manual bypass mode, make sure that all of the switches and breakers (except the Manual Bypass Switch (Q3)) are in the **OFF** position before working on the UPS's internal circuits. This avoids electric shock.
2. After the power inside the UPS is completely cut off, there is no high voltage inside the UPS except the wiring terminals and the Manual Bypass Switch (Q3). Do not touch the wiring terminals and the Manual Bypass Switch (Q3) during UPS maintenance process to avoid electric shock.
3. During manual bypass mode, the UPS's input power is completely cut off and the connected critical loads are not protected.




(Figure 3-4: Manual Bypass Mode Diagram\_ Single Input Single Unit)

### 3.1.5 ECO Mode\_ Single Input\_ Single Unit

To activate ECO mode, please refer to **6.2.5 ECO Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.

In ECO mode, when bypass AC source's input voltage and frequency are within the range of rating voltage  $\pm 10\%$  and rating frequency  $\pm 3\text{Hz}$ , the UPS works in bypass mode; otherwise, the UPS runs in online mode. For ECO mode diagram, please see **Figure 3-5**. During ECO mode, the UPS's tri-color LED illuminates green and the text 'ECO' appears in the upper right corner of the screen.



(Figure 3-5: ECO Mode Diagram\_ Single Input Single Unit)



### 3.1.6 Frequency Conversion Mode\_ Single Input\_ Single Unit


To activate frequency conversion mode, please refer to **6.2.6 Frequency Conversion Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.

After the UPS is manually set in frequency conversion mode, the inverter will automatically select 50Hz or 60Hz as the fixed output frequency. After the output frequency is determined, the system will automatically disable the bypass function. Please note that, once the inverter shuts down, there is no bypass output. For the diagram of frequency conversion mode, please see **Figure 3-6**. During frequency conversion mode, the UPS's tri-color LED illuminates green and the text '**Frequency Conversion**' appears in the upper right corner of the screen.



#### NOTE:

During frequency conversion mode, once the inverter shuts down, there is no bypass output.




(Figure 3-6: Frequency Conversion Mode Diagram\_ Single Input Single Unit)

### 3.1.7 Green Mode\_ Single Input\_ Single Unit

To activate green mode, please refer to **6.2.7 Green Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.

Green mode is the same as online mode, but the difference is that the system will automatically detect the output status (i.e. total load capacity %) to decide which specific power modules should be fully powered on or idle in order to achieve higher efficiency of the UPS. For the green mode diagram, please see **Figure 3-7**. During green mode, the UPS's tri-color LED illuminates green and the text 'Green' appears in the upper right corner of the screen.



(Figure 3-7: Green Mode Diagram\_ Single Input Single Unit)

### 3.1.8 Energy Recycle Mode\_ Single Input\_ Single Unit




#### NOTE:

Energy recycle mode is only applicable to single input and single unit application.

Energy recycle mode is only applicable to UPS self-test only. Without connection of any critical loads, the UPS can execute current test under full load condition. Before you activate energy recycle mode, please make sure that the Manual Bypass Switch (Q3), Output Switch (Q4) and each external battery cabinet's battery breaker (Q5) are in the **OFF** status.

To activate energy recycle mode (only qualified service personnel can do so), please refer to **6.2.8 Energy Recycle Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.


For the diagram of energy recycle mode, please see **Figure 3-8**. During energy recycle mode, the UPS's tri-color LED illuminates yellow and the text 'Energy Recycle' appears in the upper right corner of the screen.



(Figure 3-8: Energy Recycle Mode Diagram\_ Single Input Single Unit)

### 3.1.9 Online Mode\_ Single Input\_ Parallel Units


In online mode (parallel), the total loads will be equally shared by parallel UPSs. If one of the parallel units fails and its load is less than the total capacity of the remaining parallel units, the failing UPS's output will be switched off and its load will be equally shared by the remaining parallel units. If the failing UPS's load is larger than the total capacity of the remaining parallel units, all UPSs' inverters will turn off and the total loads will be supplied by bypass power. During online mode, each UPS's tri-color LED illuminates green and each UPS's LCD shows the text 'On-Line' in the upper right corner. Please refer to **Figure 3-9** for the path of electrical power through the parallel UPSs in online mode.



(Figure 3-9: Online Mode Diagram\_ Single Input Parallel Units)

### 3.1.10 Battery Mode\_ Single Input\_ Parallel Units


If the main AC source cannot supply power, for example, when unstable voltage or a power outage occurs, all parallel UPSs will automatically transfer from online mode to battery mode. During the conversion process, output voltage remains the same, and during battery mode, each UPS's tri-color LED illuminates yellow and each UPS's LCD shows the text 'Battery' in the upper right corner. Please refer to **Figure 3-10** for the path of electrical power through the parallel UPSs in battery mode.



(Figure 3-10: Battery Mode Diagram\_ Single Input Parallel Units)

### 3.1.11 Bypass Mode\_ Single Input\_ Parallel Units


In parallel mode, when all inverters encounter abnormal situations such as overload, short circuit, abnormal output voltage or low battery, they will automatically shut themselves down. Meanwhile, if all UPSs detect the bypass AC source is normal, they will automatically switch to bypass mode to protect the connected critical loads from power interruption. The critical loads will be equally shared by all parallel units. After the abnormalities mentioned above are eliminated, the UPSs will switch back to online mode from bypass mode. During bypass mode, each UPS's tri-color LED illuminates yellow and each UPS's LCD shows the text 'Bypass' in the upper right corner. Please refer to **Figure 3-11** for the path of electrical power through the parallel UPSs in bypass mode.



(Figure 3-11: Bypass Mode Diagram\_ Single Input Parallel Units)

### 3.1.12 Manual Bypass Mode\_ Single Input\_ Parallel Units

In parallel mode, if one of the parallel UPSs needs maintenance, please first confirm that the bypass AC source and each parallel UPS's STS module are normal. After confirmation, please follow the procedures below to manually switch each of the parallel UPSs to manual bypass mode.

- 1 Press each LCD's ON/ OFF button (  ) once and the '**POWER OFF?**' screen will pop up to ask you if you want to power off the UPS's inverter. Please select '**YES**'.
- 2 Turn on each UPS's Manual Bypass Switch (Q3).
- 3 Turn off each UPS's Bypass Switch (Q2).
- 4 Turn off each UPS's Input Switch (Q1) and Output Switch (Q4).
- 5 Turn off each external battery cabinet's breaker (Q5).

In manual bypass mode, all power inside the parallel UPSs is completely cut off and maintenance personnel can perform maintenance safely. The connected critical loads will be supplied by the manual bypass. During manual bypass mode, all parallel UPSs' tri-color LEDs and LCDs are off. Please see **Figure 3-12** for the path of electrical power through the parallel UPSs in manual bypass mode.




#### WARNING:

1. In manual bypass mode, make sure that all of the switches and breakers (except each Manual Bypass Switch (Q3)) are in the **OFF** position before working on any of the parallel UPSs' internal circuits. This avoids electric shock.
2. After the power inside all parallel UPSs is completely cut off, there is no high voltage inside the parallel UPSs except each UPS's wiring terminals and Manual Bypass Switch (Q3). Do not touch any UPS's wiring terminals and Manual Bypass Switch (Q3) during UPS maintenance process to avoid electric shock.
3. During manual bypass mode, each parallel UPS's input power is completely cut off and the connected critical loads are not protected.



#### NOTE:

For parallel UPSs, if you want to turn off one of the parallel UPSs for maintenance, please make sure the total connected critical loads will not exceed the remaining parallel units' total capacity.




(Figure 3-12: Manual Bypass Mode Diagram\_ Single Input Parallel Units)



### 3.1.13 ECO Mode\_ Single Input\_ Parallel Units

To activate ECO mode, please refer to **6.2.5 ECO Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.

In ECO mode (parallel), when each UPS's bypass input voltage and frequency are within the range of rating voltage  $\pm 10\%$  and rating frequency  $\pm 3\text{Hz}$ , each UPS works in bypass mode; otherwise, each UPS runs in online mode. During ECO mode, each UPS's tri-color LED illuminates green and each UPS's LCD shows the text 'ECO' in the upper right corner. Please see **Figure 3-13** for the path of electrical power through the parallel UPSs in ECO mode.



(Figure 3-13: ECO Mode Diagram\_ Single Input Parallel Units)

### 3.1.14 Frequency Conversion Mode\_ Single Input\_ Parallel Units


To activate frequency conversion mode, please refer to **6.2.6 Frequency Conversion Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.

For parallel application, after each of the parallel UPSs is manually set in frequency conversion mode, each inverter will automatically select 50Hz or 60Hz as the fixed output frequency. After the output frequency is determined, each system will automatically disable the bypass function. Please note that, once each inverter shuts down, there is no bypass output. During frequency conversion mode, each UPS's tri-color LED illuminates green and each UPS's LCD shows the text '**Frequency Conversion**' in the upper right corner. Please see **Figure 3-14** for the path of electrical power through the parallel UPSs in frequency conversion mode.



#### NOTE:

During frequency conversion mode (parallel), once all of the UPSs' inverters shut down, there is no bypass output.




(Figure 3-14: Frequency Conversion Mode Diagram\_ Single Input Parallel Units)

### 3.1.15 Green Mode\_ Single Input\_ Parallel Units

To activate green mode, please refer to **6.2.7 Green Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.

For parallel application, green mode is the same as online mode, but the difference is that each system will automatically detect its UPS's output status (i.e. total load capacity %) to decide which specific power modules should be fully powered on or idle in order to achieve higher efficiency of the UPS. During green mode, each UPS's tri-color LED illuminates green and each UPS's LCD shows the text 'Green' in the upper right corner. Please see **Figure 3-15** for the path of electrical power through the parallel UPSs in green mode.




(Figure 3-15: Green Mode Diagram\_ Single Input Parallel Units)

## 3.2 Dual Input

### 3.2.1 Online Mode\_ Dual Input\_ Single Unit


In online mode, the main AC source supplies AC power via the Input Switch (Q1) to the rectifier, and the rectifier converts the AC power to DC power and supplies the DC power to the inverter. In the meantime, the rectifier provides charging power to the batteries. After receiving the DC power, the inverter converts it into clean and stable AC power to the connected critical loads via the Output Switch (Q4). Please see **Figure 3-16** for online mode diagram. During online mode, the UPS's tri-color LED illuminates green and the text 'On-Line' appears in the upper right corner of the screen.



(Figure 3-16: Online Mode Diagram\_ Dual Input Single Unit)

### 3.2.2 Battery Mode\_ Dual Input\_ Single Unit


The UPS transfers to battery mode automatically if the main AC source cannot supply power, for example, when unstable voltage or a power outage occurs. In battery mode, the batteries provide DC power and the UPS converts it into AC power and supplies it to the connected critical loads via the Output Switch (Q4). During the conversion process, output voltage remains the same. Please see **Figure 3-17** for battery mode diagram. During battery mode, the UPS's tri-color LED illuminates yellow and the text '**Battery**' appears in the upper right corner of the screen.



(Figure 3-17: Battery Mode Diagram\_ Dual Input Single Unit)

### 3.2.3 Bypass Mode\_ Dual Input\_ Single Unit


When the inverter encounters abnormal situations such as over temperature, overload, short circuit, abnormal output voltage or low battery, it will automatically shut itself down. If the UPS detects the bypass AC source is normal, it will automatically switch to bypass mode to protect the connected critical loads from power interruption. Please refer to **Figure 3-18**. After the above-mentioned abnormalities are eliminated, the UPS will switch back to online mode from bypass mode. During bypass mode, the UPS's tri-color LED illuminates yellow and the text '**Bypass**' appears in the upper right corner of the screen.



(Figure 3-18: Bypass Mode Diagram\_ Dual Input Single Unit)

### 3.2.4 Manual Bypass Mode\_ Dual Input\_ Single Unit

When the UPS needs maintenance, you can manually switch the UPS to manual bypass mode. To let the UPS run in manual bypass mode, please follow the procedures below:


- 1 Confirm that the bypass AC source and the STS module are normal.
- 2 Press the LCD's ON/ OFF button (  ) once and the '**POWER OFF?**' screen will pop up to ask you if you want to power off the UPS's inverter. Please select '**YES**'.
- 3 Turn on the Manual Bypass Switch (Q3).
- 4 Turn off the Bypass Switch (Q2).
- 5 Turn off the Input Switch (Q1) and Output Switch (Q4).
- 6 Turn off each external battery cabinet's breaker (Q5).

In manual bypass mode, all power inside the UPS is completely cut off and maintenance personnel can perform maintenance safely. Please see **Figure 3-19** for manual bypass mode diagram. During manual bypass mode, the UPS's tri-color LED and LCD are both off.



#### WARNING:

1. In manual bypass mode, make sure that all of the switches and breakers (except the Manual Bypass Switch (Q3)) are in the **OFF** position before working on the UPS's internal circuits. This avoids electric shock.
2. After the power inside the UPS is completely cut off, there is no high voltage inside the UPS except the wiring terminals and the Manual Bypass Switch (Q3). Do not touch the wiring terminals and the Manual Bypass Switch (Q3) during UPS maintenance process to avoid electric shock.
3. During manual bypass mode, the UPS's input power is completely cut off and the connected critical loads are not protected.




(Figure 3-19: Manual Bypass Mode Diagram\_ Dual Input Single Unit)

### 3.2.5 ECO Mode\_ Dual Input\_ Single Unit

To activate ECO mode, please refer to **6.2.5 ECO Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.

In ECO mode, when the bypass AC source's input voltage and frequency are within the range of rating voltage  $\pm 10\%$  and rating frequency  $\pm 3\text{Hz}$ , the UPS works in bypass mode; otherwise, the UPS runs in online mode. For ECO mode diagram, please see **Figure 3-20**. During ECO mode, the UPS's tri-color LED illuminates green and the text 'ECO' appears in the upper right corner of the screen.



(Figure 3-20: ECO Mode Diagram\_ Dual Input Single Unit)


### 3.2.6 Frequency Conversion Mode\_ Dual Input\_ Single Unit

To activate frequency conversion mode, please refer to **6.2.6 Frequency Conversion Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.

After the UPS is manually set in frequency conversion mode, the inverter will automatically select 50Hz or 60Hz as the fixed output frequency. After the output frequency is determined, the system will automatically disable the bypass function. Please note that, once the inverter shuts down, there is no bypass output. For the diagram of frequency conversion mode, please see **Figure 3-21**. During frequency conversion mode, the UPS's tri-color LED illuminates green and the text 'Frequency Conversion' appears in the upper right corner of the screen.



**NOTE:** During frequency conversion mode, once the inverter shuts down, there is no bypass output.




(Figure 3-21: Frequency Conversion Mode Diagram\_ Dual Input Single Unit)



### 3.2.7 Green Mode\_ Dual Input\_ Single Unit

To activate green mode, please refer to **6.2.7 Green Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.


Green mode is the same as online mode, but the difference is that the system will automatically detect the output status (i.e. total load capacity %) to decide which specific power modules should be fully powered on or idle in order to achieve higher efficiency of the UPS. For the green mode diagram, please see **Figure 3-22**. During green mode, the UPS's tri-color LED illuminates green and the text 'Green' appears in the upper right corner of the screen.



(Figure 3-22: Green Mode Diagram\_ Dual Input Single Unit)

### 3.2.8 Online Mode\_ Dual Input\_ Parallel Units


In online mode (parallel), the total loads will be equally shared by the parallel UPSs. If one of the parallel units fails and its load is less than the total capacity of the remaining parallel units, the failing UPS's output will be switched off and its load will be equally shared by the remaining parallel units. If the failing UPS's load is larger than the total capacity of the remaining parallel units, all UPSs' inverters will turn off and the total loads will be supplied by bypass power. During online mode, each UPS's tri-color LED illuminates green and each UPS's LCD shows the text 'On-Line' in the upper right corner. Please refer to **Figure 3-23** for the path of electrical power through the parallel UPSs in online mode.



(Figure 3-23: Online Mode Diagram\_ Dual Input Parallel Units)

### 3.2.9 Battery Mode\_ Dual Input\_ Parallel Units


If the main AC source cannot supply power, for example, when unstable voltage or a power outage occurs, all parallel UPSs will automatically transfer from online mode to battery mode. During the conversion process, output voltage remains the same, and during battery mode, each UPS's tri-color LED illuminates yellow and each UPS's LCD shows the text 'Battery' in the upper right corner. Please refer to **Figure 3-24** for the path of electrical power through the parallel UPSs in battery mode.



(Figure 3-24: Battery Mode Diagram\_ Dual Input Parallel Units)

### 3.2.10 Bypass Mode\_ Dual Input\_ Parallel Units


In parallel mode, when all inverters encounter abnormal situations such as overload, short circuit, abnormal output voltage or low battery, they will automatically shut themselves down. Meanwhile, if all UPSs detect the bypass AC source is normal, they will automatically switch to bypass mode to protect the connected critical loads from power interruption. The critical loads will be equally shared by all parallel units. After the abnormalities mentioned above are eliminated, the UPSs will switch back to online mode from bypass mode. During bypass mode, each UPS's tri-color LED illuminates yellow and each UPS's LCD shows the text 'Bypass' in the upper right corner. Please see **Figure 3-25** for the path of electrical power through the parallel UPSs in bypass mode.



(Figure 3-25: Bypass Mode Diagram\_ Dual Input Parallel Units)

### 3.2.11 Manual Bypass Mode\_ Dual Input\_ Parallel Units

In parallel mode, if one of the parallel UPSs needs maintenance, please first confirm that the bypass AC source and each parallel UPS's STS module are normal. After confirmation, please follow the procedures below to manually switch each of the parallel UPSs to manual bypass mode.

- 1 Press each LCD's ON/ OFF button (  ) once and the '**POWER OFF?**' screen will pop up to ask you if you want to power off the UPS's inverter. Please select '**YES**'.
- 2 Turn on each UPS's Manual Bypass Switch (Q3).
- 3 Turn off each UPS's Bypass Switch (Q2).
- 4 Turn off each UPS's Input Switch (Q1) and Output Switch (Q4).
- 5 Turn off each external battery cabinet's breaker (Q5).

In manual bypass mode, all power inside the parallel UPSs is completely cut off and maintenance personnel can perform maintenance safely. The connected critical loads will be supplied by manual bypass. During manual bypass mode, all parallel UPSs' tri-color LEDs and LCDs are off. Please see **Figure 3-26** for the path of electrical power through the parallel UPSs in manual bypass mode.




#### WARNING:

1. In manual bypass mode, make sure that all of the switches and breakers (except each UPS's Manual Bypass Switch (Q3)) are in the **OFF** position before working on any of the parallel UPSs' internal circuits. This avoids electric shock.
2. After the power inside all parallel UPSs is completely cut off, there is no high voltage inside the parallel UPSs except each UPS's wiring terminals and Manual Bypass Switch (Q3). Do not touch any UPS's wiring terminals and Manual Bypass Switch (Q3) during UPS maintenance process to avoid electric shock.
3. During manual bypass mode, the parallel UPSs' input power is completely cut off and the connected critical loads are not protected.



#### NOTE:

For parallel UPSs, if you want to turn off one of the parallel UPSs for maintenance, please make sure the connected critical loads will not exceed the remaining parallel units' total capacity.




(Figure 3-26: Manual Bypass Mode Diagram\_ Dual Input Parallel Units)

### 3.2.12 ECO Mode\_ Dual Input\_ Parallel Units

To activate ECO mode, please refer to **6.2.5 ECO Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.

In ECO mode (parallel), when each UPS's bypass input voltage and frequency are within the range of rating voltage  $\pm 10\%$  and rating frequency  $\pm 3\text{Hz}$ , each UPS works in bypass mode; otherwise, each UPS runs in online mode. During ECO mode, each UPS's tri-color LED illuminates green and each UPS's LCD shows the text 'ECO' in the upper right corner. Please see **Figure 3-27** for the path of electrical power through the parallel UPSs in ECO mode.



(Figure 3-27: ECO Mode Diagram\_ Dual Input Parallel Units)

### 3.2.13 Frequency Conversion Mode\_ Dual Input\_ Parallel Units

To activate frequency conversion mode, please refer to **6.2.6 Frequency Conversion Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.


For parallel application, after each of the parallel UPSs is manually set in frequency conversion mode, each inverter will automatically select 50Hz or 60Hz as the fixed output frequency.

After the output frequency is determined, each system will automatically disable the bypass function. Please note that, once each inverter shuts down, there is no bypass output. During frequency conversion mode, each UPS's tri-color LED illuminates green and each UPS's LCD shows the text '**Frequency Conversion**' in the upper right corner. Please see **Figure 3-28** for the path of electrical power through the parallel UPSs in frequency conversion mode.



#### NOTE:

During frequency conversion mode (parallel), once all of the UPSs' inverters shut down, there is no bypass output.




(Figure 3-28: Frequency Conversion Mode Diagram\_ Dual Input Parallel Units)



### 3.2.14 Green Mode\_ Dual Input\_ Parallel Units

To activate green mode, please refer to **6.2.7 Green Mode Start-up Procedures**, **7.6 Main Screen** and **7.10.2 Mode Setting**.

For parallel application, green mode is the same as online mode, but the difference is that each system will automatically detect its UPS's output status (i.e. total load capacity %) to decide which specific power modules should be fully powered on or idle in order to achieve higher efficiency of the UPS. During green mode, each UPS's tri-color LED illuminates green and each UPS's LCD shows the text 'Green' in the upper right corner. Please see **Figure 3-29** for the path of electrical power through the parallel UPSs in green mode.



(Figure 3-29: Green Mode Diagram\_ Dual Input Parallel Units)


### 3.3 Hot Standby Redundancy (Only For Dual Input & At Least Two UPSs)

To provide customers more application choices, the UPS with a dual-input configuration can have a hot standby redundancy function. If you use two UPSs and wish them to work in hot standby redundancy mode, please connect the output of UPS1 to the bypass AC source of UPS 2. Please see **Figure 3-30**.

For more information about the hot standby redundancy application, please contact service personnel.

In normal condition, it is the UPS 2 inverter that supplies power to the critical loads. Both UPS 1 & UPS 2 tri-color LEDs illuminate green.

When the UPS 2 inverter becomes abnormal, the UPS 2 will automatically transfer to bypass mode and the UPS 1 inverter will supply power to the critical loads. Under such circumstances, the UPS 1 tri-color LED illuminates green and the UPS 2 tri-color LED illuminates yellow.



(Figure 3-30: Hot Standby Redundancy Diagram (only for Dual Input & at Least Two UPSs))

### 3.4 Common Battery (Only for Parallel UPSs connecting to the Same External Battery Cabinet(s))

To save on your costs and installation space, the parallel UPSs can share their connected external battery cabinet(s). For common battery application, please install an isolated switch between each parallel UPS and its connected external battery cabinet(s). Please see **Figure 3-31** for two parallel UPSs sharing one external battery cabinet as an example.


If the parallel UPSs share the external battery cabinet(s), you should use the LCD to set up relevant parameters such as '**Battery Type**', '**Capacity**', '**Battery Strings**', '**Float Charge Voltage**', '**Equalized Charge Voltage**', '**Charge Current (Max)**', etc. For more information, please refer to **7.10.4 Battery & Charging Setting**.




#### NOTE:

For common battery application, please use the LCD to set each UPS's float charge voltage (default: 272V) the same, each UPS's equalized charge voltage (default: 280V) the same, and each UPS's charge current even. For example:

- A. When (1) two UPSs are paralleled, (2) they share one external battery cabinet, (3) the battery type is 200AH, (4) there are a total of 4 battery strings, and (5) the charge current is 80A, please use the LCD to set each UPS's '**Battery Type**' the same, '**Capacity**' as 200AH, '**Battery Strings**' as 2, and '**Charge Current (Max)**' as 40A.
- B. When (1) three UPSs are paralleled, (2) they share one external battery cabinet, (3) the battery type is 300AH, (4) there are a total of 3 battery strings, and (5) the charge current is 90A, please use the LCD to set each UPS's '**Battery Type**' the same, '**Capacity**' as 300AH, '**Battery Strings**' as 1, and '**Charge Current (Max)**' as 30A.



(Figure 3-31: Common Battery Diagram\_ only for Parallel UPSs Connecting to the Same External Battery Cabinet(s))




## **Communication Interfaces**

4.1 Communication Interfaces  
on the Front of the UPS with  
Front Door Open

4.2 Communication Interfaces at  
the Rear of the Touch Panel


The communication interfaces are hot swappable and located at two different places. One is on the front of the UPS with front door open and the other is at the rear of the touch panel. Please see **Figure 4-1**.




(Figure 4-1: Communication Interfaces Location)


### 4.1 Communication Interfaces on the Front of the UPS with Front Door Open

The following communication interfaces are located on the front of the UPS with front door open. Please see the description below.



(Figure 4-2: Communication Interfaces\_ on the Front of the UPS with Front Door Open)

No.	Item	Q'ty	Description
❶	Dry Contact Card	1 PC	Includes a display port, REPO dry contacts, external battery temperature dry contacts, external switch/ breaker status dry contacts, output dry contacts and input dry contacts.
❷	Parallel Communication Card Slot	1 PC	You can install the optional parallel communication card to increase the Q'ty of parallel ports.  <b>NOTE:</b> The optional parallel communication card includes two parallel ports and one LED indicator.
❸	Parallel Communication Card	1 PC	Includes two parallel ports and one LED indicator.
❹	SMART Slot	1 PC	You can install the optional Relay I/O card for dry contact expansion.
❺	System Control Card	1 PC	Includes a USB port and an RS-232 port.
❻	Auxiliary Power Card	2 PCS	Each card includes a LED indicator and a battery start button.




(Figure 4-3: Functions of Communication Interfaces)

### 4.1.1 Display Port

Before shipment, the display port has been connected to the 10" touch panel with the designated cable in Delta factory.

## 4.1.2 REPO Dry Contacts

The REPO dry contacts provide you with quick and convenient interfaces to shut down the UPS safely when an emergency occurs. Connect the REPO dry contacts to a user-supplied switch and you can remotely shut down the UPS. The REPO dry contacts provide normally open (NO) and normally closed (NC) these two options for use.




(Figure 4-4: REPO Dry Contacts Design)




### NOTE:

If you want to enable the normally closed (NC) function, please take out the dry contact card (see **Figure 4-5**) and remove its Jump CNR3 (see **Figure 4-6**) before you turn on the UPS.



(Figure 4-5: Dry Contact Card Location)






(Figure 4-6: Jump CNR3 Location)

### 4.1.3 External Battery Temperature Dry Contacts

You can use the external battery temperature dry contacts (BT1, BT2, BT3 and BT4) to detect at maximum four external battery cabinets' temperature. You need to purchase the battery cabinet temperature sensor cable (optional).




(Figure 4-7: External Battery Temperature Dry Contacts Design)

## 4.1.4 External Switch/ Breaker Status Dry Contacts

There are four sets of external switch/ breaker status dry contacts (S1, S2, S3 and S4), which can be used to detect the status of input, bypass, manual bypass and output switches or breakers. Please follow the table below to connect the dry contacts to normally open (NO) or normally closed (NC) devices.

Type	Connection
Dry Contact_ S1	Normally closed (NC) device
Dry Contact_ S2	Normally closed (NC) device
Dry Contact_ S3	Normally closed (NC) device
Dry Contact_ S4	Normally open (NO) device



(Figure 4-8: External Switch/ Breaker Status Dry Contacts Design)

No.	Event	Description
1	External input switch or breaker detection.	Detect the external input switch or breaker's status (default: S1).
2	External bypass switch or breaker detection.	Detect the external bypass switch or breaker's status (default: S2).
3	External output switch or breaker detection.	Detect the external output switch or breaker's status (default: S3).
4	External manual bypass switch or breaker detection.	Detect the external manual bypass switch or breaker's status (default: S4).


### 4.1.5 Output Dry Contacts

There are six sets of programmable output dry contacts (see **Figure 4-9**). Please use the touch panel to set each dry contact as normally open (NO) or normally closed (NC). Each dry contact can be assigned with a specific event. Six out of twenty-one events can be assigned according to your applications. To learn how to set up, please contact your local dealer and refer to **7.10.6 Dry Contact Setting**. For the twenty-one events, please refer to the table below.



#### NOTE:

Since the output dry contacts belong to the secondary circuit, the voltage of each dry contact's connected device should not exceed 60Vdc/ Vac to avoid electric shock and insufficient insulation.




(Figure 4-9: Output Dry Contacts Design)

No.	Event	Description
1	None	No set-up.
2	Load On Inverter	The UPS works in online mode.
3	Load On Bypass	The UPS works in bypass mode.
4	Load On Battery	When the main AC source fails, the batteries supply power to the critical loads.
5	Battery Low	When the UPS runs in battery mode, battery voltage is lower than the setup limit (default: 220Vdc).
6	Bypass Input Abnormal	The bypass voltage, frequency or phase sequence is abnormal.
7	Battery Test Fail	During the battery test, the battery voltage is out of the setup limit.
8	Internal Comm. Fail	The n# power module's internal communication is abnormal.
9	External Parallel Comm. Fail	In parallel mode, parallel communication is abnormal.
10	Output Overload	The UPS is overloaded or the UPS shuts down to let the bypass supply power to the critical loads.
11	EPO Activated	The EPO button is pressed to urgently power off the UPS.
12	Load On Manual Bypass	The Manual Bypass Switch (Q3) is turned on and the UPS transfers to manual bypass mode.
13	Battery Over Temperature	The external battery cabinet's temperature is too high.
14	Output Voltage Abnormal	The output voltage is too high or too low.
15	Battery Need Replacement	The battery replacement date is due.
16	Bypass Over Temperature	The bypass static switch temperature is too high.
17	Bypass Static Switch Fault	The bypass static switch has an open/ short issue.
18	UPS Over Temperature	The UPS temperature is too high.
19	Battery Breaker Shunt Trip	When the EPO button is pressed or low battery shutdown occurs, the UPS will send a signal to the connected external shunt trip device to cut off the battery power.
20	Backfeed Protection	When the UPS's bypass SCR has an open/ short issue, the UPS will send a signal to the connected external shunt trip device to cut off the backfeed voltage.
21	General Alarm	When any UPS alarm occurs, the UPS will send an I/O signal.

## 4.1.6 Input Dry Contacts

There are four sets of programmable input dry contacts (see **Figure 4-10**). Please use the touch panel to set each dry contact as normally open (NO) or normally closed (NC). The input dry contacts allow the UPS to receive external signals from peripheral devices and let the UPS response accordingly. Each input dry contact can be assigned with a specific event. There are eleven events can be assigned according to your applications. To learn how to set up, please contact your local dealer and refer to **7.10.6 Dry Contact Setting**. For information about the four events, please refer to the table below.



(Figure 4-10: Input Dry Contacts Design)


No.	Event	Description
1	None	No set-up.
2	Generator Status	Generator status detection.
3	Battery Ground Fail	Battery leakage detection.
4	External Battery Breaker Detection	Status detection of the external battery cabinet' breaker or switch.
5	Charger Off (Positive)* <sup>1</sup>	Turn off the charger (positive).
6	Charger Off (Negative)* <sup>1</sup>	Turn off the charger (negative).
7	Battery Abnormal Shutdown	In On-Line mode: the UPS will issue battery abnormal warning. In Battery mode: the UPS will turn to Bypass or Standby mode immediately.
8	Input Transformer OTW	Input transformer over temperature warning.
9	Output Transformer OTW	Output transformer over temperature warning.
10	Battery Fuse Open	The battery fuse is blown.
11	Charge Off* <sup>1</sup>	Turn off the charger.

**NOTE:**

\*<sup>1</sup> If you use non-Delta lithium-ion batteries, you must set up **Charger Off (Positive)**, **Charger Off (Negative)** and **Charge Off** these three items. Please refer to **7.10.4 Battery & Charging Setting** and **7.10.6 Dry Contact Setting** to perform relevant setup. If you have any questions, please contact Delta customer service.


### 4.1.7 Parallel Communication Card

The UPS has one parallel communication card and the card includes two parallel ports and one LED indicator. Please see **Figure 4-11** for relevant location. If the card work normally, its LED indicator will illuminate green; if not, the LED indicator will illuminate red. During initialization process, the card's LED indicator flashes yellow.




(Figure 4-11: Location of Parallel Communication Card and its LED Indicator)

You can purchase the optional parallel communication card and install it into the parallel communication card slot. For the slot location, please refer to **Figure 4-12**.



(Figure 4-12: Location of Parallel Communication Card Slot)

When there are two parallel communication cards installed in the UPS, the lower one is named the master parallel communication card (the card is a standard accessory) and the upper one is called the backup parallel communication card (the card is an optional accessory). Please refer to **Figure 4-13** for the two cards and their LED indicators' location.



(Figure 4-13: Location of Master and Backup Parallel Communication Cards and their LED Indicators)

If both cards work normally, the master parallel communication card's LED indicator will illuminate green and the backup parallel communication card's LED indicator will illuminate yellow.


If one card works normally and the other works abnormally, the normal card's LED indicator will illuminate green and the abnormal card's LED indicator will illuminate red.

During initialization process, both cards' LED indicators flash yellow.



### 4.1.8 Parallel Ports

The parallel ports (see **Figure 4-14**) are used to connect parallel UPSs to increase the system capacity and redundancy. With the provided parallel cable, up to eight UPS units with the same capacity, voltage and frequency can be paralleled. To enhance parallel reliability, please adopt Daisy Chain method (see **Figure 5-25** & **Figure 5-27**) to execute parallel configuration.



(Figure 4-14: Location of Parallel Ports)




#### WARNING:

The provided parallel cable is placed in the accessory package. Using other types of cables to connect the parallel UPSs may cause parallel failure, malfunctions and accidents.

### 4.1.9 SMART Slot

You can install the optional Relay I/O card (for dry contact expansion) into the SMART slot shown in **Figure 4-15**. For relevant installation and application information, please contact Delta customer service.



(Figure 4-15: SMART Slot Location)


### 4.1.10 USB Port & RS-232 Port

The USB port & RS-232 port are available for authorized service personnel.

### 4.1.11 Auxiliary Power Cards

The UPS has two auxiliary power cards. Each card has one LED indicator. Please see **Figure 4-16** for their location.


If the auxiliary power card works normally, its LED indicator will illuminate green. If the auxiliary power card is off or abnormal, its LED indicator will be off.



(Figure 4-16: Location of Auxiliary Power Cards and their LED Indicators)

### 4.1.12 Battery Start Buttons


Please refer to **6.2.2 Battery Mode Start-up Procedures** for relevant information.





(Figure 4-17: Location of Battery Start Buttons)


## 4.2 Communication Interfaces at the Rear of the Touch Panel

The following communication interfaces are located at the rear of the touch panel. Please see the description below.



(Figure 4-18: Communication Interfaces \_ at the Rear of the Touch Panel)

No.	Item	Function
①	RESET	Press the RESET button once to restart the LCD.
②	MODBUS (Built-in MODUBS card)	<ol style="list-style-type: none"> <li>1. Lets the UPS have MODBUS communication function.</li> <li>2. Connects to a user-supplied monitoring system.</li> </ol>
③	BMS	Connects to a user-supplied battery management system or Delta battery management system (optional).
④	DISPLAY	<ol style="list-style-type: none"> <li>1. Connects to the display port shown in <b>Figure 4-3</b>.</li> <li>2. Before shipment, the display port has been connected to the 10" touch panel with the designated cable in Delta factory.</li> </ol>
⑤	EMS/ CONSOLE	Connects to a user-supplied environmental monitoring system or Delta EnviroProbe 1000/ 1100/ 1200 (optional).
⑥	 (USB Ports)	There are two USB ports. Connect a user-supplied USB flash drive to any of the USB ports to (1) upgrade the UPS and LCD's firmware and (2) download event logs.
⑦	 (Built-in SNMP card)	<ol style="list-style-type: none"> <li>1. Lets the UPS have network communication function.</li> <li>2. Connects to a user-supplied monitoring system.</li> </ol>



## **Installation and Wiring**

- 5.1 Before Installation and Wiring
- 5.2 Installation Environment
- 5.3 UPS Transportation
- 5.4 Fixing the UPS
- 5.5 Wiring
- 5.6 External Battery Cabinet Connection Warnings
- 5.7 STS Module
- 5.8 Power Module

## 5.1 Before Installation and Wiring

1. Please read this user manual thoroughly before installation, wiring and usage. Only authorized Delta engineers or service personnel can perform installation, wiring, panel & cover removal, maintenance and operation. If you want to execute any action mentioned above by yourself, the action must be under the supervision of authorized Delta engineers or service personnel. If you use a forklift or other equipment to move the UPS, please make sure its load bearing is sufficient. Please refer to **Table 5-1**.
2. The UPS must be connected with an external battery cabinet (user-supplied and handled and configured by Delta service personnel). Please refer to **5.6 External Battery Cabinet Connection Warnings** for relevant information.
3. In this user manual, the meaning of Q1, Q2, Q3, Q4 and Q5 represents the following.

Code	Meaning
Q1	Input Switch
Q2	Bypass Switch
Q3	Manual Bypass Switch
Q4	Output Switch
Q5	External Battery Cabinet's Breaker


## 5.2 Installation Environment

- Install the UPS indoors. Do not place it outdoors.
- Make sure that transportation routes (e.g. corridors, door gates, elevators, etc.) and installation area can accommodate and bear the weight of the UPS, external battery cabinet(s) and handling equipment. Please refer to **Table 5-1** for floor weight loading information.

**Table 5-1: HPH UPS Floor Weight Loading Table**

HPH Series UPS_ 160/ 200kVA		
UPS Capacity	160kVA/150kW	200kVA/200kW
Power Module Q'ty	3	4
Weight	340kg	376kg
Weight Loading	515.2kg/m <sup>2</sup>	569.7kg/m <sup>2</sup>

- The UPS adopts top and bottom wiring. Please leave adequate space on the top and at the bottom of the UPS to allow cable entry.
- Ensure that the installation area is big enough for maintenance and ventilation. Since the UPS adopts the design of air inlet at the front and air outlet at the rear, we suggest that you:
  1. Keep a distance of 150cm from the front of the UPS for maintenance and ventilation.
  2. Keep a distance of 100cm from the back of the UPS for maintenance and ventilation.
  3. Keep a distance of 100cm from the top of the UPS for maintenance, wiring and ventilation.



(Figure 5-1: UPS Air Inlet & Outlet Direction)

- Keep the installation area clean. Please note that wiring routes must be hermetic to prevent possible damage from rodents.
- Keep the installation area's temperature around 25°C and humidity within 90%. The highest operating altitude is 1000 meters above sea level.
- For safety concerns, we suggest that you:
  1. Equip surroundings of the installation area with CO<sub>2</sub> or dry powder fire extinguishers.
  2. Install the UPS in an environment where fireproof materials are used to construct the walls, floors and ceilings.
  3. Install the UPS on a floor that is made of noncombustible materials.

- Do not allow unauthorized personnel to enter the installation area and assign specified personnel to keep the UPS key.




**WARNING:**

Do not use air conditioners or similar equipment to blow into the rear of the UPS and hinder ventilation.

## 5.3 UPS Transportation

- At the bottom of the UPS, there are four casters to help you to move the UPS to a designated area. Before you move the UPS, please turn the four leveling feet counterclockwise to raise them off the ground. This protects the leveling feet from damage when moving the UPS. Please use sufficient manpower (at least six people) and equipment (e.g. forklift) to carefully move the UPS from its pallet to ground. Please pay attention to the movement of the casters to avoid accidents.



(Figure 5-2: UPS Leveling Foot and Caster)



**NOTE:**

1. The UPS is fixed on the pallet with two balance supports. When taking apart the two balance supports from the UPS, please pay attention to the movement of the casters to avoid accidents.
  2. Please refer to the **Unpacking Guide** attached to the UPS external wooden box for location of the balance supports.
- The casters are designed to move on level ground. Do not move the UPS on an uneven surface. This might cause damage to the casters or tip the UPS which could damage the unit.
  - After the UPS has been removed from the pallet to ground, we suggest that at least three people move the UPS to the installation area. One person use their hands to hold a lateral side of the UPS, one person hold the other lateral side of the UPS with their hands, and one person use their hands to push the UPS either from the front side or from the backside to move the unit to the installation area and avoid tipping the UPS.




- If you need to move the UPS over a long distance, please use appropriate equipment like a forklift. Do not use the UPS casters to move the unit over a long distance.

## 5.4 Fixing the UPS


Please follow the steps below:

- 1 Before fixing the UPS in a designated installation area, please double check whether the area's floor weight loading is sufficient to bear the UPS, external battery cabinet(s) and handling equipment (i.e. forklift) to avoid accidents. For UPS floor weight loading information, please refer to **Table 5-1**.
- 2 After the UPS is moved to the designated installation area, use a #17 wrench to stabilize the UPS four leveling feet on the floor. Please note that the UPS must stand on the floor stably and levelly without any tipping.
- 3 Use a 17mm socket wrench and two M10 screws ① (originally used to fix the front balance support on the pallet) to install the front balance support (removed during the unpacking process) at the front of the UPS. Use the two expansion screws ② (provided by qualified service personnel) to fix the front balance support on the ground to avoid UPS movement. Please see **Figure 5-3**.



(Figure 5-3: Balance Support Installation\_ Front of the UPS)

- 4 Use a 17mm socket wrench and two M10 screws ① (originally used to fix the rear balance support on the pallet) to install the rear balance support (removed during the unpacking process) at the rear of the UPS. Use the two expansion screws ② (provided by qualified service personnel) to fix the rear balance support on the ground to avoid UPS movement. Please see **Figure 5-4**.



**(Figure 5-4: Balance Support Installation\_ Rear of the UPS)**



**WARNING:**

If you don't use the balance supports to fix the UPS on the ground, the unit might topple over. For safety concerns, please use the balance supports to fix the UPS to the floor.

- 5 Follow **5.5 Wiring** to perform wiring procedures.
- 6 Follow **5.6 External Battery Cabinet Connection Warnings** to connect the external battery cabinet(s).
- 7 After finishing the procedures above, close the UPS front door.

## 5.5 Wiring

### 5.5.1 Pre-wiring Warnings



**NOTE:**

1. Before wiring, please ensure that you have followed **5.4 Fixing the UPS** to fix the UPS in the designated installation area firmly.
2. Before wiring, please read **5.5 Wiring** thoroughly.
3. Only authorized Delta engineers or service personnel can perform installation, wiring, panel & cover removal, maintenance and operation. If you want to execute any action mentioned above by yourself, the action must be under the supervision of authorized Delta engineers or service personnel.

- Before wiring or making any electrical connection, make sure that the power supplied to the input and output of the UPS is completely cut off.
- The UPS adopts top and bottom wiring. Please leave adequate space on the top and at the bottom of the UPS to allow cable entry.
- Check that the size, diameter, phase, polarity are correct for each cable that needs connecting to the UPS and external battery cabinet(s). Please refer to **Table 5-2** for the specifications of input/ output/ battery cables and switches.

**Table 5-2: Specifications of Input, Output and Battery Copper Cables & Switches****NOTE:**

**Table 5-2** is based on (1) default input/ output voltage: 220V, (2) default battery Q'ty: 40PCS and (3) default charge current per power module: 5A. For other conditions different from **Table 5-2**, please contact service personnel for relevant values.

HPH 160/ 200kVA			
Capacity		160kVA/ 150kW	200kVA/ 200kW
Input	Rated current at input voltage 220V (in the status of battery charging)	252A	335A
	Recommended cable size (R/ S/ T/ N)	70 mm <sup>2</sup> x 2 PCS	95 mm <sup>2</sup> x 2 PCS
	Maximum cable size (R/ S/ T/ N)	240 mm <sup>2</sup> x 1 PC	240 mm <sup>2</sup> x 1 PC
	Cable lug width	30mm	
	Screw size	M10	
	Cable Q'ty	3 PCS per conduit	
Output	Rated current at output voltage 220V	243A	304A
	Recommended cable size (R/ S/ T/ N)	70 mm <sup>2</sup> x 2 PCS	95 mm <sup>2</sup> x 2 PCS
	Maximum cable size (R/ S/ T/ N)	240 mm <sup>2</sup> x 1 PC	240 mm <sup>2</sup> x 1 PC
	Cable lug width	30mm	
	Screw size	M10	
	Cable Q'ty	3 PCS per conduit	

HPH 160/ 200kVA			
Capacity		160kVA/ 150kW	200kVA/ 200kW
Battery	Nominal discharge current (condition: per cell 2V)	329A	439A
	Max. discharge current (condition: per cell 1.75V)	376A	501A
	Recommended cable size (+/- N)	95 mm <sup>2</sup> x 2 PCS	150 mm <sup>2</sup> x 2 PCS
	Maximum cable size (+/- N)	240 mm <sup>2</sup> x 1 PC	240 mm <sup>2</sup> x 1 PC
	Cable lug width	40mm	
	Screw size	M10	
	Cable Q'ty	2 PCS per conduit	
Tightening Torque		M10=250±10Kgf.cm	
Input Switch (Q1)		400A	
Bypass Switch (Q2)		400A	
Manual Bypass Switch (Q3)		400A	
Output Switch (Q4)		400A	



#### NOTE:

1. Please refer to national and local electrical codes for acceptable non-fuse switches, breakers and cable size.
  2. The cables mentioned in **Table 5-2** with PVC material and with temperature resistance up to 105°C are suggested. Please refer to national and local electrical codes for acceptable rated voltage and temperature.
  3. The tightening torque for M10 screw should be 250±10Kgf.cm.
- To avoid UPS failure, the input of the UPS must be Y connection.
  - If there is a floating voltage between the input power's neutral (N) and the ground (⊕), and you require that the VNG of the UPS should be zero, we suggest that you install an isolation transformer in front of the input side of the UPS, and connect the isolation transformer's secondary neutral (N) and the ground (⊕) to the nearest place of the transformer.

- The main AC source must be a three-phase four-wire system and meets the specifications specified on the UPS rating label. For main AC source connection, make sure it is in positive phase sequence. Please refer to **5.5.3 Single Unit Wiring** and **5.5.4 Parallel Units Wiring** for wiring information.
- For external battery cabinet connection, please check the battery polarity. Do not connect the batteries in reverse. Please refer to **5.6 External Battery Cabinet Connection Warnings**.
- Connect the external battery cabinet's grounding terminal (⊕) to the UPS's grounding terminal (⊕). Please refer to **Figure 5-20** and **Figure 5-26** for grounding information.
- The UPS's grounding terminal (⊕) must be grounded. Please use ring-type terminals when wiring. For the location of the UPS's grounding terminals (⊕), please refer to **Figure 5-13**.

**WARNING:**

1. Wrong wiring will cause damage to the UPS and electric shock.
2. For single input, the UPS will not work normally if the main AC power's neutral (N) is not firmly connected or not connected to the UPS's Input neutral (N).  
  
For dual input, the UPS will not work normally if the main AC power and bypass power's neutral (N) is not firmly connected or not connected to the UPS's Input neutral (N).
3. If the UPS is not grounded, the power boards and components might be damaged after the UPS is powered on.

## 5.5.2 Single Input/ Dual Input Modification


**WARNING:**

Only authorized Delta engineers or service personnel can modify single input/ dual input setup.

The UPS default setting is single input. If you want to modify it into dual input, please follow the procedures below.


1. Unscrew the six screws to remove the rear panel (see **Figure 5-5** and **Figure 5-6**). After removing the rear panel, you will see the AC Input terminals and Bypass Input terminals shown in **Figure 5-7**.

(Rear View)




(Figure 5-5: UPS Rear View)

(Rear View)




(Figure 5-6: Rear Panel & Screw Location)

(Rear View after  
Rear Panel Removal)



(Figure 5-7: Wiring Terminals\_ AC Input & Bypass Input )


- 2) Unscrew the six screw nuts and remove the three copper bars. Please refer to **Figure 5-8**.



(Figure 5-8: Remove the Six Screw Nuts and Three Copper Bars )

- 3) For dual input and top wiring application, follow **Figure 5-8-1** to install the removed three copper bars on the designated areas. Please secure the six screw nuts tightly.


(Dual Input & Top Wiring Application)



(Figure 5-8-1: Install the Three Copper Bars and Secure the Six Screw Nuts  
\_ for Dual Input & Top Wiring Application )

- 4 For dual input and bottom wiring application, follow **Figure 5-8-2** to install the removed three copper bars on the designated areas. Please secure the six screw nuts tightly.

**(Dual Input & Bottom Wiring Application)**



**(Figure 5-8-2: Install the Three Copper Bars and Secure the Six Screw Nuts  
\_ for Dual Input & Bottom Wiring Application )**



**NOTE:**

If you want to modify the UPS from dual input into single input, please reverse the procedures mentioned above.

### 5.5.3 Single Unit Wiring



**NOTE:**


1. Only authorized Delta engineers or service personnel can perform installation, wiring, panel & cover removal, maintenance and operation. If you want to execute any action mentioned above by yourself, the action must be under the supervision of authorized Delta engineers or service personnel.
2. The UPS rating voltage is 220/ 380Vac, 230/ 400Vac or 240/ 415Vac.
3. The external battery cabinet's rating voltage is  $\pm 240$ Vdc.
4. Before wiring, please read **5.5 Wiring** thoroughly.




- **Single Input (Single Unit)**

When there is only one AC power source, single unit wiring procedures are as follows.


- 1 The UPS adopts top and bottom wiring. Please leave adequate space on the top and at the bottom of the UPS to allow cable entry.
- 2 Remove the rear panel's six screws (**Figure 5-9 ~ Figure 5-10**) to see the wiring terminals (**Figure 5-11 ~ Figure 5-13**).




(Figure 5-9: UPS Rear View)




(Figure 5-10: Screw Location)



(Figure 5-11: Wiring Terminals\_ AC Input & Bypass Input )




(Figure 5-12: Wiring Terminals\_ Battery Input & UPS Output )




(Figure 5-13: Wiring Terminals\_ Grounding )

- 3 For top wiring, please remove the top cover (there are 6 screws) shown in **Figure 5-14**.



(Figure 5-14: Location of Top Cover )

- 4 For bottom wiring, please remove the bottom cover (there are 4 screws) shown in **Figure 5-15**.



(Figure 5-15: Location of Bottom Cover )

- 5 The wiring terminals include:

No.	Item	Description	Function
1	AC Input Terminals	Include R/ S/ T/ N terminals.	Connect to the main AC source.
2	Bypass Input Terminals	Include R/ S/ T/ N terminals.	Connect to the bypass AC source.
3	UPS Output Terminals	Include R/ S/ T/ N terminals.	Connect to the critical loads.
4	Battery Input Terminals	Include +/ -/ N terminals.	Connect to the external battery cabinet.
5	⊕	Includes one grounding terminal.	For the UPS's protective earthing.
6	⊕	Includes three grounding terminals.	For the external battery cabinet and critical loads' grounding.

- 6 Make sure the Input Switch (Q1), Bypass Switch (Q2), Manual Bypass Switch (Q3) and Output Switch (Q4) are in the **OFF** position. Please see **Figure 2-5** for switch location.
- 7 Make sure each external battery cabinet's breaker is in the **OFF** position.
- 8 Follow **Table 5-2** to select proper input, output and battery cables.
- 9 Connect the main AC source, output and external battery cabinet's cables to the UPS. There are two types of wiring, top wiring and bottom wiring. Please refer to the following.


**Figure 5-16: Single Unit Single Input Top Wiring Diagram\_ Step 1**

**Figure 5-17: Single Unit Single Input Top Wiring Diagram\_ Step 2**

**Figure 5-18: Single Unit Single Input Bottom Wiring Diagram\_ Step 1**


**Figure 5-19: Single Unit Single Input Bottom Wiring Diagram\_ Step 2**

### 5.6 External Battery Cabinet Connection Warnings




**(Figure 5-16: Single Unit Single Input Top Wiring Diagram\_ Step 1)**

### Single Input\_ Top Wiring\_ Step 2




(Figure 5-17: Single Unit Single Input Top Wiring Diagram\_ Step 2)

### Single Input\_ Bottom Wiring\_ Step 1



(Figure 5-18: Single Unit Single Input Bottom Wiring Diagram\_ Step 1)

## Single Input\_ Bottom Wiring\_ Step 2




(Figure 5-19: Single Unit Single Input Bottom Wiring Diagram\_ Step 2)

**NOTE:**

The UPS will not work normally if the main AC source's neutral (N) is not firmly connected or not connected to the UPS's Input neutral (N).

- 10 Follow the table below to select proper Protective Earth (PE) copper cables and **Figure 5-20** to ground the UPS, external battery cabinet(s) and connected critical loads. Please refer to national and local electrical codes for acceptable rated voltage and temperature. The minimum size of a PE copper cable shall be at least half of a phase conductor. The grounding diagram is for reference.

UPS Capacity		160kVA/ 150kW	200kVA/ 200kW
Suggested PE Cable Size	Input	70 mm <sup>2</sup> x 1 PC	95 mm <sup>2</sup> x 1 PC
	Output	70 mm <sup>2</sup> x 1 PC	95 mm <sup>2</sup> x 1 PC
	Battery	95 mm <sup>2</sup> x 1 PC	150 mm <sup>2</sup> x 1 PC
Cable Lug Width		40 mm	
Screw Size		M10	
Tightening Torque		M10 = 250 ± 10 kgf-cm	



(Figure 5-20: Grounding Diagram\_ Single Unit )

- **Dual Input (Single Unit)**

When there are two AC power sources, single unit wiring procedures are as follows.

- 1 Follow **5.5.2 Single Input/ Dual Input Modification** to modify the UPS into dual input.
- 2 Follow the procedures 1 ~ 8 stated in the section of **Single Input (Single Unit)**.
- 3 Connect the main AC source, bypass source, output and external battery cabinet's cables to the UPS. There are two types of wiring, top wiring and bottom wiring. Please refer to the following.

**Figure 5-21: Single Unit Dual Input Top Wiring Diagram\_ Step 1**

**Figure 5-22: Single Unit Dual Input Top Wiring Diagram\_ Step 2**


**Figure 5-23: Single Unit Dual Input Bottom Wiring Diagram\_ Step 1**

**Figure 5-24: Single Unit Dual Input Bottom Wiring Diagram\_ Step 2**

#### **5.6 External Battery Cabinet Connection Warnings**




### Dual Input\_Top Wiring\_ Step 1




(Figure 5-21: Single Unit Dual Input Top Wiring Diagram\_ Step 1)

### Dual Input\_Top Wiring\_ Step 2




(Figure 5-22: Single Unit Dual Input Top Wiring Diagram\_ Step 2)

### Dual Input\_ Bottom Wiring\_ Step 1



(Figure 5-23: Single Unit Dual Input Bottom Wiring Diagram\_ Step 1)

### Dual Input\_ Bottom Wiring\_ Step 2



(Figure 5-24: Single Unit Dual Input Bottom Wiring Diagram\_ Step 2)

**NOTE:**

The UPS will not work normally if the main AC source and bypass source's neutral (N) is not firmly connected or not connected to the UPS's Input neutral (N).

- ④ Follow the procedure ⑩ stated in the section of **Single Input (Single Unit)**.

## 5.5.4 Parallel Unit Wiring

**NOTE:**

1. Only authorized Delta engineers or service personnel can perform installation, wiring, panel & cover removal, maintenance and operation. If you want to execute any action mentioned above by yourself, the action must be under the supervision of authorized Delta engineers or service personnel.
2. Up to eight UPS units can be paralleled for redundancy and capacity expansion. Only UPSs with the same capacity, voltage and frequency can be paralleled. Please only use the provided parallel cable to parallel the UPS units. Otherwise, parallel functions will fail.
3. When UPSs are paralleled, the length of each unit's input cables plus output cables must be the same. This ensures that the parallel UPSs can equally share the critical loads in bypass mode.
4. The UPS rating voltage is 220/ 380Vac, 230/ 400Vac or 240/ 415Vac.
5. The external battery cabinet's rating voltage is  $\pm 240\text{Vdc}$ .
6. Before wiring, please read **5.5 Wiring** thoroughly.

### • Single Input (Parallel Units)

When there is only one AC power source, parallel units' wiring procedures are as follows.

- ① Please follow the procedures ① ~ ⑧ stated in the section of **Single Input (Single Unit)**.
- ② Connect the main AC source, output and external battery cabinet's cables to each UPS. There are two types of wiring, top wiring and bottom wiring. Please refer to the following.

**Figure 5-16: Single Unit Single Input Top Wiring Diagram\_ Step 1**


**Figure 5-17: Single Unit Single Input Top Wiring Diagram\_ Step 2**

**Figure 5-18: Single Unit Single Input Bottom Wiring Diagram\_ Step 1**

**Figure 5-19: Single Unit Single Input Bottom Wiring Diagram\_ Step 2**

**Figure 5-25: Parallel Units Single Input Wiring Diagram**

**5.6 External Battery Cabinet Connection Warnings**



(Figure 5-25: Parallel Units Single Input Wiring Diagram)




**NOTE:**

The UPS will not work normally if the main AC source's neutral (N) is not firmly connected or not connected to the UPS's Input neutral (N).

- 3 Use the provided parallel cable to connect the parallel ports on the parallel units. Please refer to **Figure 4-3** for the parallel port location.
- 4 Follow the table below to select proper Protective Earth (PE) copper cables and **Figure 5-26** to ground the UPS, external battery cabinet(s) and connected critical loads. Please refer to national and local electrical codes for acceptable rated voltage and temperature. The minimum size of a PE copper cable shall be at least half of a phase conductor. The grounding diagram is for reference.

UPS Capacity		160kVA/ 150kW	200kVA/ 200kW
Suggested PE Cable Size	Input	70 mm <sup>2</sup> x 1 PC	95 mm <sup>2</sup> x 1 PC
	Output	70 mm <sup>2</sup> x 1 PC	95 mm <sup>2</sup> x 1 PC
	Battery	95 mm <sup>2</sup> x 1 PC	150 mm <sup>2</sup> x 1 PC
Cable Lug Width		40 mm	
Screw Size		M10	
Tightening Torque		M10 = 250 ± 10 kgf-cm	



(Figure 5-26: Grounding Diagram\_ Parallel Units )



### WARNING:

Before start-up of the parallel units, qualified service personnel must set each UPS's '**Parallel Group ID**' (1 or 2) and '**Parallel ID**' (1~8) through the LCD. Otherwise, the parallel UPSs cannot be started. Please refer to **7.10.5 Parallel Setting**.

### • Dual Input (Parallel Units)

When there are two AC power sources, parallel units' wiring procedures are as follows.

- 1 Follow **5.5.2 Single Input/ Dual Input Modification** to modify the UPS from single input to dual input.
- 2 Refer to the procedures 1 ~ 8 stated in the section of **Single Input (Single Unit)**.
- 3 Connect the main AC source, bypass source, output and external battery cabinet's cables to each UPS. There are two types of wiring, top wiring and bottom wiring. Please refer to the following.

**Figure 5-21: Single Unit Dual Input Top Wiring Diagram\_ Step 1**


**Figure 5-22: Single Unit Dual Input Top Wiring Diagram\_ Step 2**

**Figure 5-23: Single Unit Dual Input Bottom Wiring Diagram\_ Step 1**

**Figure 5-24: Single Unit Dual Input Bottom Wiring Diagram\_ Step 2**

**Figure 5-27: Parallel Units Dual Input Wiring Diagram**

**5.6 External Battery Cabinet Connection Warnings**



(Figure 5-27: Parallel Units Dual Input Wiring Diagram)



**NOTE:**

The UPS will not work normally if the main AC source and bypass source's neutral (N) is not firmly connected or not connected to the UPS's Input neutral (N).

- 4 Use the provided parallel cable to connect the parallel ports on the parallel units. Please refer to **Figure 4-3** for the parallel port location.
- 5 Follow the procedure 10 stated in the section of **Single Input (Parallel Units)**.



**WARNING:**

Before start-up of the parallel units, qualified service personnel must set each UPS's '**Parallel Group ID**' (1 or 2) and '**Parallel ID**' (1~8) through the LCD. Otherwise, the parallel UPSs cannot be started. Please refer to **7.10.5 Parallel Setting**.

## 5.6 External Battery Cabinet Connection Warnings

You should connect the UPS with at least one external battery cabinet to ensure that the connected critical loads are protected when a power failure occurs. You can connect up to four units of external battery cabinets to the UPS.

- To ensure that the batteries are fully charged, please charge the batteries at least 8 hours before initial use of the UPS. The charging procedures are as follows.

① Connect the UPS to the main AC source and external battery cabinet(s). Please see **5. Installation and Wiring**.

② Follow **6. UPS Operation** to turn on the UPS and external battery cabinet(s). After the UPS is powered on, the UPS will automatically charge the batteries.



### WARNING:

You can connect the critical loads to the UPS only after the batteries are fully charged. This guarantees that the UPS can provide sufficient backup power to the critical loads connected when a power failure occurs.

### • Battery Parameters

No.	Item	Description
1	Charge Voltage	Float charge voltage: $\pm 272\text{Vdc}$ (default)
		Equalized charge voltage: $\pm 280\text{Vdc}$ (default)
2	Charge Current	Default: $\pm 5\text{A}$ (per power module)
		Minimum: $\pm 6\text{A}$
		Maximum: $\pm 45\text{A}$ (160kVA)/ $\pm 60\text{A}$ (200 kVA) (per power module's Max. current: 15A)
3	Low Battery Shutdown Voltage	$\pm 200\sim\pm 220\text{Vdc}$ (default: 210Vdc)
4	The Number of Batteries	12V x 40 PCS (default)


**NOTE:**

1. You can adjust the charge current from 6A to the maximum in increments of 1A. For the maximum value, please refer to the following table.

160kVA	200kVA
45A	60A

2. If you need to modify the default charge current setting and default low battery shutdown setting, please contact your local dealer or service personnel.
  3. You can follow on-site requirements to choose 12V × 30/ 32/ 34/ 36/ 38/ 40/ 42/ 44 or 46 PCS batteries. The change of the number of batteries will influence the change of applied specifications. For battery selection, installation and replacement, please contact your local dealer or customer service.
  4. The number of batteries that you set up via the LCD must be the same as that of on-site installation; otherwise, the batteries will be over charged, not fully charged or even seriously damaged.
- Only use the same type of batteries from the same supplier. Never use old, new and different Ah batteries at the same time.
  - The number of batteries must meet UPS requirements.
  - Do not connect the batteries in reverse.
  - Use a voltage meter to measure whether the total voltage, after the external battery cabinet connection, is around 12.5Vdc × the total number of batteries.
  - The default number of batteries is 40 PCS of 12V batteries connected in string, and you should connect the external battery cabinet's neutral to the middle 20<sup>th</sup> and 21<sup>st</sup> batteries. You should use battery cables to connect the external battery cabinet with the '+', '-' and 'N' terminals marked on the UPS. Please refer to **Figure 5-28**.





(Figure 5-28: External Battery Cabinet Connection)

- Please follow your UPS's rating to install an appropriate protective device for each external battery cabinet. You can choose to install either (1) an isolated switch connected in series with a DC fuse or (2) a DC circuit breaker. Please refer to **Table 5-3**.
- The protective device's capacity must be larger than the battery current shown in **Table 5-3**.

**Table 5-3: External Battery Cabinet's Protective Device (Default Battery Q'ty: 40 PCS)**

Power Module Q'ty	UPS Rating	Protective Device's Current	Protective Device's Voltage
3	160kVA/ 150kW	450A	(1) 4-pole DC breaker (per pole voltage $\geq 250\text{Vdc}$ ) or (2) 3-pole DC breaker (per pole voltage $\geq 500\text{Vdc}$ ) or (3) DC fuse $\geq 500\text{Vdc}$
4	200kVA/ 200kW	600A	

**NOTE:**

1. The table above is for 40 PCS batteries (default). If you install different numbers of batteries, please contact service personnel for protective device's current and voltage.
2. The above-mentioned DC fuse and DC circuit breaker are optional. If you want to buy any of them, please contact Delta service personnel.
3. If you need to parallel multiple units of external battery cabinets, please contact Delta service personnel for relevant information.
4. To extend backup time, you can parallel up to four units of external battery cabinets to the UPS. Please note that the number of the batteries in each of paralleled external battery cabinets must be the same.

- Please note that only authorized Delta engineers or service personnel can perform wiring or you can perform wiring only under the supervision of authorized Delta engineers or service personnel. To connect the external battery cabinet(s) to the UPS, please refer to:

***Figure 5-16: Single Unit Single Input Top Wiring Diagram\_ Step 1***

***Figure 5-17: Single Unit Single Input Top Wiring Diagram\_ Step 2***

***Figure 5-18: Single Unit Single Input Bottom Wiring Diagram\_ Step 1***

***Figure 5-19: Single Unit Single Input Bottom Wiring Diagram\_ Step 2***

***Figure 5-21: Single Unit Dual Input Top Wiring Diagram\_ Step 1***

***Figure 5-22: Single Unit Dual Input Top Wiring Diagram\_ Step 2***

***Figure 5-23: Single Unit Dual Input Bottom Wiring Diagram\_ Step 1***

***Figure 5-24: Single Unit Dual Input Bottom Wiring Diagram\_ Step 2***

***Table 5-3: External Battery Cabinet's Protective Device  
(Default Battery Q'ty: 40 PCS)***


- For the external battery cabinet's grounding information, please refer to:

***Figure 5-20: Grounding Diagram\_ Single Unit***

***Figure 5-26: Grounding Diagram\_ Parallel Units***

- The external battery cabinet's protective device must be planned and designed by qualified service personnel. The protective device should be either (1) an isolated switch connected in series with a DC fuse or (2) a DC circuit breaker; please refer to **Table 5-3**. When choosing the external battery cabinet's protective device, please take the following factors into consideration: (1) over current between the UPS and battery circuit, (2) short circuit, (3) wire/ cable material, and (4) local electrical regulations. If you have any questions about the external battery cabinet's protective device, please contact Delta service personnel. Please refer to **Figure 5-29 ~ Figure 5-31** for the installation of the external battery cabinet's protective device.


- Option 1: An isolated switch connected in series with a DC fuse (voltage  $\geq 500\text{Vdc}$ )



(Figure 5-29: Installation of an Isolated Switch Connected in Series with a DC Fuse)


- Option 2: A DC circuit breaker

- (1) 4-pole DC circuit breaker (per pole voltage  $\geq 250\text{Vdc}$ )



(Figure 5-30: Installation of a 4-Pole DC Circuit Breaker)

(2) 3-pole DC circuit breaker (per pole voltage  $\geq 500\text{Vdc}$ )



3-Pole DC Circuit Breaker

(Figure 5-31: Installation of a 3-Pole DC Circuit Breaker)

- To save on your costs and installation space, parallel UPSs (at maximum 8 units) can share external battery cabinet(s). For relevant information, please refer to **3.4 Common Battery (Only for Parallel UPSs connecting to the Same External Battery Cabinet(s))**.



**WARNING:**

- Before performing battery/ battery cabinet replacement, please turn off each external battery cabinet's breaker (Q5) to isolate the battery power from the UPS completely.
- A battery can present a risk of electric shock and high short-circuit current. Servicing of batteries and battery cabinets must be performed or supervised by qualified service personnel knowledgeable in batteries, battery cabinets and the required precautions. Keep unauthorized personnel away from batteries and battery cabinets.

- External Battery Cabinet Alarm**


When any external battery cabinet connected to the UPS has the following problems, the UPS system will sound an alarm. Please see the table below.

No.	External Battery Cabinet Status	Alarm
1	Battery Abnormal - Reversed	Sounds 50ms every second.
2	Battery Ground Fault	Sounds 50ms every second.

No.	External Battery Cabinet Status	Alarm
3	Battery Over Temperature	Sounds 50ms every second.
4	Battery Under Temperature	Sounds 50ms every second.
5	Battery Breaker Off	Sounds 50ms every 3 seconds.
6	Battery Disconnected (Missing)	Sounds once every second.
7	Battery Over Charged	Long beep.
8	Battery Test Fail	Sounds 50ms every second.
9	Battery End of Discharge Imminent	Sounds 50ms every second.
10	Battery End of Discharge	Long beep.
11	Battery Life Time Expired	Sounds 50ms every 3 seconds.


## 5.7 STS Module

The hot swappable STS module has been installed inside the UPS in the Delta factory before shipment. Please see **Figure 5-32** for its location.



(Figure 5-32: STS Module Location)

For STS module illustration, please refer to **Figure 5-33**.



(Figure 5-33: STS Module)


### 5.7.1 STS Module Installation


The hot swappable STS module has been installed inside the UPS in the Delta factory before shipment. If the STS module is removed for some reasons and you want to re-install it, please follow the steps below.



**WARNING:**


1. Only qualified service personnel can perform the following STS module installation procedures.
2. The STS module is heavy (> 21kg). At least two people are required for handling.

- 1 Confirm that the STS module's switch is in the lower position (  ).




(Figure 5-34: Confirm the STS Module's Switch in the Lower Position)

- 2 Insert the STS module into the unoccupied STS module slot until it snaps into place. Two people are required.





(Figure 5-35: Insert the STS Module into the UPS)

- 3 Re-install the four screws (removed during the STS module removal process) to firmly fix the STS module's bracket ears on the UPS cabinet.



(Figure 5-36: Fix the STS Module on the UPS)

- 4 Turn the STS module's switch to the upper position (  ).




(Figure 5-37: Turn the STS Module's Switch to the Upper Position)


## 5.7.2 STS Module Removal



### NOTE:

1. Only qualified service personnel can perform the following STS module removal procedures.
2. The STS module is heavy (> 21kg). At least two people are required for handling.


- 1 Turn the STS module's switch to the lower position (  ) and wait until the STS module's LED indicator becomes off.



(Figure 5-38: Turn the STS Module's Switch to the Lower Position)


- 2 Unscrew the four screws shown in **Figure 5-39**.






(Figure 5-39: Remove the Four Screws)

- 3 Pull out the STS module from the slot (two people are required) (see **Figure 5-40**). When the STS module cannot be pulled out any more, press the lock (see **Figure 5-41**) on the left side of the STS module in order to continuously pull out the module from the UPS cabinet.




(Figure 5-40: Remove the STS Module)



(Figure 5-41: Press the Lock of the STS Module)

### 5.7.3 STS Module's LED Indicator




(Figure 5-42: STS Module's LED Indicator )

The STS module's LED indicator shows its operation status. Please refer to the following table.

LED Indicator	Description
OFF	The STS module is OFF.
ON (yellow)	The STS module is working in bypass mode, ECO mode, or energy recycle mode.
Flashing (yellow)_ on for 0.3 second and off for 3 seconds	The STS module is abnormal.




**NOTE:**

In bypass mode, if you turn the STS module's switch to the lower position (  ), the STS module will shut down, its output and its LED indicator will turn off.


## 5.8 Power Module

For 160kVA UPS, it includes three power modules and each power module's capacity is 53.33kVA/ 50kW. For 200kVA UPS, it includes four power modules and each power module's capacity is 50kVA/ 50kW. For power module location, please refer to **Figure 5-43**.



(Figure 5-43: Power Module Location)

For power module illustration, please refer to **Figure 5-44**.



(Figure 5-44: Power Module )

## 5.8.1 Power Module Installation

The power modules have been installed inside the UPS in the Delta factory before shipment. If any power module is removed for some reasons and you want to re-install it, please follow the steps below.



### WARNING:

1. Only after the UPS is manually set in the manual bypass mode, can the following power module installation procedures be executed. To let the UPS run in manual bypass mode, please refer to:

**3.1.4 Manual Bypass Mode\_ Single Input\_ Single Unit**

**3.1.12 Manual Bypass Mode\_ Single Input\_ Parallel Units**


**3.2.4 Manual Bypass Mode\_ Dual Input\_ Single Unit**

**3.2.11 Manual Bypass Mode\_ Dual Input\_ Parallel Units**

2. Only qualified service personnel can perform the following power module installation procedures.
3. Each power module is heavy (> 36kg). At least two people are required for handling.
4. Please ensure that the total number of the power modules is correct. Otherwise, you cannot start up the UPS.


160kVA	200kVA
3 power modules	4 power modules

- 1 Confirm that the power module's switch is in the lower position (  ).




(Figure 5-45: Confirm the Power Module's Switch in the Lower Position)

- 2 Insert the power module into the unoccupied power module slot until it snaps into place. Two people are required.





(Figure 5-46: Insert the Power Module into the UPS)

- 3 Use the removed four M6 screws to firmly fix the power module's bracket ears on the UPS cabinet. Please refer to **Figure 5-47**.



(Figure 5-47: Fix the Power Module on the UPS)

- 4 Turn the power module's switch to the upper position (  ).



(Figure 5-48: Turn the Power Module's Switch to the Upper Position)

## 5.8.2 Power Module Removal



### NOTE:


1. Only after the UPS is manually set in the manual bypass mode, can the following power module removal procedures be executed. To let the UPS run in manual bypass mode, please refer to:


**3.1.4 Manual Bypass Mode\_ Single Input\_ Single Unit**


**3.1.12 Manual Bypass Mode\_ Single Input\_ Parallel Units**

**3.2.4 Manual Bypass Mode\_ Dual Input\_ Single Unit**

**3.2.11 Manual Bypass Mode\_ Dual Input\_ Parallel Units**


2. Only qualified service personnel can perform the following power module removal procedures.
3. Each power module is heavy (> 36kg). At least two people are required for handling.
4. In online mode, if you turn the power module's switch to the lower position (  ), the UPS will transfer to run in bypass mode.

- 1 Turn the power module's switch to the lower position (  ). After that, the power module will start discharging. After discharging, the power module's LED indicator will be off.




(Figure 5-49: Turn the Power Module's Switch to the Lower Position)

- 2 Use a screwdriver to remove the four screws shown in **Figure 5-50**.




(Figure 5-50: Remove the Four Screws)

- 3 Pull out the power module from the slot (two people are required) (see **Figure 5-51**). When the power module cannot be pulled out any more, press the lock (see **Figure 5-52**) on the left side of the power module in order to continuously pull out the module from the UPS cabinet.




(Figure 5-51: Remove the Power Module)



(Figure 5-52: Press the Lock of the Power Module)

### 5.8.3 Power Module's LED Indicator



(Figure 5-53: Power Module's LED Indicator )


The power module's LED indicator shows its operation status. Please refer to the following table.

LED Indicator	Description
OFF	The power module is OFF.
ON (green)	<ol style="list-style-type: none"> <li>1. The power module is running in online mode or in battery mode.</li> <li>2. The power module's inverter starts up.</li> <li>3. The power module's PFC starts up.</li> </ol>
Flashing (green)_ on for 2 seconds and off for 1 second	The power module is under discharging process.




LED Indicator	Description
Flashing (green)_ on for 0.3 second and off for 3 seconds	The power module is abnormal.

**NOTE:**

In online mode, if you turn the power module's switch to the lower position ( , the power module will shut down its output and discharge the DC BUS voltage until the voltage reaches to a safety level. After that, the power module's LED indicator will be off.





## UPS Operation

- 6.1 Pre Start-up & Pre Turn-off Warnings for Single Unit and Parallel Units
- 6.2 Start-up Procedures
- 6.3 Turn-off Procedures

## 6.1 Pre Start-up & Pre Turn-off Warnings for Single Unit and Parallel Units



### NOTE:

1. All unit No., UPS status, date, time, warning No., event No., load (%), battery remaining time, user login, administrator login, etc. shown in the LCD diagrams presented in **6. UPS Operation** are for reference only. Actual readings depend on the operation of the UPS.
2. In this user manual, the meaning of Q1, Q2, Q3, Q4 and Q5 represents the following.

Code	Meaning
Q1	Input Switch
Q2	Bypass Switch
Q3	Manual Bypass Switch
Q4	Output Switch
Q5	External Battery Cabinet's Breaker

3. Before operation, ensure that installation and wiring have been completely done according to **5. Installation and Wiring**, and relevant instructions have been followed.
4. Before operation, please refer to **2.8 Tri-color LED Indicator & Buzzer** and **7. LCD Display & Settings**.

### Single Unit

#### • Pre Start-up Warnings for Single Unit


1. Make sure that all of switches and breakers, including every external battery cabinet's breaker, are turned to the **OFF** position.
2. Make sure that the UPS's voltage difference between the Neutral (N) and Ground (⊕) is < 3V.
3. Check if the wiring is correct. Ensure that the AC power's voltage, frequency, phase and battery type meet the UPS's requirements.
4. Check if all power modules are properly installed and every power module's switch is in the upper position (⬆). Please refer to **5.8 Power Module** for more information.

- **Pre Turn-off Warnings for Single Unit**

If you perform turn-off procedures for single unit, all power will be completely cut off. Please make sure the critical loads connected to the UPS have already been safely shut down before you perform the turn-off procedures.

### **Parallel Units**

- **Pre Start-up Warnings for Parallel Units**

1. You can parallel at maximum eight UPS units.
2. For parallel units, ensure that each parallel cable (provided) is connected well.
3. Make sure that all of switches and breakers, including every external battery cabinet's breaker, are turned to the **OFF** position.
4. Make sure that each parallel UPS's voltage difference between the Neutral (N) and Ground (⊕) is  $< 3V$ .
5. Check if the wiring is correct. Ensure that the AC power's voltage, frequency, phase and battery type meet the UPS's requirements.
6. Check if all power modules are properly installed and every power module's switch is in the upper position (  ). Please refer to **5.8 Power Module** for more information.
7. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
8. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

- **Pre Turn-off Warnings for Parallel Units**

1. If you want to turn off one of the parallel UPSs, please check whether the remaining parallel units' total capacity exceeds the total critical loads. If the remaining parallel units' total capacity is less than the total critical loads, all parallel units will shut down due to overload.
2. If you perform turn-off procedures for all parallel UPSs, all power will be completely cut off. Please make sure that the critical loads connected to the parallel UPSs have already been safely shut down before you perform the turn-off procedures.

## 6.2 Start-up Procedures

### 6.2.1 Online Mode Start-up Procedures



#### WARNING:

1. For parallel units, please follow **6.2.3 Bypass Mode Start-up Procedures** to turn on each parallel UPS. After confirming that parallel operation can be normally run, follow the following procedures step by step.
2. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
3. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.


- 1 Ensure that the Manual Bypass Switch (Q3) is in the **OFF** position.
- 2 Switch **ON** every external battery cabinet's breaker (Q5).
- 3 Switch **ON** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4).
- 4 After you switch **ON** the Input Switch (Q1) and Bypass Switch (Q2), each auxiliary power card's LED indicator will illuminate green and the following status will occur simultaneously.
  - (1) The system and each power module will start initialization. After each power module finishes initialization, each power module's fans will start running, each power module will start establishing DC BUS voltage and each power module's LED indicator will illuminate green.
  - (2) The parallel communication card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate green.



#### NOTE:

If you purchase an additional parallel communication card (optional) and install it in the parallel communication card slot shown in **Figure 4-12**, the card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate yellow. For more information, please refer to **4.1.7 Parallel Communication Card**.

For the locations of parallel communication card, auxiliary power cards, power modules and associated LED indicators, please refer to **Figure 6-1**.



(Figure 6-1: The Locations of Parallel Communication Card, Auxiliary Power Cards, Power Modules and Associated LED Indicators)

- 5 The LCD initial screen (see **Figure 6-2**) will appear within 40 seconds after the Input Switch (Q1) and Bypass Switch (Q2) are turned on.




(Figure 6-2: LCD Initial Screen)

- 6 After 20 seconds of LCD initialization, the LCD will enter the **Main Screen**. For the **Main Screen** information, please refer to **7.6 Main Screen**.


Now, each power module keeps running and its LED indicator remains green. After each power module finishes establishing DC BUS voltage, the charger will start to charge the batteries.


If the bypass AC source is within the normal range, the UPS will transfer to run in bypass mode, the LCD screen will show as **Figure 6-3** and the tri-color LED indicator will illuminate yellow. For the location of the tri-color LED indicator, please refer to **Figure 2-12**.



(Figure 6-3: Main Screen\_ User Login & ON/ OFF Button Location)




- 7 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power on the UPS's inverter. Please select 'YES'.



(Figure 6-4: Power on Reminder Screen)

- 8 After selection of 'YES' to start up the UPS's inverter, each power module will start up and perform self-inspection. At the same time, the system begins synchronization with the bypass AC source. After the self-inspection is completed, the UPS will automatically transfer to run in online mode, the tri-color LED indicator will illuminate green and the following screen will appear. For the tri-color LED indicator location, please refer to **Figure 2-12**.



(Figure 6-5: Online Mode Screen)

## 6.2.2 Battery Mode Start-up Procedures



### WARNING:

1. For parallel units, please follow **6.2.3 Bypass Mode Start-up Procedures** to turn on each parallel UPS. After confirming that parallel operation can be normally run, follow the following procedures step by step.
2. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
3. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

- 1 Ensure that the Manual Bypass Switch (Q3) is in the **OFF** position.
- 2 Switch **ON** every external battery cabinet's breaker (Q5).
- 3 Switch **ON** the Output Switch (Q4).
- 4 Press any of the **BATT. START** buttons (see **Figure 7-2**) for one second and release it. After that, each auxiliary power card's LED indicator will illuminate green and the following status will occur simultaneously.
  - (1) The system and each power module will start initialization. After each power module finishes initialization, each power module's fans will start running.
  - (2) The parallel communication card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate green.



### NOTE:

If you purchase an additional parallel communication card (optional) and install it in the parallel communication card slot shown in **Figure 4-12**, the card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate yellow. For more information, please refer to **4.1.7 Parallel Communication Card**.


For the locations of parallel communication card, auxiliary power cards, power modules and associated LED indicators, please refer to **Figure 6-1**.

- 5 The LCD initial screen (see **Figure 6-6**) will appear within 40 seconds after each auxiliary power card's LED indicator illuminates green.




(Figure 6-6: LCD Initial Screen)

- 6 After 20 seconds of LCD initialization, the LCD will enter the **Main Screen** shown in **Figure 6-7** and the tri-color LED indicator will illuminate yellow. For the location of the tri-color LED indicator, please refer to **Figure 2-12**.




(Figure 6-7: Main Screen\_ User Login & ON/ OFF Button Location)

- 7 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power on the UPS. Please select 'YES'.



(Figure 6-8: Power on Reminder Screen)

- 8 After selection of 'YES' to start up the UPS's inverter, each power module will start up, each power module's LED indicator will illuminate green and each power module will perform self-inspection. After the self-inspection is completed, the UPS will automatically transfer to run in battery mode. At this moment, the tri-color LED indicator illuminates yellow and the following screen appears. For the tri-color LED indicator location, please refer to **Figure 2-12**.



(Figure 6-9: Battery Mode Screen)

### 6.2.3 Bypass Mode Start-up Procedures



**WARNING:**

1. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
2. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

- 1 Ensure that the Manual Bypass Switch (Q3) is in the **OFF** position.
- 2 Switch **ON** every external battery cabinet's breaker (Q5).
- 3 Switch **ON** the Input Switch (Q1) and Bypass Switch (Q2).
- 4 After you switch **ON** the Input Switch (Q1) and Bypass Switch (Q2), each auxiliary power card's LED indicator will illuminate green and the following status will occur simultaneously.
  - (1) The system and each power module will start initialization. After each power module finishes initialization, each power module's fans will start running, each power module will start establishing DC BUS voltage and each power module's LED indicator will illuminate green.
  - (2) The parallel communication card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate green.



**NOTE:**

If you purchase an additional parallel communication card (optional) and install it in the parallel communication card slot shown in **Figure 4-12**, the card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate yellow. For more information, please refer to **4.1.7 Parallel Communication Card**.

For the locations of parallel communication card, auxiliary power cards, power modules and associated LED indicators, please refer to **Figure 6-1**.

- 5 The LCD initial screen (see **Figure 6-10**) will appear within 40 seconds after the Input Switch (Q1) and Bypass Switch (Q2) are turned on.




(Figure 6-10: LCD Initial Screen)


- 6 After 20 seconds of LCD initialization, the LCD will enter the **Main Screen**. For the **Main Screen** information, please refer to **7.6 Main Screen**.


Now, each power module keeps running and its LED indicator remains green. After each power module finishes establishing DC BUS voltage, the charger will start to charge the batteries.

If the bypass AC source is within the normal range, the UPS will transfer to run in bypass mode, the LCD screen will show as **Figure 6-11** and the tri-color LED indicator will illuminate yellow. For the location of the tri-color LED indicator, please refer to **Figure 2-12**.



( Figure 6-11: Main Screen\_ User Login & ON/ OFF Button Location)

- 7 For parallel application, please check each parallel UPS's parallel settings. Please note that each parallel UPS's parallel ID No. must be different, and parallel group No., input, output and battery settings must be the same.
- 8 For parallel application, press the icon (  ) located in the upper left corner of the screen and check if the total number of the parallel UPSs is correct. The UPS with the smallest parallel ID No. is defined as the master unit. Please refer to **Figure 6-12**.




(Figure 6-12: Parallel ID No. Inquiry Screen)

- 9 For single unit, turn on the Output Switch (Q4).

For parallel units, ensure that the output voltage difference between each parallel UPS is below 3V. If larger than 3V, it means abnormal and please contact service personnel immediately. If below 3V, turn on each parallel UPS's Output Switch (Q4).

Now, the tri-color LED indicator illuminates yellow and the LCD shows the following screen (see **Figure 6-13**). For the location of the tri-color LED indicator, please refer to **Figure 2-12**.



(Figure 6-13: Bypass Mode Screen)

## 6.2.4 Manual Bypass Mode Start-up Procedures




### WARNING:

1. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
2. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.
3. Please note that you can turn on the Manual Bypass Switch (Q3) only when the UPS needs maintenance. In manual bypass mode, the connected critical loads will be supplied by the manual bypass and the output won't be protected. Please ensure that the bypass AC source is normal.
4. In manual bypass mode, the connected critical loads will be supplied by the manual bypass; thus, maintenance personnel can perform maintenance without interrupting the power supplying to the critical loads.
5. Ensure that all of the breakers and switches (except the Manual Bypass Switch (Q3)) are in the **OFF** position, and use a voltmeter to check there is no high voltage inside the UPS. Only after confirmation can service personnel perform UPS maintenance.
6. Please note that, during UPS maintenance process, the Manual Bypass Switch (Q3) and wiring terminals have high voltage. Do not touch the Manual Bypass Switch (Q3) and wiring terminals to avoid electric shock.


### • From Online Mode to Manual Bypass Mode


- 1 In online mode, the LCD's main screen shows as follows and the tri-color LED indicator illuminates green. For the tri-color LED indicator location, please refer to **Figure 2-12**.



( Figure 6-14: Online Mode Screen\_ User Login & ON/ OFF Button Location)




- 2 Check if the bypass voltage and STS module are normal or not.
- 3 If normal, press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power off the UPS's inverter.



(Figure 6-15: Power off Reminder Screen)

- 4 If normal, please select 'YES'. After that, the UPS will shut down the inverter and transfer to run in bypass mode.
- 5 Ensure that the UPS runs in bypass mode. After confirmation, turn on the Manual Bypass Switch (Q3).
- 6 Switch **OFF** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4). After that, the screen shows as follows.



(Figure 6-16: Manual Bypass Mode Screen)

- 7 When the UPS performs DC BUS discharging, each power module's LED indicator flashes green. After discharging, each power module's LED indicator will be off.
- 8 About three minutes later, the UPS will shut down, and the LCD and the tri-color LED will be off.
- 9 Switch **OFF** every external battery cabinet's breaker (Q5).

- **From Manual Bypass Mode to Online Mode**



**WARNING:**

1. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
2. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

- 1 Switch **ON** every external battery cabinet's breaker (Q5).
- 2 Switch **ON** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4).
- 3 After you switch **ON** the Input Switch (Q1) and Bypass Switch (Q2), each auxiliary power card's LED indicator will illuminate green and the following status will occur simultaneously.
  - (1) The system and each power module will start initialization. After each power module finishes initialization, each power module's fans will start running, each power module will start establishing DC BUS voltage and each power module's LED indicator will illuminate green.
  - (2) The parallel communication card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate green.



**NOTE:**

If you purchase an additional parallel communication card (optional) and install it in the parallel communication card slot shown in **Figure 4-12**, the card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate yellow. For more information, please refer to **4.1.7 Parallel Communication Card**.

For the locations of parallel communication card, auxiliary power cards, power modules and associated LED indicators, please refer to **Figure 6-1**.

- 4 The LCD initial screen (see **Figure 6-17**) will appear within 40 seconds after the Input Switch (Q1) and Bypass Switch (Q2) are turned on.




(Figure 6-17: LCD Initial Screen)


- 5 After 20 seconds of LCD initialization, the LCD will enter the **Main Screen**. For the **Main Screen** information, please refer to **7.6 Main Screen**.


Now, each power module keeps running and its LED indicator remains green. After each power module finishes establishing DC BUS voltage, the charger will start to charge the batteries.

If the bypass AC source is within the normal range, the UPS will transfer to run in bypass mode, the LCD screen will show as **Figure 6-18** and the tri-color LED indicator will illuminate yellow. For the location of the tri-color LED indicator, please refer to **Figure 2-12**.




( Figure 6-18: Manual Bypass Mode Screen\_ User Login & ON/ OFF Button Location)

- 6 Switch **OFF** the Manual Bypass Switch (Q3).
- 7 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power on the UPS's inverter. Please select '**YES**'.



(Figure 6-19: Power on Reminder Screen)

- 8 After selection of '**YES**' to start up the UPS's inverter, each power module will start up and perform self-inspection. At the same time, the system begins synchronization with the bypass AC source. After the self-inspection is completed, the UPS will automatically transfer to run in online mode, the tri-color LED indicator will illuminate green and the following screen will appear. For the tri-color LED indicator location, please refer to **Figure 2-12**.



(Figure 6-20: Online Mode Screen)

## 6.2.5 ECO Mode Start-up Procedures



### WARNING:

1. For parallel units, please follow **6.2.3 Bypass Mode Start-up Procedures** to turn on each parallel UPS. After confirming that parallel operation can be normally run, follow the following procedures step by step.
2. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
3. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

- 1 Ensure that the Manual Bypass Switch (Q3) is in the **OFF** position.
- 2 Switch **ON** every external battery cabinet's breaker (Q5).
- 3 Switch **ON** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4).
- 4 After you switch **ON** the Input Switch (Q1) and Bypass Switch (Q2), each auxiliary power card's LED indicator will illuminate green and the following status will occur simultaneously.
  - (1) The system and each power module will start initialization. After each power module finishes initialization, each power module's fans will start running, each power module will start establishing DC BUS voltage and each power module's LED indicator will illuminate green.
  - (2) The parallel communication card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate green.



### NOTE:

If you purchase an additional parallel communication card (optional) and install it in the parallel communication card slot shown in **Figure 4-12**, the card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate yellow. For more information, please refer to **4.1.7 Parallel Communication Card**.

For the locations of parallel communication card, auxiliary power cards, power modules and associated LED indicators, please refer to **Figure 6-1**.

- 5 The LCD initial screen (see **Figure 6-21**) will appear within 40 seconds after the Input Switch (Q1) and Bypass Switch (Q2) are turned on.




(Figure 6-21: LCD Initial Screen)

- 6 After 20 seconds of LCD initialization, the LCD will enter the **Main Screen**. For the **Main Screen** information, please refer to **7.6 Main Screen**.


Now, each power module keeps running and its LED indicator remains green. After each power module finishes establishing DC BUS voltage, the charger will start to charge the batteries.

If the bypass AC source is within the normal range, the UPS will transfer to run in bypass mode, the LCD screen will show as **Figure 6-22** and the tri-color LED indicator will illuminate yellow. For the location of the tri-color LED indicator, please refer to **Figure 2-12**.




( Figure 6-22: Main Screen\_ User Login)

- 7 Please log in as an **Administrator**. For the **Administrator** password, please contact service personnel. After login, ensure that you are in the **Administrator** login status (see **Figure 6-23**).





(Figure 6-23: Main Screen\_ Administrator Login & ON/ OFF Button Location)


- 8 Click **SETUP** → **Mode Setting** → **ECO**.



(Figure 6-24: Select ECO Mode)


- 9 After manually selecting **ECO** mode via the LCD, press the icon (  ) located in the upper left corner of the screen to go back to the **Main Screen**.

- 10 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power on the UPS's inverter. Please select 'YES'.



(Figure 6-25: Power on Reminder Screen)

- 11 After selection of 'YES' to start up the UPS's inverter, each power module will start up and perform self-inspection. At the same time, the system begins synchronization with the bypass AC source. After the self-inspection is completed, the UPS will automatically transfer to run in online mode. After the system confirms that the bypass voltage is normal, the UPS will automatically switch to run in ECO mode to let the bypass AC source supply power (see **Figure 6-26**). Now, the tri-color LED indicator illuminates green and the following screen appears. For the tri-color LED indicator location, please refer to **Figure 2-12**.



(Figure 6-26: ECO Mode Screen)



## 6.2.6 Frequency Conversion Mode Start-up Procedures



### WARNING:

1. For parallel units, please follow **6.2.3 Bypass Mode Start-up Procedures** to turn on each parallel UPS. After confirming that parallel operation can be normally run, follow the following procedures step by step.
2. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
3. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

- 1 Ensure that the Manual Bypass Switch (Q3) is in the **OFF** position.
- 2 Switch **ON** every external battery cabinet's breaker (Q5).
- 3 Switch **ON** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4).
- 4 After you switch **ON** the Input Switch (Q1) and Bypass Switch (Q2), each auxiliary power card's LED indicator will illuminate green and the following status will occur simultaneously.
  - (1) The system and each power module will start initialization. After each power module finishes initialization, each power module's fans will start running, each power module will start establishing DC BUS voltage and each power module's LED indicator will illuminate green.
  - (2) The parallel communication card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate green.



### NOTE:

If you purchase an additional parallel communication card (optional) and install it in the parallel communication card slot shown in **Figure 4-12**, the card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate yellow. For more information, please refer to **4.1.7 Parallel Communication Card**.

For the locations of parallel communication card, auxiliary power cards, power modules and associated LED indicators, please refer to **Figure 6-1**.

- 5 The LCD initial screen (see **Figure 6-27**) will appear within 40 seconds after the Input Switch (Q1) and Bypass Switch (Q2) are turned on.




(Figure 6-27: LCD Initial Screen)

- 6 After 20 seconds of LCD initialization, the LCD will enter the **Main Screen**. For the **Main Screen** information, please refer to **7.6 Main Screen**.


Now, each power module keeps running and its LED indicator remains green. After each power module finishes establishing DC BUS voltage, the charger will start to charge the batteries.

If the bypass AC source is within the normal range, the UPS will transfer to run in bypass mode, the LCD screen will show as **Figure 6-28** and the tri-color LED indicator will illuminate yellow. For the location of the tri-color LED indicator, please refer to **Figure 2-12**.




( Figure 6-28: Main Screen\_ User Login)

- 7 Please log in as an **Administrator**. For the **Administrator** password, please contact service personnel. After login, ensure that you are in the **Administrator** login status (see **Figure 6-29**).





(Figure 6-29: Main Screen\_ Administrator Login & ON/ OFF Button Location)


- 8 Click **SETUP** → **Mode Setting** → **Frequency Conversion**.



(Figure 6-30: Select Frequency Conversion Mode)


- 9 After manually selecting **Frequency Conversion** mode via the LCD, the UPS will run in standby mode and the output will be terminated.
- 10 Press the icon (  ) located in the upper left corner of the screen to go back to the **Main Screen**.

- 11 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power on the UPS's inverter. Please select 'YES'.



(Figure 6-31: Power on Reminder Screen)

- 12 After selection of 'YES' to start up the UPS's inverter, each power module will start up and perform self-inspection. After the self-inspection is completed, the UPS will automatically transfer to run in frequency conversion mode and the output frequency will be the same as setup value. Now, the tri-color LED indicator illuminates green and the following screen appears. For the tri-color LED indicator location, please refer to **Figure 2-12**.



(Figure 6-32: Frequency Conversion Mode Screen)

## 6.2.7 Green Mode Start-up Procedures



### WARNING:

1. For parallel units, please follow **6.2.3 Bypass Mode Start-up Procedures** to turn on each parallel UPS. After confirming that parallel operation can be normally run, follow the following procedures step by step.
2. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
3. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

- 1 Ensure that the Manual Bypass Switch (Q3) is in the **OFF** position.
- 2 Switch **ON** every external battery cabinet's breaker (Q5).
- 3 Switch **ON** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4).
- 4 After you switch **ON** the Input Switch (Q1) and Bypass Switch (Q2), each auxiliary power card's LED indicator will illuminate green and the following status will occur simultaneously.
  - (1) The system and each power module will start initialization. After each power module finishes initialization, each power module's fans will start running, each power module will start establishing DC BUS voltage and each power module's LED indicator will illuminate green.
  - (2) The parallel communication card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate green.



### NOTE:

If you purchase an additional parallel communication card (optional) and install it in the parallel communication card slot shown in **Figure 4-12**, the card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate yellow. For more information, please refer to **4.1.7 Parallel Communication Card**.

For the locations of parallel communication card, auxiliary power cards, power modules and associated LED indicators, please refer to **Figure 6-1**.

- 5 The LCD initial screen (see **Figure 6-33**) will appear within 40 seconds after the Input Switch (Q1) and Bypass Switch (Q2) are turned on.




(Figure 6-33: LCD Initial Screen)

- 6 After 20 seconds of LCD initialization, the LCD will enter the **Main Screen**. For the **Main Screen** information, please refer to **7.6 Main Screen**.


Now, each power module keeps running and its LED indicator remains green. After each power module finishes establishing DC BUS voltage, the charger will start to charge the batteries.

If the bypass AC source is within the normal range, the UPS will transfer to run in bypass mode, the LCD screen will show as **Figure 6-34** and the tri-color LED indicator will illuminate yellow. For the location of the tri-color LED indicator, please refer to **Figure 2-12**.




( Figure 6-34: Main Screen\_ User Login)

- 7 Please log in as an **Administrator**. For the **Administrator** password, please contact service personnel. After login, ensure that you are in the **Administrator** login status (see **Figure 6-35**).





(Figure 6-35: Main Screen\_ Administrator Login & ON/ OFF Button Location)


- 8 Click **SETUP** → **Mode Setting** → **Green**.



(Figure 6-36: Select Green Mode)


- 9 After manually selecting **Green** mode via the LCD, press the icon (  ) located in the upper left corner of the screen to go back to the **Main Screen**.

- 10 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power on the UPS's inverter. Please select 'YES'.



(Figure 6-37: Power on Reminder Screen)

- 11 After selection of 'YES' to start up the UPS's inverter, each power module will start up and perform self-inspection. At the same time, the system begins synchronization with the bypass AC source. After the self-inspection is completed, the UPS will automatically transfer to run in green mode and the system will automatically detect the output status (i.e. total load capacity %) to decide which specific power modules should be fully powered on or idle in order to achieve higher efficiency of the UPS. Now, the tri-color LED indicator illuminates green and the following screen appears. For the tri-color LED indicator location, please refer to **Figure 2-12**.



(Figure 6-38: Green Mode Screen)



## 6.2.8 Energy Recycle Mode Start-up Procedures

**WARNING:**

Energy recycle mode is only applicable to single input and single unit application.

- 1 Ensure that the Manual Bypass Switch (Q3), Output Switch (Q4) and every external battery cabinet's breaker (Q5) are in the **OFF** position.
- 2 Switch **ON** the Input Switch (Q1) and Bypass Switch (Q2).
- 3 After you switch **ON** the Input Switch (Q1) and Bypass Switch (Q2), each auxiliary power card's LED indicator will illuminate green and the following status will occur simultaneously.
  - (1) The system and each power module will start initialization. After each power module finishes initialization, each power module's fans will start running.
  - (2) The parallel communication card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate green.

**NOTE:**

If you purchase an additional parallel communication card (optional) and install it in the parallel communication card slot shown in **Figure 4-12**, the card's LED indicator will illuminate red first and then the card will start initialization. After initialization, the parallel communication card's LED indicator will illuminate yellow. For more information, please refer to **4.1.7 Parallel Communication Card**.

For the locations of parallel communication card, auxiliary power cards, power modules and associated LED indicators, please refer to **Figure 6-1**.


- 4 The LCD initial screen (see **Figure 6-39**) will appear within 40 seconds after the Input Switch (Q1) and Bypass Switch (Q2) are turned on.



(Figure 6-39: LCD Initial Screen)


- 5 After 20 seconds of LCD initialization, the LCD will enter the **Main Screen**. For the **Main Screen** information, please refer to **7.6 Main Screen**.

If the bypass AC source is within the normal range, the UPS will transfer to run in bypass mode, the LCD screen will show as **Figure 6-40** and the tri-color LED indicator will illuminate yellow. For the location of the tri-color LED indicator, please refer to **Figure 2-12**.




( Figure 6-40: Main Screen\_ User Login)

- 6 Please log in as an **Administrator**. For the **Administrator** password, please contact service personnel. After login, ensure that you are in the **Administrator** login status (see **Figure 6-41**).





(Figure 6-41: Main Screen\_ Administrator Login & ON/ OFF Button Location)


- 7 Click **SETUP** → **Mode Setting** → **Energy Recycle**.



(Figure 6-42: Select Energy Recycle Mode)


- 8 After manually selecting **Energy Recycle** mode via the LCD, press the icon (  ) located in the upper left corner of the screen to go back to the **Main Screen**.

- 9 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power on the UPS's inverter. Please select 'YES'.



(Figure 6-43: Power on Reminder Screen)

- 10 After selection of 'YES' to start up the UPS's inverter, each power module will start up and perform self-inspection. At the same time, the system begins synchronization with the bypass AC source. After the self-inspection is completed, the UPS will automatically transfer to run in energy recycle mode and perform self-aging test. Now, the tri-color LED indicator illuminates yellow and the following screen appears. For the tri-color LED indicator location, please refer to **Figure 2-12**.



(Figure 6-44: Energy Recycle Mode Screen)

## 6.3 Turn-off Procedures


### 6.3.1 Online Mode Turn-off Procedures




#### WARNING:


1. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
2. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

- 1 In online mode, the LCD shows the following screen (**Figure 6-45**) and the tri-color LED indicator illuminates green. For the tri-color LED indicator location, please refer to **Figure 2-12**.




( Figure 6-45: Online Mode Screen & ON/ OFF Button Location)

- 2 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power off the UPS's inverter. Please select 'YES'.



(Figure 6-46: Power off Reminder Screen)

- 3 After selection of 'YES', the UPS will shut down the inverter, terminate each power module's output and let the bypass AC source supply power. If the bypass AC source is abnormal, there is a risk of output interruption and the connected critical loads won't be protected. At this moment, each power module keeps charging the batteries, the tri-color LED indicator illuminates yellow and the following screen (**Figure 6-47**) appears. For the tri-color LED indicator location, please refer to **Figure 2-12**.



(Figure 6-47: Bypass Mode Screen)

- 4 Switch **OFF** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4). After that, the UPS will run in standby mode.
- 5 Now, each power module performs DC BUS discharging and its LED indicator flashes green. After discharging, each power module's LED indicator will be off.
- 6 About 3 minutes later, the UPS will shut down, and the LCD and the tri-color LED indicator will be off.
- 7 Switch **OFF** every external battery cabinet's breaker (Q5).


### 6.3.2 Battery Mode Turn-off Procedures




#### **WARNING:**


1. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
2. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

- 1 In battery mode, the LCD shows the following screen (**Figure 6-48**) and the tri-color LED indicator illuminates yellow. For the tri-color LED indicator location, please refer to **Figure 2-12**.




( Figure 6-48: Battery Mode Screen & ON/ OFF Button Location)

- 2 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power off the UPS's inverter. Please select 'YES'.



(Figure 6-49: Power off Reminder Screen)

- 3 After selection of 'YES', the UPS will shut down the inverter, terminate each power module's output and transfer to run in standby mode. At this moment, the tri-color LED indicator illuminates yellow and the following screen (**Figure 6-50**) appears. For the tri-color LED indicator location, please refer to **Figure 2-12**.



(Figure 6-50: Standby Mode Screen)

- 4 Switch **OFF** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4).
- 5 Now, each power module performs DC BUS discharging and its LED indicator flashes green. After discharging, each power module's LED indicator will be off.
- 6 About 3 minutes later, the UPS will shut down, and the LCD and the tri-color LED indicator will be off.
- 7 Switch **OFF** every external battery cabinet's breaker (Q5).


### 6.3.3 Bypass Mode Turn-off Procedures



#### **WARNING:**

1. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
  2. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.
- 1 In bypass mode, the LCD shows the following screen (**Figure 6-51**) and the tri-color LED indicator illuminates yellow. For the tri-color LED indicator location, please refer to **Figure 2-12**.





( Figure 6-51: Bypass Mode Screen)

- 2 Switch **OFF** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4). After that, the UPS will run in standby mode.
- 3 Now, each power module performs DC BUS discharging and its LED indicator flashes green. After discharging, each power module's LED indicator will be off.
- 4 About 3 minutes later, the UPS will shut down, and the LCD and the tri-color LED indicator will be off.
- 5 Switch **OFF** every external battery cabinet's breaker (Q5).

### 6.3.4 Manual Bypass Mode Turn-off Procedures



#### **WARNING:**

1. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
2. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

In manual bypass mode, the LCD and the tri-color LED indicator are both **OFF**. To completely shut down the UPS, switch **OFF** the Manual Bypass Switch (Q3).

**NOTE:**


1. Ensure that the LCD, all LED indicators and fans are **OFF**.
2. Check that all breakers, switches and power are **OFF**.

### 6.3.5 ECO Mode Turn-off Procedures


**WARNING:**


1. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
2. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.

- 1 In ECO mode, the LCD shows the following screen (**Figure 6-52**) and the tri-color LED indicator illuminates green. For the tri-color LED indicator location, please refer to **Figure 2-12**.




( Figure 6-52: ECO Mode Screen & ON/ OFF Button Location)

- 2 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power off the UPS's inverter. Please select 'YES'.




(Figure 6-53: Power off Reminder Screen)

- 3 After selection of 'YES', the UPS will shut down the inverter, terminate each power module's output and let the bypass AC source supply power. If the bypass AC source is abnormal, there is a risk of output interruption and the connected critical loads won't be protected. At this moment, each power module keeps charging the batteries, the tri-color LED indicator illuminates yellow and the following screen appears (Figure 6-54). For the tri-color LED indicator location, please refer to **Figure 2-12**.




(Figure 6-54: Bypass Mode Screen)

- 4 Please log in as an **Administrator**. For the **Administrator** password, please contact service personnel. After login, ensure that you are in the **Administrator** login status (see **Figure 6-55**).



(Figure 6-55: Bypass Mode Screen\_ Administrator Login)

- 5 Click **SETUP** → **Mode Setting** → **On-Line**.



(Figure 6-56: Select Online Mode)

- 6 Switch **OFF** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4).
- 7 Now, each power module performs DC BUS discharging and its LED indicator flashes green. After discharging, each power module's LED indicator will be off.
- 8 About 3 minutes later, the UPS will shut down, and the LCD and the tri-color LED indicator will be off.
- 9 Switch **OFF** every external battery cabinet's breaker (Q5).

### 6.3.6 Frequency Conversion Mode Turn-off Procedures




#### WARNING:

1. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
2. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.


1

In frequency conversion mode, the LCD shows the following screen (**Figure 6-57**) and the tri-color LED indicator illuminates green. For the tri-color LED indicator location, please refer to **Figure 2-12**.



( Figure 6-57: Frequency Conversion Mode Screen & ON/ OFF Button Location)


2

Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power off the UPS's inverter. Please select 'YES'.




#### WARNING:

Please note that, once you select 'YES', all power will be completely cut off. Please make sure that the critical loads connected to the UPS have already been safely shut down before you perform the turn-off procedures.




(Figure 6-58: Power off Reminder Screen)

- 3 After selection of 'YES', the UPS will shut down the inverter and terminate each power module's output. As there is no bypass output in frequency conversion mode, all output will be terminated right after the inverter is shut down. Now, each power module keeps charging the batteries, the tri-color LED indicator illuminates yellow and the following screen appears (**Figure 6-59**). For the tri-color LED indicator location, please refer to **Figure 2-12**.




(Figure 6-59: Standby Mode Screen)

- 4 Switch **OFF** the Output Switch (Q4) and log in as an **Administrator**. For the **Administrator** password, please contact service personnel. After login, ensure that you are in the **Administrator** login status (see **Figure 6-60**).



(Figure 6-60: Standby Mode Screen\_ Administrator Login)

- 5 Click **SETUP** → **Mode Setting** → **On-Line**. If the bypass voltage is in the normal range, the UPS will run in bypass mode to let the bypass AC source supply power to the output.



(Figure 6-61: Select Online Mode)


- 6 Switch **OFF** the Input Switch (Q1) and Bypass Switch (Q2).
- 7 Now, each power module performs DC BUS discharging and its LED indicator flashes green. After discharging, each power module's LED indicator will be off.
- 8 About 3 minutes later, the UPS will shut down, and the LCD and the tri-color LED indicator will be off.
- 9 Switch **OFF** every external battery cabinet's breaker (Q5).

### 6.3.7 Green Mode Turn-off Procedures




#### **WARNING:**


1. For parallel units, ensure that every operation procedure mentioned below is synchronized to all parallel UPSs.
  2. For parallel application, if you just want to operate a specific UPS but not all parallel ones, please contact service personnel.
- 1 In green mode, the LCD shows the following screen (**Figure 6-62**) and the tri-color LED indicator illuminates green. For the tri-color LED indicator location, please refer to **Figure 2-12**.



( Figure 6-62: Green Mode Screen & ON/ OFF Button Location)


- 2 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power off the UPS's inverter. Please select 'YES'.






(Figure 6-63: Power off Reminder Screen)

- 3 After selection of '**YES**', the UPS will shut down each power module's output and let the bypass AC source supply power. If the bypass AC source is abnormal, there is a risk of output interruption and the connected critical loads won't be protected. At this moment, each power module keeps charging the batteries, the tri-color LED indicator illuminates yellow and the following screen appears (**Figure 6-64**). For the tri-color LED indicator location, please refer to **Figure 2-12**.




(Figure 6-64: Bypass Mode Screen)

- 4 Please log in as an **Administrator**. For the **Administrator** password, please contact service personnel. After login, ensure that you are in the **Administrator** login status (see **Figure 6-65**).



(Figure 6-65: Bypass Mode Screen\_ Administrator Login)

- 5 Click **SETUP** → **Mode Setting** → **On-Line**. If the bypass voltage is in the normal range, the UPS will run in bypass mode to let the bypass AC source supply power to the output.



(Figure 6-66: Select Online Mode)

- 6 Switch **OFF** the Input Switch (Q1), Bypass Switch (Q2) and Output Switch (Q4).
- 7 Now, each power module performs DC BUS discharging and its LED indicator flashes green. After discharging, each power module's LED indicator will be off.
- 8 About 3 minutes later, the UPS will shut down, and the LCD and the tri-color LED indicator will be off.
- 9 Switch **OFF** every external battery cabinet's breaker (Q5).


### 6.3.8 Energy Recycle Mode Turn-off Procedures




#### **WARNING:**


Energy recycle mode is only applicable to single input and single unit application.

- 1 In energy recycle mode, the LCD shows the following screen (**Figure 6-67**) and the tri-color LED indicator illuminates yellow. For the tri-color LED indicator location, please refer to **Figure 2-12**.




( Figure 6-67: Energy Recycle Mode Screen & ON/ OFF Button Location)

- 2 Press the ON/ OFF button (  ) once and the following screen will pop up to ask you if you want to power off the UPS's inverter. Please select 'YES'.




(Figure 6-68: Power off Reminder Screen)

- 3 After selection of 'YES', the UPS will stop self-aging test and transfer to run in bypass mode. At this moment, the tri-color LED indicator illuminates yellow and the following screen appears (**Figure 6-69**). For the tri-color LED indicator location, please refer to **Figure 2-12**.




(Figure 6-69: Bypass Mode Screen)

- 4 Please log in as an **Administrator**. For the **Administrator** password, please contact service personnel. After login, ensure that you are in the **Administrator** login status (see **Figure 6-70**).



(Figure 6-70: Bypass Mode Screen\_ Administrator Login)


- 5 Click **SETUP** → **Mode Setting** → **On-Line**.



(Figure 6-71: Select Online Mode)

- 6 Switch **OFF** the Input Switch (Q1) and Bypass Switch (Q2).
- 7 The UPS will shut down, and then, the LCD and the tri-color LED indicator will be off.





## **LCD Display & Settings**

7.1 LCD Display Hierarchy

7.2 How to Turn on the LCD

7.3 ON/ OFF Button

7.4 Introduction of Touch Panel  
and Function Keys

7.5 Password Entry

7.6 Main Screen

7.7 Main Menu


7.8 Power Flow & Summary &  
System Status

7.9 Check System Readings

7.10 UPS Settings

7.11 System Maintenance

## 7.1 LCD Display Hierarchy



(Figure 7-1: LCD Display Hierarchy)




**NOTE:**

1. \*<sub>1</sub> means that the **ADMINISTRATOR** password is needed. For password information, please refer to **7.5 Password Entry**.
2. The information on the LCD screen presented in **7. LCD Display & Settings**, including UPS operation mode, machine number, date, time, total number of alarms, load %, battery remaining time, user login or administrator login, are for reference only. The actual screen of display depends on operation situation.
3. For how to turn on the touch panel, please refer to **7.2 How to Turn on the LCD** and **7.3 ON/ OFF Button**.

## 7.2 How to Turn on the LCD

1 To turn on the LCD, please follow the steps below:

- a. Turn on the Input Switch (Q1). After that, the LCD will be on and LCD initial screen (**Figure 7-3**) will appear; or
- b. Turn on the Bypass Switch (Q2). After that, the LCD will be on and LCD initial screen (**Figure 7-3**) will appear; or
- c. Turn on the Input Switch (Q1) and Bypass Switch (Q2). After that, the LCD will be on and LCD initial screen (**Figure 7-3**) will appear; or
- d. Turn on the external battery cabinet's breaker (Q5), open the front door of the UPS, and press any of the battery start buttons (**Figure 7-2**) for 1 second and release it. After that, the LCD will be on and LCD initial screen (**Figure 7-3**) will appear.




(Figure 7-2: The Position of Battery Start Buttons)



(Figure 7-3: LCD Initial Screen)


- 2 About 20 seconds after the LCD initial screen is on, the **Main Screen** will appear (see **Figure 7-4**). After you see the **Main Screen**, you can operate the LCD. Please note that the **Main Screen** appears in the **User** login status. Please refer to the figure below.



(Figure 7-4: Main Screen\_ User Login)

### 7.3 ON/ OFF Button

After the touch panel is turned on in accordance with the steps stated in **7.2 How to Turn on the LCD**, the main screen will appear in the **User** login status and the ON/ OFF Button (🔌) shown in **Figure 7-5** will appear.




(Figure 7-5: Main Screen\_ User Login & ON/ OFF Button Location)

- **Power On**

When the ON/ OFF button is gray (🔌), it indicates that the UPS's inverter is in the **OFF** status. Press the button once and a reminder window shown below will pop up to ask for confirmation of '**POWER ON**'.

After selecting '**Yes**', the ON/ OFF button will turn green (🔌), indicating that the power-on process is completed.




(Figure 7-6: Power On Reminder Window)

- **Power Off**


When the ON/ OFF button is green (🔌), it indicates that the UPS's inverter is in the **ON** status. Press the button once and a reminder window shown below will pop up to ask for confirmation of '**POWER OFF**'.

After selecting '**Yes**', the ON/ OFF button will turn gray (🔌), indicating that the power-off process is completed.




























(Figure 7-7: Power Off Reminder Window)








## 7.4 Introduction of Touch Panel and Function Keys






(Figure 7-8: Introduction of Touch Panel and Function Keys)













No.	Icon/ Text	Button Function (Yes or No)	Text/ Digital Display (Yes or No)	Symbol Display (Yes or No)	Description
①	 UPS-1.1	✓	✓		<p>Back to the main screen. The UPS-1.1 shown below the symbol  indicates the group ID and parallel ID of the UPS.</p> <p> <b>NOTE:</b> For the parallel UPSs (at maximum eight), if you press the master UPS's icon (  ), you can check the master UPS's every status and readings and also other slave UPSs' partial status and partial readings. If you press any of the slave UPSs' icons (  ), you can only check the slave UPS's partial status and partial readings.</p>
②	 MEASUREMENT	✓			Shortcut button for the measurement menu. For more information, please refer to <b>7.9 Check System Readings</b> .
③	 SETUP	✓			Shortcut button for the setup menu. For more information, please refer to <b>7.10 UPS Settings</b> .
④	 MAINTENANCE	✓			Shortcut button for the maintenance menu. For more information, please refer to <b>7.11 System Maintenance</b> .
⑤	 LOG IN User	✓		✓	Indicates login by <b>User</b> . The button can be pressed to change the login permission. For more information, please refer to <b>7.5 Password Entry</b> .
	 LOG IN Administrator	✓		✓	Indicates login by <b>Administrator</b> . The button can be pressed to change the login permission. For more information, please refer to <b>7.5 Password Entry</b> .

No.	Icon/ Text	Button Function (Yes or No)	Text/ Digital Display (Yes or No)	Symbol Display (Yes or No)	Description
6	 EVENT LOG	✓		✓	1. Event log shortcut button (  ). Press the button to check the total event logs. 2. When the warning symbol (  ) is blue, it indicates that there is no warning.
	 WARNING   WARNING 	✓	✓	✓	1. Warning event shortcut button (  ). 2. Buzzer button (  ). 3. When the warning symbol (  ) is red, it indicates that there is a warning. At this time, the buzzer will sound and the buzzer symbol (  ) will appear and light up. The numerical value at the right of the red warning symbol indicates the total number of warning events. By clicking the buzzer button (  ), the buzzer will be muted. At this time, the buzzer disabled symbol (  ) will appear.
7	09:30 May 10,2023		✓		Indicates the time and date.
8	On-Line ECO Frequency Conversion Green Energy Recycle Bypass Battery Standby Softstart		✓		Indicates the UPS operation status (the actual display will depend on the actual operation status).
9	 Power Flow	✓			Shortcut button for power flow diagram. Press the button to check the operation mode and status of the UPS. For more information, please refer to <b>7.8 Power Flow &amp; Summary &amp; System Status</b> .
10	 Summary	✓			Shortcut button for summary information. Press the button to check the input, output, and battery status of the UPS. For more information, please refer to <b>7.8 Power Flow &amp; Summary &amp; System Status</b> .



No.	Icon/ Text	Button Function (Yes or No)	Text/ Digital Display (Yes or No)	Symbol Display (Yes or No)	Description
11		✓			Shortcut button for system status. Press the button to check the status of each power module, parallel communication card, system control card, and auxiliary power card. For more information, please refer to <b>7.8 Power Flow &amp; Summary &amp; System Status</b> .
12		✓			Shortcut icon for EMS information. On the <b>EMS</b> screen, you can check the integrated status of each optional EMS 1000 (EnviroProbe) device connected to the UPS (Green: Normal; Yellow: Warning; Red: Alarm; Gray: Off); the integrated status is determined by the most severe status among the device's temperature (°C) status, humidity (%) status, and the status of input contacts DI1~DI4. Please refer to <b>7.8 Power Flow, Summary, System Status &amp; EMS</b> .
13		✓		✓	ON/ OFF button. For more information, please refer to <b>7.3 ON/ OFF Button</b> .
14		✓		✓	1. Bypass input status (green: normal; red: abnormal). 2. Bypass input screen shortcut button.
15		✓		✓	1. Main input status (green: normal; red: abnormal). 2. Main input screen shortcut button.
16		✓	✓	✓	1. Battery status (green: normal; red: abnormal). 2. Battery remaining capacity (%). 3. Battery remaining time (minutes). 4. Battery status screen shortcut button.
17				✓	Bypass static switch status (green: <b>ON</b> ; gray: <b>OFF</b> ).

No.	Icon/ Text	Button Function (Yes or No)	Text/ Digital Display (Yes or No)	Symbol Display (Yes or No)	Description
18				✓	Rectifier status (green: normal; gray: waiting or <b>OFF</b> ).
19		✓		✓	1. Inverter status (green: normal; gray: wait or <b>OFF</b> ). 2. Inverter output screen shortcut button.
20		✓	✓	✓	1. Output status (green: normal; gray: no output). 2. Load capacity (%). 3. Output screen shortcut button.


Other symbols which will appear during the operation of the touch panel are shown in the table below.

No.	Symbol	Function
1		Goes to the top page.
		
2		Goes to the last page.
3		Moves up.
		
4		Moves down.
		
5		Increases number.
6		Decreases number.
7		Indicates the page No.
8		Deletes number/ word.
		






No.	Symbol	Function
9		Capital
10		Space

**NOTE:**

1. After the back light is turned off, the user can gently touch the LCD to return to the **Main Screen**. For information about the **Main Screen**, please refer to **7.6 Main Screen**.
2. The sleep time for the back light can be adjusted. Please refer to **7.10.7 General Setting**.
3. If you are logged in as an **Administrator** (the **Administrator** password is required; please refer to **7.5 Password Entry**), you will be logged out when the backlight is off. After you touch the screen to wake it up, the LCD will go back to the **Main Screen** in the **User** login status. Even if you set up the backlight in '**Never Sleep**' mode, you will still be logged out after the screen is idle for 5 minutes.
4. The default language is English. If the language needs to be changed, please click  → **General Setting** → **User** → **Language** to change the displayed language of the screen. The default language will be different in different countries.

## 7.5 Password Entry


1. Password entry is only required for login as an **Administrator**. **User** login does not require a password.
2. Click  → enter the **Administrator** password (please contact service personnel for the default password) → the icon  appears, indicating the **Administrator** login is successful.
3. To change the **Administrator** password, click  → **General Setting** → **User** → **Administrator Password** (4 digits).

**NOTE:**


Different login IDs (Administrator/ User) have different access to different screens, inspection items and setup items. Please refer to **7.1 LCD Display Hierarchy**.

## 7.6 Main Screen


1. Please refer to **7.2 How to Turn on the LCD** and **7.3 ON/ OFF Button** to enter the **Main Screen**.
2. The system shows different power flow screens depending on the status of the UPS. Each power flow screen is a **Main Screen**. See the examples below.




The screen above indicates that the UPS is in standby mode. The inverter is not turned on and the bypass is out of the range.




The screen above indicates that the UPS is in bypass mode and the inverter is not turned on.




The screen above indicates that the UPS is in online mode and the loads are supplied by the inverter. Please refer to **7.10.2 Mode Setting** and **6.2.1 Online Mode Start-up Procedures**.




The screen above indicates that the UPS is in green mode. The loads are supplied by the inverter, and alternating power modules will turn off in accordance with the total load situation. For green mode settings, please refer to **7.10.2 Mode Setting** and **6.2.7 Green Mode Start-up Procedures**.




The screen above indicates that the UPS is in ECO mode. The inverter is in the ready-to-power-on status, and the loads are supplied by the bypass. For ECO mode settings, please refer to **7.10.2 Mode Setting** and **6.2.5 ECO Mode Start-up Procedures**.



The screen above indicates that the UPS is in energy recycle mode. The output power will be recycled to the input without being sent to the loads and the aging test could be conducted. For energy recycle mode settings, please refer to **7.10.2 Mode Setting** and **6.2.8 Energy Recycle Mode Start-up Procedures**.




The screen above indicates that the UPS is in frequency conversion mode and the bypass output is restricted. For frequency conversion mode settings, please refer to **7.10.2 Mode Setting** and **6.2.6 Frequency Conversion Mode Start-up Procedures**.






After the Manual Bypass Switch (Q3) is turned on, the UPS will be switched to manual bypass mode, and the screen above will appear. Before maintenance personnel perform maintenance, the UPS must be switched to this mode and it must be ensured that all input power and battery power are disconnected. After power disconnection, the LCD will be off. If there is any sudden malfunction in the bypass, the loads will lose power and become unprotected. Please refer to **6.2.4 Manual Bypass Mode Start-up Procedures**.

## 7.7 Main Menu

There are three main menu buttons  ,  and  ; positions are shown in the figure below.



Main Menu Button	Description
 MEASUREMENT	<p>Press the button to go to the <b>Measurement Menu</b>. In the menu, you can check the UPS's readings including the following:</p> <ol style="list-style-type: none"> <li>1. <b>Main Input</b></li> <li>2. <b>Bypass Input</b></li> <li>3. <b>Inverter Output</b></li> <li>4. <b>Power Module Summary</b></li> <li>5. <b>UPS Output</b></li> <li>6. <b>Battery Status</b></li> <li>7. <b>EMS</b></li> </ol> <p>For more information, please refer to <b>7.9 Check System Readings</b>.</p>
 SETUP	<p>Press the button to go to the <b>Setup Menu</b>. In the menu, you can set up the following settings.</p> <ol style="list-style-type: none"> <li>1. <b>Bypass Setting</b></li> <li>2. <b>Mode Setting</b></li> <li>3. <b>Output Setting</b></li> <li>4. <b>Battery &amp; Charging Setting</b></li> <li>5. <b>Parallel Setting</b></li> <li>6. <b>Dry Contact Setting</b></li> <li>7. <b>General Setting</b></li> <li>8. <b>IP Setting</b></li> <li>9. <b>Control</b></li> <li>10. <b>EMS Setting</b></li> <li>11. <b>Network Service</b></li> <li>12. <b>Remote User Setting</b></li> </ol> <p>For more information, please refer to <b>7.10 UPS Settings</b>.</p>


Main Menu Button	Description
 MAINTENANCE	<p>Press the button to go to the <b>Maintenance Menu</b>. In the menu, you can (1) check the warning events/ historical events/ statistics/ relevant temperature readings/ firmware version, (2) execute the manual battery test, (3) clear the statistics/ historical event/ battery test result, and (4) upgrade firmware.</p> <p>In the <b>Maintenance Menu</b>, it includes the following items.</p> <ol style="list-style-type: none"> <li>1. <b>Warning</b></li> <li>2. <b>Historical Event</b></li> <li>3. <b>Statistics</b></li> <li>4. <b>Test</b></li> <li>5. <b>Clear</b></li> <li>6. <b>Advanced Diagnosis</b></li> <li>7. <b>Version &amp; S/N</b></li> </ol> <p>For more information, please refer to <b>7.11 System Maintenance</b>.</p>

**NOTE:**


Different login IDs (Administrator/ User) have different access to different screens, inspection items and setup items. Please refer to **7.1 LCD Display Hierarchy**.


## 7.8 Power Flow, Summary, System Status & EMS


There are three shortcut buttons for you to check the **Power Flow**, **Summary**, and **System Status** respectively. Please see the figure below.




Press the  button to check the UPS's power flow diagram shown in the figure below.





Press the  button to check information related to input, output and battery. Please refer to the figure below.




Press the  button to check each status of the power module, bypass STS module, auxiliary power card, parallel communication card and system control card.






4. Press the  icon to check the integrated status of each optional EMS 1000 (EnviroProbe) device connected to the UPS (Green: Normal; Yellow: Warning; Red: Alarm; Gray: Off); the integrated status is determined by the most severe status among the device's temperature (°C) status, humidity (%) status, and the status of input contacts DI1~DI4.

For more EMS information, please refer to **7.9.7 EMS** and **7.10.10 EMS Setting**.




# 7.9 Check System Readings


## 7.9.1 Main Input

Path:  → Main Input


On the **MAIN INPUT** screen (shown in the figure below), users can inquire about the **Phase Voltage**, **Line Voltage**, **Current** and **Frequency** readings.




## 7.9.2 Bypass Input

Path:  → Bypass Input


On the **BYPASS INPUT** screen (shown in the figure below), users can inquire about the **Phase Voltage**, **Line Voltage** and **Frequency** readings.



### 7.9.3 Inverter Output

Path:  → Inverter Output


On the **INVERTER OUTPUT** screen (shown in the figure below), users can inquire about each power module's **Phase Voltage**, **Line Voltage**, **Current** and **Frequency** readings.




### 7.9.4 Power Module Summary

Path:  → Power Module Summary


On the **POWER MODULE SUMMARY** screen (shown in the figure below), users can inquire about each power module's **Phase Voltage**, **Current**, **DC BUS Voltage**, **PM A/D** and **PM D/D** readings.




## 7.9.5 UPS Output

Path:  → **UPS Output**


On the **UPS OUTPUT** screen (shown in the figure below), users can inquire about **Phase Voltage, Line Voltage, Current, Frequency, Load, Apparent Power, Active Power** and **Power Factor** readings.




UPS-1.1




MEASUREMENT  
UPS Output




SETUP




MAINTENANCE



LOG IN  
Administrator



EVENT LOG




09:30  
May 10, 2023

On-Line


UPS OUTPUT

Phase Voltage (V)	220.0	220.0	220.0	Apparent Power(KVA)	18.7	18.6	18.7
Line Voltage (V)	380.0	380.0	380.0	Active Power(KW)	18.7	18.6	18.7
Current (A)	227.0	227.0	227.0	Power Factor	0.99	0.99	0.99
Frequency (Hz)	50.0						
Load (%)	30	30	30				


## 7.9.6 Battery Status

Path:  → **Battery Status**

On the **BATTERY STATUS** screen (shown in the figure below), users can inquire about **Status, Voltage, Current, Remaining Capacity, Remaining Time, Estimated Recharging Time, Test Result, Battery Temperature (#1~#4)**, and each power module's **Charge Voltage** and **Charge Current**.




UPS-1.1




MEASUREMENT


Battery Status



SETUP




MAINTENANCE




LOG IN

Administrator



EVENT LOG



09:30

May 10, 2023

On-Line

BATTERY STATUS

PAGE 1

PAGE 2

Status	None	Test Result	None
Voltage (V)	+ 272.0 - 272.0	Battery Temp. #1 (°C)	-
Current (A)	+ 0 - 0	Battery Temp. #2 (°C)	-
Remaining Capacity (%)	90	Battery Temp. #3 (°C)	-
Remaining Time (mins)	05:00	Battery Temp. #4 (°C)	-
Estimated Recharging Time (mins)	00:00		

UPS-1.1	MEASUREMENT Battery Status	SETUP	MAINTENANCE	LOG IN Administrator	EVENT LOG	09:30 May 10, 2023 On-Line
BATTERY STATUS						
PAGE 1 PAGE 2						
Power Module#	1	2	3	4		
Charge Voltage of PM# (V)	+ 272.0 - 272.0	+ 272.0 - 272.0	+ 272.0 - 272.0	+ 272.0 - 272.0		
Charge Current of PM# (A)	+ 1.0 - 1.0	+ 1.0 - 1.0	+ 1.0 - 1.0	+ 1.0 - 1.0		

### 7.9.7 EMS


**Path 1:** Tap the shortcut icon (  ) on the **Main Screen**.


**Path 2:**  → **EMS**

To activate the EMS function of the UPS, you have to connect the optional EMS 1000 (EnviroProbe) device(s) with the UPS; the EMS information of each device (ID #) will be displayed on the **EMS** screen as shown in the figure below. Please refer to the table below for the descriptions of each item shown on the **EMS** screen.



#### NOTE:


1. The items shown on the **EMS** screen is related to the settings in the (  ) → **EMS Setting**; the settings can be adjusted according to your needs.
2. For installation of the optional EMS 1000 (EnviroProbe), please refer to **7.9.7.1 Connecting the optional EMS 1000 (EnviroProbe)** and the **EnviroProbe 1000 Quick Guide** attached in the package of the optional EMS 1000 (EnviroProbe).



No.	Item	Color (Status)	Descriptions
①	ID	Green (Normal) Yellow (Warning) Red (Alarm) Gray (Off)	<ol style="list-style-type: none"> <li>Different ID # represents a different EMS 1000 (EnviroProbe) device connected to the UPS. <p><b>NOTE:</b> The LCD will only show the EMS 1000 (EnviroProbe) devices (ID #) whose status have been set as '<b>Enable</b>'. Please refer to <b>7.10.10 EMS Setting</b>.</p> </li> <li>Shows the integrated status of each EMS 1000 (EnviroProbe) device connected to the UPS. The integrated status is determined by the most severe status among the device's temperature (°C) status, humidity (%) status, and the status of input contacts DI1~DI4.</li> </ol>

No.	Item	Color (Status)	Descriptions
②	Temperature	Green (Normal) Yellow (Warning) Red (Alarm)	<p>The color represents the status of Temperature/ Humidity based on the relevant settings. Please refer to <b>7.10.10 EMS Setting</b>.</p> <p>When the detected Temperature/ Humidity:</p> <ol style="list-style-type: none"> <li>1. is lower than the value set for <b>Warning</b>, it shows <b>Green</b>.</li> <li>2. is higher than the value set for <b>Warning</b> but lower than the value set for <b>Alarm</b>, it shows <b>Yellow</b>.</li> <li>3. is higher than the value set for <b>Alarm</b>, it shows <b>Red</b>.</li> <li>4. has reached the value set for <b>Alarm/ Warning</b>, the status will recover <b>from Alarm to Warning/ from Warning to Normal</b> respectively only when the detected value has been lowered to its corresponding <b>Recovery</b> value.</li> </ol>
③	Humidity	Green (Normal) Yellow (Warning) Red (Alarm)	
④	DI1 DI2 DI3 DI4	Green (None/ Information) Yellow (Warning) Red (Alarm)	<ol style="list-style-type: none"> <li>1. Different colors represent different triggered status of each input contact.</li> <li>2. The <b>Title</b> of input contacts DI1~DI4, <b>NO/ NC</b> setting, and <b>Event Type</b> can be adjusted according to your needs. Please refer to <b>7.10.10 EMS Setting</b>.</li> </ol>


1. If the status of the EMS 1000 (EnviroProbe) device (ID #) is OFF (gray) as shown in the figure below, it means the communication of the device (ID #) is abnormal.



The reasons may be:


- (1) The status of the EMS 1000 (EnviroProbe) device (ID #) has been set as '**Enable**' (please refer to **7.10.10 EMS Setting**), but the device (ID #) is not connected to the UPS or the connection cable may be damaged.
- (2) The ID # setting is wrong. Please refer to **7.10.10 EMS Setting**.

At this time, the warning message '**The EMS 1000 ID # Communication Fail**' shown in the figure below will appear. For solutions, please refer to **10. Troubleshooting**.



2. After connection of the EMS 1000 (EnviroProbe) to the UPS, if you don't set the status of the EMS 1000 (EnviroProbe) device (ID #) as '**Enable**' (please refer to **7.10.10 EMS Setting**), the information of the EMS 1000 (EnviroProbe) device (ID #) will not show on the **EMS** screen.

If none of the status of the EMS 1000 (EnviroProbe) devices (ID #) is set as '**Enable**' (please refer to **7.10.10 EMS Setting**), the **EMS** screen will show as follows.





### 7.9.7.1 Connecting the optional EMS 1000 (EnviroProbe)

1. You can connect a maximum of 16 optional EMS 1000 (EnviroProbe) devices to each UPS to expand the environment monitoring range. A maximum of 8 UPS units can be paralleled. Please use the CAT-5 cable (user-supplied & the cable length depends on the on-site application and environment) to connect the EMS 1000 (EnviroProbe) to the EMS port on the UPS. For the location of the EMS port, please refer to **4.2 Communication Interfaces at the Rear of the Touch Panel**; for more information about installation of the optional EMS 1000 (EnviroProbe), please refer to **EnviroProbe 1000 Quick Guide**.
2. The UPS only supports RS485 communication mode. When installing the EMS 1000 (EnviroProbe), please set the device's communication mode as RS485 following **3-1 Comm DIP Switch Settings** of the **EnviroProbe 1000 Quick Guide**.
3. You have to assign a different ID # for each EMS 1000 (EnviroProbe) device connected to the UPS for the UPS to identify different devices. When installing the EMS 1000 (EnviroProbe), please set the ID # by the four ID DIP switches on the left of the device following **3-2 ID DIP Switch Settings** of the **EnviroProbe 1000 Quick Guide**.

**NOTE:**


1. You must set the ID # on the LCD according to the ID DIP switch setting on the EMS 1000 (EnviroProbe) device. Please refer to **7.10.10 EMS Setting**.
2. The ID # of each EMS 1000 (EnviroProbe) device connected to the UPS must be different.
3. When connecting more than one EMS 1000 (EnviroProbe) devices to the UPS, you don't have to set the ID # in numerical order.
4. To enable the EMS function of the UPS, you have to set up relevant items on the LCD after connecting the optional EMS 1000 (EnviroProbe) to the UPS. Please refer to **7.10.10 EMS Setting**.

## 7.10 UPS Settings

### 7.10.1 Bypass Setting

Path:  → **Bypass Setting**

On the **BYPASS SETTING** screen (shown in the figure below), **Bypass Frequency Range**, **Bypass Voltage (Max.)**, **Bypass Voltage (Min.)** and **ECO Voltage Range** can be set up. If the range is exceeded, the system will issue an alarm. Only qualified service personnel can perform the above-mentioned setup items. Please contact Delta customer service for assistance.



09:30  
May 10, 2023

UPS-1.1 MEASUREMENT **SETUP** MAINTENANCE LOG IN Administrator EVENT LOG Bypass

SETUP  
Bypass setting

**BYPASS SETTING**

Bypass Frequency Range: ± 3 Hz

Bypass Voltage (Max.): + 10 %

Bypass Voltage (Min.): - 10 %


ECO Voltage Range (±%): ± 9 %

Item	Description
<b>Bypass Frequency Range</b>	Set up the bypass output's frequency range.
<b>Bypass Voltage (Max.)</b>	Set up the bypass output's maximum voltage.
<b>Bypass Voltage (Min.)</b>	Set up the bypass output's minimum voltage.
<b>ECO Voltage Range</b>	Set up the bypass output's voltage range in ECO mode.

## 7.10.2 Mode Setting

Path:  → **Mode Setting**

On the **MODE SETTING** screen (shown in the figure below), five options, **On-Line Mode**, **Green Mode**, **ECO Mode**, **Energy Recycle Mode** and **Frequency Conversion Mode** can be selected. These settings must be performed by qualified service personnel. Please contact Delta customer service for assistance.




Item	Description
<b>On-Line Mode</b>	Set up the UPS in on-line mode. In on-line mode, it is the inverter to supply power to the connected loads.
<b>Green Mode</b>	Set up the UPS in green mode. In green mode, it is the inverter to supply power to the connected loads and the power modules take turn to rest according to the situation of total load capacity.
<b>ECO Mode</b>	Set up the UPS in ECO mode. In ECO mode, it is the bypass to supply power to the connected loads. It is suggested that you set the UPS in ECO mode only when there is stable main AC power. Otherwise, power supply quality will be compromised.
<b>Energy Recycle Mode</b>	Set up the UPS in energy recycle mode. In energy recycle mode, the full load output can be simulated for the aging test without real output to the loads.
<b>Frequency Conversion Mode</b>	Set up the UPS in frequency conversation mode. In frequency conversation mode, it is the inverter to supply power to the connected loads with a fixed output frequency. Please note that the output will be terminated once the inverter is turned off.

## 7.10.3 Output Setting

Path:  → **Output Setting**

On the **OUTPUT SETTING** screen (shown in the figure below), the following items can be set up. These settings must be carried out by qualified service personnel. Please contact Delta customer service for assistance.




Item	Description
<b>Voltage</b>	Set up the output voltage.
<b>Voltage Compensation</b>	When the UPS is distant from the loads and there is a voltage drop in the output, you can adjust the INV output voltage amplitude for voltage compensation.
<b>Frequency</b>	Set up the output frequency as 50Hz (default) or 60Hz. The system will automatically select the output frequency in accordance with the bypass power.
<b>Slew Rate</b>	Set up the maximum permissible speed for the system output frequency to catch up the bypass frequency variation.
<b>Power Module Redundancy</b>	Set up how many power modules that need to be preserved for redundancy.
<b>Asynchronous Transfer Time</b>	When it is impossible for the inverter to reach synchronous phase lock with the bypass, the output will be terminated during conversion process according to this setup time.
<b>Module Sequential Start</b>	Set up the time interval for every power module to be converted from the battery mode to online mode. The setup is applicable to the generator to avoid bearing the whole loads right away.

Item	Description
<b>System Sequential Start</b>	Set up the time interval for the system to be converted from the battery mode to online mode. The setup is applicable to the generator to avoid bearing the whole loads right away.

### 7.10.4 Battery & Charging Setting


Path:  → **Battery & Charging Setting**

On the **BATTERY & CHARGING SETTING** screen (shown in the figure below), the following items can be set up. These settings must be carried out by qualified service personnel. Please contact Delta customer service for assistance.



BATTERY & CHARGING SETTING		
Battery Type PbAc ▼	Battery Rating Voltage 240 V	Battery Strings 1 ▼
Battery Low Warning 220 V	Battery Cut Off Voltage 210 V	Capacity 450 A
Float Charge Voltage 272 V	Equalized Charge Voltage 280 V	Charge Current (Max) 45 A

Submit



BATTERY & CHARGING SETTING		
Auto Equalized Charge Disable ▼	Auto Equalized Charge Interval 1 Month ▼	Equalized Charge Time 480 min

UPS-1.1

MEASUREMENT

SETUP

Battery & Charging Setting

MAINTENANCE

LOG IN  
Administrator

EVENT LOG

09:30  
May 10, 2023

Bypass

BATTERY & CHARGING SETTING

PAGE 1

PAGE 2

PAGE 3

PAGE 4

Battery Test Fail Voltage

0 V

Battery Test Duration

3 min

Auto Battery Test Interval

None ▼

UPS-1.1

MEASUREMENT

SETUP

Battery & Charging Setting

MAINTENANCE

LOG IN  
Administrator

EVENT LOG

09:30  
May 10, 2023

Bypass

BATTERY & CHARGING SETTING

PAGE 1

PAGE 2

PAGE 3

PAGE 4

Low Temperature Alarm

Enable ▼

10 °C

Installation Date

2018-May-10 ▼

High Temperature Alarm

Enable ▼

40 °C

Next Replacement Date

2021-May-10 ▼

Item	Description
<b>Battery Type</b>	Set up the battery type.
<b>Battery Rating Voltage</b>	Set up the battery rating voltage.
<b>Battery Strings</b>	Set up how many battery strings that are used on site.
<b>Battery Low Warning</b>	Set up the battery low warning voltage.
<b>Battery Cut Off Voltage</b>	Set up the battery low voltage. In battery mode, when the battery low voltage is reached, the battery power will cut off, the UPS will shut down, and the connected loads won't be protected.
<b>Capacity</b>	Set up the battery capacity.
<b>Float Charge Voltage</b>	Set up the float charge voltage.

Item	Description
<b>Equalized Charge Voltage</b>	Set up the equalized charge voltage.
<b>Charge Current (Max.)</b>	Set up the maximum charge current.
<b>Auto Equalized Charge</b>	Enable or disable the auto-equalized charge.
<b>Auto Equalized Charge Interval</b>	Set up the auto equalized charge interval.
<b>Equalized Charge Time</b>	Set up the equalized charge time.
<b>Battery Test Fail Voltage</b>	Set up the battery test fail voltage. When the battery voltage is under the test fail voltage, it means battery fail.
<b>Battery Test Duration</b>	Set up how long the battery test should last.
<b>Auto Battery Test Interval</b>	Set up the battery test interval.
<b>Low Temperature Alarm</b>	Enable or disable the low temperature alarm. If enabled, set up the temperature.
<b>High Temperature Alarm</b>	Enable or disable the high temperature alarm. If enabled, set up the temperature.
<b>Installation Date</b>	Record the battery installation date.
<b>Next Replacement Date</b>	Set up the battery replacement date.

### 7.10.5 Parallel Setting

Path:  → **Parallel Setting**

On the **PARALLEL SETTING** screen (shown in the figure below), the following items can be set up. These settings must be carried out by qualified service personnel. Please contact Delta customer service for assistance.

The screenshot shows the 'PARALLEL SETTING' screen. At the top, there is a navigation bar with icons for 'UPS-1.1', 'MEASUREMENT', 'SETUP Parallel Setting' (highlighted), 'MAINTENANCE', 'LOG IN Administrator', 'EVENT LOG', and a 'Bypass' button. The main content area has a blue background and contains three settings:


- Parallel Group ID:** A dropdown menu showing '1'.
- Parallel ID:** A dropdown menu showing '1'.
- Common Battery:** A dropdown menu showing 'Enable'.

Item	Description
<b>Parallel Group ID</b>	The UPSs in parallel connection must be assigned the same parallel group ID No. in order to let the outputs of the parallel UPSs be put in parallel connection and let the loads be evenly distributed among the parallel units. If the parallel UPSs have different parallel group ID No., their output signals might be synchronized but their outputs cannot be connected in parallel.
<b>Parallel ID</b>	The UPSs that need to be paralleled must be assigned the same parallel group ID No. and different parallel ID No. in order to let the parallel function work.
<b>Common Battery</b>	If the parallel UPSs that have the same parallel group ID No. need to share common batteries, please select ' <b>Enable</b> ' for the ' <b>Common Battery</b> ' setup item. Otherwise, the function of battery abnormality detection will fail.

## 7.10.6 Dry Contact Setting

Path:  → **Dry Contact Setting**

On the **DRY CONTACT SETTING** screen (shown in the figure below), the event, NO (normally open) or NC (normally closed) for each of the input and output dry contacts can be set up. These settings must be carried out by qualified service personnel. Please contact Delta customer service for assistance.



Input Dry Contact No.	Event Selection	Type
<b>Input Dry Contact 1</b> <b>Input Dry Contact 2</b> <b>Input Dry Contact 3</b> <b>Input Dry Contact 4</b>	Select one of the following events as the setting for each input dry contact. 1. None 2. Generator status 3. Battery ground fail 4. External battery breaker detection	Set up NO (normally open) or NC (normally closed) for each input dry contact.



Input Dry Contact No.	Event Selection	Type
<b>Input Dry Contact 1</b> <b>Input Dry Contact 2</b> <b>Input Dry Contact 3</b> <b>Input Dry Contact 4</b>	5. Charge Off (Positive) 6. Charge Off (Negative) 7. Battery Abnormal Shutdown 8. Input Transformer OTW 9. Output Transformer OTW 10. Battery Fuse Open 11. Charge Off	Set up NO (normally open) or NC (normally closed) for each input dry contact.


Output Dry Contact No.	Event Selection	Type
<b>Output Dry Contact 1</b> <b>Output Dry Contact 2</b> <b>Output Dry Contact 3</b> <b>Output Dry Contact 4</b> <b>Output Dry Contact 5</b> <b>Output Dry Contact 6</b>	Select one of the following events as the setting for each output dry contact.  1. None 2. Load on inverter 3. Load on bypass 4. Load on battery 5. Battery low 6. Battery input abnormal 7. Battery test fail 8. Internal comm. fail 9. External parallel comm. fail (only applicable to parallel application)	Set up NO (normally open) or NC (normally closed) for each output dry contact.

Output Dry Contact No.	Event Selection	Type
<b>Output Dry Contact 1</b> <b>Output Dry Contact 2</b> <b>Output Dry Contact 3</b> <b>Output Dry Contact 4</b> <b>Output Dry Contact 5</b> <b>Output Dry Contact 6</b>	10. Output overload 11. EPO activated 12. Load on manual bypass 13. Battery over temperature 14. Output voltage abnormal 15. Battery need replacement 16. Bypass over temperature 17. Bypass static switch fault 18. UPS over temperature 19. Battery breaker shunt trip 20. Backfeed protection 21. UPS general alarm	Set up NO (normally open) or NC (normally closed) for each output dry contact.

## 7.10.7 General Setting

Path:  → General Setting

On the **GENERAL SETTING** screen (shown in the figure below), the following items can be set up.







The screenshot shows the 'GENERAL SETTING' screen. At the top, there is a navigation bar with icons for 'UPS-1.1', 'MEASUREMENT', 'SETUP' (highlighted as 'General Setting'), 'MAINTENANCE', 'LOG IN' (Administrator), 'EVENT LOG', and a 'Bypass' button. Below the navigation bar, the 'GENERAL SETTING' title is displayed. Underneath, there are four circular sub-menus: 'DATE/TIME', 'SCREEN', 'USER', and 'DUST FILTER'. The 'DATE/TIME' sub-menu is selected, showing three settings: 'Date Format' (set to 'MMM-DD-YYYY'), 'Date' (set to 'May-10-2018'), and 'Time' (set to '09:30:26'). Each setting has a dropdown arrow next to it.


UPS-1.1	MEASUREMENT	SETUP General Setting	MAINTENANCE	LOG IN Administrator	EVENT LOG	09:30 May 10, 2023
<div> <div>GENERAL SETTING</div> <div>DATE/TIME</div> <div>SCREEN</div> <div>USER</div> <div>DUST FILTER</div> </div>						Bypass
<div> <div>Screen Brightness</div> <div>80 ▼</div> </div> <div> <div>Screen Sleep (after)</div> <div>1 min ▼</div> </div>						

UPS-1.1	MEASUREMENT	SETUP General Setting	MAINTENANCE	LOG IN Administrator	EVENT LOG	09:30 May 10, 2023
<div> <div>GENERAL SETTING</div> <div>DATE/TIME</div> <div>SCREEN</div> <div>USER</div> <div>DUST FILTER</div> </div>						Bypass
<div> <div>Language</div> <div>English ▼</div> </div> <div> <div>Admin Password</div> <div>****</div> </div> <div> <div>On/Off Button Access</div> <div>Any User ▼</div> </div>						
<div> <div>MODBUS ID</div> <div>1</div> </div> <div> <div>Baud Rate</div> <div>19200 ▼</div> </div> <div> <div>Parity</div> <div>None ▼</div> </div>						


UPS-1.1	MEASUREMENT	SETUP General Setting	MAINTENANCE	LOG IN Administrator	EVENT LOG	09:30 May 10, 2023
<div> <div>GENERAL SETTING</div> <div>DATE/TIME</div> <div>SCREEN</div> <div>USER</div> <div>DUST FILTER</div> </div>						Bypass
<div> <div>Dust Filter Installation</div> <div>Enable ▼</div> </div> <div> <div>Dust Filter Installation Date</div> <div>May-23-2018 ▼</div> </div> <div> <div>Dust Filter Replacement Date</div> <div>May-23-2020 ▼</div> </div>						

Item	Sub Item	Description
<b>DATE/ TIME</b>	Date Format	Select the date format.
	Date	Set up the date.
	Time	Set up the time.
<b>SCREEN</b>	Screen Brightness	Adjust the LCD display brightness (default: 80).
	Screen Sleep (after)	Set up the LCD backlight sleep time (default: 1 minute).
<b>USER</b>	Language	Set up the display language (default: English).
	Admin Password	Set up the administrator password (4 digits).
	On/ Off Button Access	Set up the access for the <b>ON/ OFF Button</b> (  ) as 'Any User' or 'Administrator Only'.
	MODBUS ID	Set up the MODBUS ID for the MODBUS port located at the rear of the touch panel.
	Baud Rate	Set up the baud rate for the MODBUS port located at the rear of the touch panel.
	Parity	Setup the parity checking scheme for the MODBUS port located at the rear of touch panel.
<b>DUST FILTER</b>	Dust Filter Installation	If you have installed any dust filter, please select ' <b>Enable</b> '; if not, please select ' <b>Disable</b> '.
	Dust Filter Installation Date	Set up the dust filter installation date.  <b>NOTE:</b> Only when you select ' <b>Enable</b> ' for ' <b>Dust Filter Installation</b> ' can you set up the ' <b>Dust Filter Installation Date</b> '.
	Dust Filter Replacement Date	Set up the dust filter replacement date. When the date is due, the red warning icon (  ) will automatically appear in the upper right corner of the LCD, and the alarm message ' <b>Replace Dust Filter</b> ' will be displayed.  <b>NOTE:</b> Only when you select ' <b>Enable</b> ' for ' <b>Dust Filter Installation</b> ' can you set up the ' <b>Dust Filter Installation Date</b> '.

## 7.10.8 IP Setting

Path:  → IP Setting

On the **IP SETTING** screen (shown in the figure below), the following items can be set up. These settings must be carried out by qualified service personnel. Please contact Delta customer service for assistance.



IP SETTING			
DHCP Client	IP Address	Subnet Mask	Gateway IP
Enable ▼	10.144.7.26	255.255.255.0	10.144.7.254
DNS 1 IP	DNS 2 IP	Search Domain	Host Name
10.136.156.1	10.145.156.40	delta.corp	DELTA


00-18-23-61-17-CC





Item	Description
<b>DHCP Client</b>	Enable or disable the DHCP client.
<b>IP Address</b>	Set up the IP address.
<b>Subnet Mask</b>	Set up the subnet mask.
<b>Gateway IP</b>	Set up the gateway IP address.
<b>DNS 1 IP</b>	Set up the DNS server 1 IP address.
<b>DNS 2 IP</b>	Set up the DNS server 2 IP address.
<b>Search Domain</b>	Set up the search domain.
<b>Host Name</b>	Set up the host name.

## 7.10.9 Control

Path:  → **Control**

On the **CONTROL** screen (shown in the figure below), the following items can be set up. These settings must be carried out by qualified service personnel. Please contact Delta customer service for assistance.



Item	Description
<b>Buzzer</b>	Enable or disable the buzzer.
<b>Reset Module</b>	Reset the power modules or not. In bypass mode, when you press the ON/ OFF button (  ) to start up the UPS but the UPS does not respond, please select 'Reset' to reset the power modules. After the power modules are reset, please press the ON/ OFF button (  ) to start up the UPS.
<b>Reset System</b>	Reset the system or not. In bypass mode, when you press the ON/ OFF button (  ) to start up the UPS but the UPS does not respond, please select 'Reset' to reset the system. After the system is reset, please press the ON/ OFF button (  ) to start up the UPS.
<b>Force Equalized Charge</b>	Manually force the UPS to run in auto equalized charge mode to charge the batteries.
<b>Force Bypass to Inverter</b>	Manually force the UPS to switch from bypass to inverter when the inverter keeps staying in the soft-start status and is unable to transfer to on-line mode successfully.


### 7.10.10 EMS Setting

Path:  → **EMS Setting**

On the **EMS SETTING** screen\*<sup>1</sup> (shown in the figure below), the following items can be set up. These settings must be carried out by qualified service personnel. Please contact Delta customer service for assistance.




**NOTE:** \*<sup>1</sup> means that the **Administrator** password is needed. For password information, please refer to **7.5 Password Entry**.



The screenshot shows the 'EMS SETTING' screen with a blue background. At the top, there is a navigation bar with icons for UPS-1.1, MEASUREMENT, SETUP EMS Setting (highlighted), MAINTENANCE, LOG IN Administrator, EVENT LOG, and a mute icon. The top right corner displays the time '09:30', date 'May 10, 2023', and status 'On-Line'. Below the navigation bar, there are two circular buttons labeled 'SENSOR' and 'INPUT CONTACT'. The main area is divided into two sections: 'Temperature' and 'Humidity'. Each section has four rows of settings: Alarm, Recovery, Warning, and another Recovery. Each row has a comparison operator (> or <), a numerical value, and a unit (°C or %). The 'Status' dropdown is set to 'Disable'.

ID	Title	Status
ID 0	EMS0	Disable

Temperature			Humidity		
Alarm	>	40.0 °C	Alarm	>	90 %
Recovery	<	38.0 °C	Recovery	<	85 %
Warning	>	30.0 °C	Warning	>	80 %
Recovery	<	28.0 °C	Recovery	<	75 %



The screenshot shows the 'EMS SETTING' screen with a blue background. At the top, there is a navigation bar with icons for UPS-1.1, MEASUREMENT, SETUP EMS Setting (highlighted), MAINTENANCE, LOG IN Administrator, EVENT LOG, and a mute icon. The top right corner displays the time '09:30', date 'May 10, 2023', and status 'On-Line'. Below the navigation bar, there are two circular buttons labeled 'SENSOR' and 'INPUT CONTACT'. The main area is divided into two sections: 'Temperature' and 'Humidity'. Each section has four rows of settings: Alarm, Recovery, Warning, and another Recovery. Each row has a comparison operator (> or <), a numerical value, and a unit (°C or %). The 'Status' dropdown is set to 'Disable'.


ID	Title	Status
ID 0	EMS0	Disable

Input Contact	NO/NC	Title	Event Type
1	Normally Open	Security	Warning
2	Normally Open	Leakage	Warning
3	Normally Open	Fire	Warning
4	Normally Open	Smoke	Warning



**NOTE:**

After connecting the optional EMS 1000 (EnviroProbe) to the UPS, you have to manually set both **ID** and **Status** to enable the EMS function of the UPS. Settings for the other items can be adjusted according to your needs; the default values are shown in the figures above.


Item	Sub Item	Description
SENSOR	ID	Set the ID # (ID 0/ ID 1/ .../ ID 15) according to the ID DIP switch set on the EMS 1000 (EnviroProbe) device. For the ID DIP switch settings, please refer to <b>7.9.7.1 Connecting the optional EMS 1000 (EnviroProbe)</b> .  <b>NOTE:</b> If the ID # setting is wrong, the warning message 'The EMS 1000 ID # Communication Fail' will appear.
	Title	Set the title for the EMS 1000 (EnviroProbe), 16 characters at most.
	Status	The status <b>Enable/ Disable</b> determines whether or not the LCD shows the EMS information of the EMS 1000 (EnviroProbe) device (ID #).
	Temperature	Set the temperature (°C) values for Alarm/ Warning/ Recovery.
	Humidity	Set the Humidity (%) values for Alarm/ Warning/ Recovery.
INPUT CONTACT	Input Contact 1	<ol style="list-style-type: none"> <li>1. Set the input contact as Normally Open (NO)/ Normally Closed (NC).</li> <li>2. Set the title for the input contact, 16 characters at most.</li> <li>3. Set the Event Type as None/ Information/ Warning/ Alarm.</li> </ol>
	Input Contact 2	
	Input Contact 3	
	Input Contact 4	

Not only does the **EMS** screen show status of the input contacts (please refer to **7.9.7 EMS**), but the **Warning** screen, **Historical Event** screen, UPS tri-color LED indicator and buzzer also response to the status of the input contacts.



**NOTE:** For the location of the UPS tri-color LED indicator and buzzer, please refer to **2.8 Tri-color LED Indicator & Buzzer**.

Event Type of Input Contact	EMS DI1~DI4 (LCD)	Tri-color LED Indicator	Buzzer	Warning (LCD)	Historical Event (LCD)
None	Green	Green	No Sound	No	No
Information	Green	Green	No Sound	No	Yes
Warning	Yellow	Yellow	Short Beep	Yes	Yes
Alarm	Red	Red	Long Beep	Yes	Yes


All the above settings are related to the items shown on the **EMS** screen in the  **EMS**. Please refer to **7.9.7 EMS**.



### 7.10.11 Network Service

Path:  → **Network Service**

On the **Network Service** screen (shown in the figure below), the following items can be set up. These settings must be carried out by qualified service personnel. Please contact Delta customer service for assistance.




Item	Description
HTTP	Enable or disable the HTTP service.
HTTPS	Enable or disable the HTTPS service.

### 7.10.12 Remote User Setting

Path:  → **Remote User Setting**

On the **Remote User Setting** screen (shown in the figure below), the following items can be set up. These settings must be carried out by qualified service personnel. Please contact Delta customer service for assistance.





Privilege	Account Name	Password	Login Limitation
Administrator	admin		Allow Any
Device Manager	device		Allow Any
User	user		Allow Any






Item	Sub Item	Description
Remote User Setting	Administrator	Set up the administrator's account name, password and login limitation.
	Device Manager	Set up the device manager's account name, password and login limitation.
	User	Set up the user's account name, password and login limitation.

## 7.11 System Maintenance








### 7.11.1 Alarm Warning

**Path 1:**  MAINTENANCE → **Warning**

**Path 2:** When there is a warning, the buzzer icon (  ) will light up in red, and the buzzer will make an alarm sound. Click the warning icon (  ) to enter the **WARNING** screen.


On the **WARNING** screen (shown in the figure below), users can use the (     ) buttons to inquire about warning logs or use the function key (  ) to enter a specific page No. to check the warning logs. The system can store at maximum 200 warning logs.






The **WARNING** screen also displays relevant solutions. For warning solutions, please refer to **10. Troubleshooting**.

 UPS-1.1	 MEASUREMENT	 SETUP	 MAINTENANCE Warning	 LOG IN Administrator	 WARNING		09:30 May 10, 2023 On-Line
WARNING							
No.	Log	Solution					
3	Touch Panel Comm Loss	Please contact service personnel for more information.					
2	PFC#1 Fan Fault	Please contact service personnel for more information.					
1	PM#1 Repair Switch Open	Please contact service personnel for more information.					

## 7.11.2 Historical Event


Path:  → **Historical Event**

The **HISTORICAL EVENT** screen shown below provides each historical event's No., start date and time, code (red: serious; orange: minor; green: normal), location, and log description. You can click the icon () to magnify the entire historical event description.


You can use the buttons (, , , ) to check the historical event logs or use the function key () to enter a specific page No. to view the historical event logs.

The system can save up to 10000 historical event logs. The greater the event number is, the newer the event is. When the total number of historical event logs exceeds the storage capacity (up to 10000 entries), the oldest 500 historical event logs will be overwritten.


You can click the download button () to download the historical event logs. To clear the historical event logs, please refer to **7.11.5 Clear**.




UPS-1.1




MEASUREMENT




SETUP




MAINTENANCE  
Historical Event



LOG IN  
Administrator



WARNING 9






















09:30  
May 10, 2023

On-Line



HISTORICAL EVENT


DOWNLOAD

No. ▲	Start Date	Code	Location	Log	
187	2017-10-15 10:27:07	 3200-02	STS	Emergency PWR Off	
186	2017-10-15 10:26:52	 2519-01	STS	CSU Aux Pwr #2 On Repair	
185	2017-10-15 10:26:36	 2518-01	STS	CSU Aux Pwr #1 On Repair	
184	2017-10-15 09:06:59	 0128-01	STS	Mains Input Freq Out Range	
183	2017-10-15 10:27:07	 5005-01	STS	No Output	
182	2017-10-15 10:26:52	 480A-01	STS	COM Card #2 Absent	
181	2017-10-15 10:26:36	 0100-01	STS	Mains Input Volt Out Range	
180	2017-10-15 09:16:45	 3200-01	STS	About Emergency PWR Off	




1







UPS-1.1



MEASUREMENT




SETUP




MAINTENANCE

Historical Event




LOG IN

Administrator



WARNING

9























09:30  
May 10, 2023

On-Line

HISTORICAL EVENT

DOWNLOAD

No. ▲	Start Date	Code	Location	Log	
179	2017-10-15 09:06:59	 480A-01	STS	Battery Disconnected	
178	2017-10-15 08:22:45	 1021-01	STS	Mains Input Freq Out Range	
177	2017-10-15 08:10:06	 2501-01	STS	Mains Input Volt Out Range	
176	2017-10-15 07:58:15	 501F-01	STS	UPS Soft Start	
175	2017-10-15 07:48:22	 5005-01	STS	No Output	
174	2017-10-15 07:35:10	 480A-01	STS	COM Card #2 Absent	
173	2017-10-15 07:25:25	 0100-01	STS	Mains Input Volt Out Range	
172	2017-10-15 07:15:02	 3200-01	STS	About Emergency PWR Off	




2

### 7.11.3 Statistics

Path:  MAINTENANCE → Statistics

On the **STATISTICS** screen (shown in the figure below), users can inquire about the following statistics.




Item	Description
In Battery Mode	Means how many times that the UPS runs in battery mode.
Battery Mode Duration	Means how long the UPS runs in battery mode.
In Bypass Mode	Means how many times that the UPS runs in bypass mode.
Bypass Mode Duration	Means how long the UPS runs in bypass mode.
Operation Time	Means how long the UPS has operated.

To clear the statistics, please refer to **7.11.5 Clear**.

### 7.11.4 Test

Path:  MAINTENANCE → Test

You have to log in as an **Administrator** to enter the **TEST** screen to perform a manual battery test.




### 7.11.5 Clear

**Path:**  → **Clear**

You have to log in as an **Administrator** to enter the **CLEAR** screen<sup>\*1</sup> to clear the records of (1) statistics, (2) historical event, (3) battery test result and (4) kilowatt hour (kWh).



**NOTE:** <sup>\*1</sup> means that the **Administrator** password is needed. For password information, please refer to **7.5 Password Entry**.



Item	Description
<b>Clear Statistics</b>	After you select ' <b>Clear</b> ' and confirm clearance of statistics, all records of the statistics will be cleared.

Item	Description
<b>Clear Historical Event</b>	After you select ' <b>Clear</b> ' and confirm clearance of historical event logs, all historical event logs will be cleared.
<b>Clear Battery Test Result</b>	After you select ' <b>Clear</b> ' and confirm clearance of battery test result, the battery test result will be cleared.
<b>Clear Kilowatt Hour (kWh)</b>	After you select ' <b>Clear</b> ' and confirm clearance of kilowatt hour records, the kilowatt hour statistics will be cleared.



#### NOTE:








The records of (1) statistics, (2) historical event, (3) battery test result, and (4) kilowatt hour (kWh) provide important information for system analysis and maintenance. Do not clear any of them without the consent of qualified service personnel.


## 7.11.6 Advanced Diagnosis

Path:  MAINTENANCE → **Advanced Diagnosis**


You have to log in as an **Administrator** to enter the **ADVANCED DIAGNOSIS** screen to check:

1. STS temperature, battery temperature, and fan speed of the system.
2. INV temperature and PFC temperature of a specific battery module.


 UPS-1.1	 MEASUREMENT	 SETUP	 MAINTENANCE Advanced Diagnosis	 LOG IN Administrator	 EVENT LOG	 Bypass	09:30 May 10, 2023
ADVANCED DIAGNOSIS				SYSTEM POWER MODULE			
STS Temp. (°C)				25	25	25	
Battery Temp. (°C)				25	25	25	25
Fan Speed (rpm)				2300	2300	-	



### 7.11.7 Version & S/N

**Path:**  → **Version & S/N**

On the **VERSION & S/N** screen (shown in the figure below), users can check and update the software version and serial number. For detailed information please refer to the table below.



UPS-1.1

MEASUREMENT

SETUP

MAINTENANCE  
Version & S/N

LOG IN  
Administrator

EVENT LOG

09:30  
May 10, 2023

Bypass

VERSION & S/N

S/NMAININV

	MCU	FPGA
Parallel Communication Card #1	0H0025ANFP.13.00	4A0003ADFP.13.01
Parallel Communication Card #2	0H0025ANFP.13.00	4A0003ADFP.13.01
System Control Card	0H0025ANFP.13.00	4A0003ADFP.13.01
Touch Panel	S.187	

Choose File

UPGRADE

UPS-1.1

MEASUREMENT

SETUP

MAINTENANCE  
Version & S/N

LOG IN  
Administrator

EVENT LOG

09:30  
May 10, 2023

Bypass

VERSION & S/N

S/NMAININV

	MCU	FPGA		MCU	FPGA
PM 01	0H0028AD00.00.03	4A005AD00.00.01	PM 02	0H0028AD00.00.03	4A005AD00.00.01
PM 03	0H0028AD00.00.03	4A005AD00.00.01	PM 04	0H0028AD00.00.03	4A005AD00.00.01

Choose File

UPGRADE

UPS-1.1

MEASUREMENT

SETUP

MAINTENANCE  
Version & S/N

LOG IN  
Administrator

EVENT LOG

09:30  
May 10, 2023

Bypass

VERSION & S/N

S/NMAININV

	MCU	FPGA		MCU	FPGA
PM 01	0H0013AD00.00.0A	0H0034AD00.10.0B	PM 02	0H0013AD00.00.0A	0H0034AD00.10.0B
PM 03	0H0045AD00.00.0A	0H0034AD00.10.0B	PM 04	0H0013AD00.00.0A	0H0034AD00.10.0B


Choose File

UPGRADE



Item	Sub Item	Description
<b>S/N</b>	System	Check the system's serial No.
	Touch Panel	Check the touch panel's serial No.
	Power Module#	Check a specific power module's serial No.
<b>MAIN</b>	COM#_ MCU/ FPGA	Check and update a specific COM's MCU or FPGA firmware version.
	System _ MCU/ FPGA	Check and update the system's MCU or FPGA firmware version.
	Touch Panel _ MCU/ FPGA	Check and update the touch panel's MCU or FPGA firmware version.
<b>INV</b>	PM #_ MCU/ FPGA	Check and update the MCU or FPGA firmware version of a specific power module's inverter.
<b>PFC</b>	PM #_ MCU/ FPGA	Check and update the MCU or FPGA firmware version of a specific power module's PFC.






## Optional Accessories

No.	Item	Function
1	Relay I/O Card	Increases the quantity of dry contacts.
2	Parallel communication card	Provides two redundant parallel ports and one LED indicator for parallel communication. Please refer to <b>4.1.7 Parallel Communication Card</b> for more information.
3	EnviroProbe 1000/ EnviroProbe 1100/ EnviroProbe 1200	Monitors temperature, humidity and other connected monitoring devices in a room environment. The EnviroProbe 1000/ 1100/ 1200 should work with either an SNMP card or an EMS2000.
4	Battery Cabinet Temperature Sensor Cable	Detects the temperature of the external battery cabinet(s) connected to the UPS.
5	Parallel Cable (5-meter long)	Connects the parallel UPSs.
6	Parallel Cable (10-meter long)	Connects the parallel UPSs.
7	Battery Management System	Monitors (1) each battery's voltage, (2) each battery pack's voltage and charge/ discharging current, and (3) battery environment temperature.
8	EMS 1000 (EnviroProbe)	Monitors temperature, humidity and other connected monitoring devices in a room environment. Connect the EMS 1000 (EnviroProbe) to the UPS's EMS port located at the rear of the touch panel, and the UPS will integrate the detected information of the EMS 1000 (EnviroProbe) and display relevant data on the LCD. See <b>Figure 4-18</b> for the location of the EMS port. For more information about the application of the EMS 1000 (EnviroProbe), please refer to <b>7.9.7 EMS</b> and <b>7.10.10 EMS Setting</b> .



#### NOTE:

1. For detailed installation and operation of any accessory mentioned above, please refer to the **Quick Guide**, **User Guide**, or **Installation & Operation Guide** included in the package of the relevant optional accessory.
2. If you want to buy any accessory mentioned above, please contact your local dealer or customer service.



# Maintenance

- **UPS**

1. UPS Cleaning:

Regularly clean the UPS, especially the slits and openings and filters, to ensure that the air freely flows into the UPS to avoid overheating. If necessary, use an air-gun to clean the slits and openings and replace the filters regularly to prevent any object from blocking or covering these areas.

2. UPS Regular Inspection:

- a. Monthly check the filters and yearly replace them.
- b. Regularly check the UPS every half year and inspect:
  - 1) Whether the UPS, LED indicators, and alarm function are operating normally.
  - 2) Whether the UPS works in bypass mode (normally, the UPS will work in normal mode). If yes, check if any error, overload, internal fault, etc. occurs.
  - 3) Whether battery voltage is normal. If the battery voltage is too high or too low, find the root cause.

- **Batteries**

The HPH series UPS uses sealed lead-acid batteries. The battery life depends on the temperature, the usage, and the charging/ discharging frequency. High temperature environments and high charging/ discharging frequency will quickly shorten the battery life. Please follow the suggestions below to ensure a normal battery lifetime.

1. Keep usage temperature between 15°C~25°C.
2. When the UPS needs to be stored for an extended period of time, the batteries must be recharged once every three months and the charging time must not be less than 24 hours each time.


- **Fans**

Higher temperatures shorten fan life. When the UPS is running, please check if all of the fans work normally and make sure if the ventilation air can move freely around and through the UPS. If not, replace the fans.



**NOTE:**

Please ask your local dealer or customer service for more maintenance information. Do not perform maintenance if you are not trained for it.



# Troubleshooting

When you see the following alarm messages appear on the LCD, please follow the solutions shown below. If you see other alarm messages that are not listed in the table below, please contact Delta service personnel for assistance. Do not perform troubleshooting if you are not trained for it.

No.	Alarm Message	Possible Cause	Solution
1	Mains Input Volt/ Freq Out Range	<ol style="list-style-type: none"> <li>1. The input switch is turned off.</li> <li>2. The main AC source's voltage or frequency is abnormal.</li> </ol>	<ol style="list-style-type: none"> <li>1. Please check if the input switch is turned off or not. If yes, please turn it on.</li> <li>2. Please check if the main AC source's voltage or frequency is abnormal or not. If yes, please wait for the main AC source to be restored.</li> <li>3. If the alarm message still exists after the solutions mentioned above have been executed, please contact service personnel.</li> </ol>
2	Mains Input Volt Phase Seq Abnormal	The wiring is incorrect.	Please check the wiring and phase sequence of the main AC source, and contact service personnel for assistance.
3	Mains Input Breaker Off	The input switch is turned off.	<ol style="list-style-type: none"> <li>1. Please check if the input switch is turned off or not. If yes, please turn it on.</li> <li>2. If the alarm message still exists after the solution mentioned above has been executed, please contact service personnel.</li> </ol>
4	Bypass Input Volt Out Range	<ol style="list-style-type: none"> <li>1. The bypass switch is turned off.</li> <li>2. The bypass AC source's voltage is abnormal.</li> </ol>	<ol style="list-style-type: none"> <li>1. Please check if the bypass switch is turned off or not. If yes, please turn it on.</li> <li>2. Please check if the bypass AC source's voltage is abnormal or not. If yes, please wait for the bypass AC source to be restored.</li> <li>3. If the alarm message still exists after the solutions mentioned above have been executed, please contact service personnel.</li> </ol>
5	Bypass Input Freq Out Range	<ol style="list-style-type: none"> <li>1. The bypass switch is turned off.</li> <li>2. The bypass AC source's frequency is abnormal.</li> </ol>	<ol style="list-style-type: none"> <li>1. Please check if the bypass switch is turned off or not. If yes, please turn it on.</li> <li>2. Please check if the bypass AC source's frequency is abnormal or not. If yes, please wait for the bypass AC source to be restored.</li> <li>3. If the alarm message still exists after the solutions mentioned above have been executed, please contact service personnel.</li> </ol>



No.	Alarm Message	Possible Cause	Solution
6	Bypass Input Volt Phase Seq Abnormal	The wiring is incorrect.	Please check the wiring and phase sequence of the bypass AC source, and contact service personnel for assistance.
7	Bypass Volt Out ECO Range	The bypass AC source's voltage or frequency exceeds the range for ECO mode.	Please check the bypass AC source's voltage or frequency. If it is abnormal, please wait for the bypass AC source to be restored.
8	Bypass Breaker Off	For single input application, the input switch is turned off.	1. Please check if the input switch is turned off or not. If yes, please turn it on. 2. If the alarm message still exists after the solution mentioned above has been executed, please contact service personnel.
		For dual input application, the bypass switch is turned off.	1. Please check if the bypass switch is turned off or not. If yes, please turn it on. 2. If the alarm message still exists after the solution mentioned above has been executed, please contact service personnel.
9	Bypass STS Over Heat Warning	Heat dissipation is poor or components are damaged.	1. Check if any foreign matter blocks the fans or air inlet. If yes, remove the foreign matter. 2. Decrease some loads. 3. If the alarm message still exists after the solutions mentioned above have been executed, please contact service personnel.
10	Bypass STS Fault	The bypass static switch or its driving circuit is abnormal.	Please contact service personnel for assistance.
11	Battery End of Discharge Imminent	The battery voltage is lower than the alarm value.	If there is no bypass power feeding to the system, please shut down the connected loads in accordance with normal procedures as soon as possible.
12	Battery End Of Discharge	The battery voltage is lower than the End-of-Discharge setup value.	If there is no bypass power feeding to the system, please shut down the connected loads in accordance with normal procedures as soon as possible.
13	Battery Over Charged	The charger is abnormal.	Please contact service personnel for assistance.

No.	Alarm Message	Possible Cause	Solution
14	Battery Disconnected	<ol style="list-style-type: none"> <li>1. The batteries are not connected.</li> <li>2. The battery breaker is turned off.</li> </ol>	<ol style="list-style-type: none"> <li>1. Please check if the batteries are properly connected.</li> <li>2. Please check if the battery breaker is turned off or not. If yes, please turn it on.</li> <li>3. If the alarm message still exists after the solutions mentioned above have been executed, please contact service personnel.</li> </ol>
15	Battery Life Expired"	<ol style="list-style-type: none"> <li>1. The battery replacement date is due.</li> <li>2. The system date is wrongly set.</li> </ol>	<ol style="list-style-type: none"> <li>1. Please check if the battery replacement date is due or not. If yes, please contact service personnel for assistance.</li> <li>2. Please check the setting of the system date. If there is any error, please correct it.</li> </ol>
16	Battery Reversed	The battery wiring is wrong.	Check the battery wiring. If there is any error or abnormality, please contact service personnel for assistance.
17	Battery Test Fail	The battery wiring is wrong or battery abnormalities exist.	Check the batteries. If wrong battery wiring or battery abnormalities exist, please contact service personnel for assistance.
18	Battery Ground Fault	The battery grounding is wrong or the input dry contact configuration is wrong.	<ol style="list-style-type: none"> <li>1. Check if the battery wiring is normal or not.</li> <li>2. Check if the input dry contact configuration is normal or not.</li> <li>3. If the alarm message still exists after the solutions mentioned above have been executed, please contact service personnel.</li> </ol>
19	Battery Breaker OFF	The battery breaker is turned off.	<ol style="list-style-type: none"> <li>1. Please check if the external battery breaker is turned off or not. If yes, please turn it on.</li> <li>2. If the alarm message still exists after the solution mentioned above has been executed, please contact service personnel.</li> </ol>
20	Battery Over Temperature	The battery temperature is too high or the batteries are abnormal.	<ol style="list-style-type: none"> <li>1. Improve ventilation to reduce the battery temperature.</li> <li>2. Check if the batteries are abnormal or not. If yes, please contact service personnel for assistance.</li> </ol>
21	Battery Under Temperature	The battery temperature is too low or the batteries are abnormal.	<ol style="list-style-type: none"> <li>1. Check the battery constant temperature equipment.</li> <li>2. Check if the batteries are abnormal or not. If yes, please contact service personnel for assistance.</li> </ol>

No.	Alarm Message	Possible Cause	Solution
22	Output Overload Warning	The connected loads exceed the rated value.	Please decrease the loads.
23	Output Overload Shutdown	The connected loads exceed the rated value for a long time.	<ol style="list-style-type: none"> <li>1. After overload shutdown, the connected loads will be supplied by the bypass. Please decrease the loads to let the system re-start automatically.</li> <li>2. If the alarm message still exists after the solution mentioned above has been executed, please contact service personnel.</li> </ol>
24	INV Volt Abnormal	The inverter's output voltage is too high or too low.	Please contact service personnel for assistance.
25	INV Over Current Warning	The inverter's output current is too high.	Please contact service personnel for assistance.
26	INV Over Current Shutdown	The inverter's output current is too high.	Please contact service personnel for assistance.
27	INV Output Current Unbalance	The connected loads are abnormal or the power modules are damaged.	Please contact service personnel for assistance.
28	Output Breaker Off	The output breaker or switch is off.	<ol style="list-style-type: none"> <li>1. Please check if the output switch is turned off or not. If yes, please turn it on.</li> <li>2. If the alarm message still exists after the solution mentioned above has been executed, please contact service personnel.</li> </ol>
29	PM Redundancy Loss	The connected loads exceed the redundancy setting.	<ol style="list-style-type: none"> <li>1. Please reduce the loads.</li> <li>2. Please reset the power module redundancy setting. Please refer to <b>7.10.3 Output Setting</b>.</li> </ol>
30	System Fan Fault	The system's fan components are damaged.	Please contact service personnel for assistance.
31	STS Module Fan Abnormal	The STS module's fan components are damaged.	Please contact service personnel for assistance.

No.	Alarm Message	Possible Cause	Solution
32	PM #n Fan Abnormal	The #n power module's fan components are damaged.	Please contact service personnel for assistance.
33	Replace Dust Filter	The filter replacement date is due.	Please contact service personnel for assistance.
34	Parallel Unit Config Incompatible - AC In Type	There are conflicts between the parallel UPS units' AC input settings.	Check if the AC input settings among the parallel UPS units are correct or not, and contact service personnel for assistance.
35	Parallel Unit Config Incompatible - Output Type	There are conflicts between the parallel UPS units' output settings.	Check if the output settings among the parallel UPS units are correct or not, and contact service personnel for assistance.
36	Parallel Unit Config Incompatible - Bat Type	<ol style="list-style-type: none"> <li>1. There are conflicts between the parallel UPS units' battery settings.</li> <li>2. The input dry contact setting for the generator is abnormal.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check if the battery settings among the parallel UPS units are correct or not, and contact service personnel for assistance.</li> <li>2. Check the input dry contact setting.</li> </ol>
37	EXT Parallel Comm Loss	The parallel cable is loose or the circuit board has abnormalities.	Check if the parallel cable is firmly connected or not, and contact service personnel for assistance.
38	Local Comm Loss	The system's internal communication cable is loose or the circuit board has abnormalities.	Please contact service personnel for assistance.
39	EXTCAN Bus Abnormal - Physical	The parallel cable is loose or the circuit board has abnormalities.	Check if the parallel cable is firmly connected or not, and contact service personnel for assistance.
40	INTCAN Bus Abnormal - Physical	The system's internal communication cable is loose or the circuit board has abnormalities.	Please contact service personnel for assistance.
41	MONCAN Abnormal - Physical	The system's internal communication cable is loose or the circuit board has abnormalities.	Please contact service personnel for assistance.

No.	Alarm Message	Possible Cause	Solution
42	PFC #n MONCAN Comm Loss	The circuit board has abnormalities.	Please contact service personnel for assistance.
43	Parallel IO Abnormal	The system's internal communication cable is loose or the circuit board has abnormalities.	Please contact service personnel for assistance.
44	INV #n PLL Bus Abnormal	The main AC source's voltage is changed or the circuit board has abnormalities.	Please confirm if the main AC source's voltage is abnormal or not. If yes, please wait for the main AC source to be restored to normal. If no, please contact service personnel for assistance.
45	System Aux Pwr Fault	The #n auxiliary power card has abnormalities.	Please contact service personnel for assistance.
46	CSU Aux Pwr #n On Repair	The #n auxiliary power card is not inserted.	Please contact service personnel for assistance.
47	COM Card #n Absent	The #n parallel communication card is abnormal.	Please contact service personnel for assistance.
48	PM#n Abnormal Absent	The #n power module is abnormally removed or the power outage occurs.	Please contact service personnel for assistance.
49	STS Card FPGA Config Abnormal	The system control card is abnormal.	Please contact service personnel for assistance.
50	Soft Start Fail	The #n power module is abnormal.	Please contact service personnel for assistance.
51	PM #n PFC Input Current Unbalance	The #n power module is abnormal.	Please contact service personnel for assistance.
52	PFC #n Over Heat Warning	The fans are abnormal.	1. Check if any foreign matter blocks the fans or not. If yes, remove the foreign matter. 2. Contact service personnel for assistance.

No.	Alarm Message	Possible Cause	Solution
53	PFC #n Over Heat Shutdown	The fans are abnormal.	1. Check if any foreign matter blocks the fans or not. If yes, remove the foreign matter. 2. Contact service personnel for assistance.
54	PFC #n DC Bus Over Shutdown	The #n power module is abnormal.	Please contact service personnel for assistance.
55	PFC #n DC Bus Under Shutdown	The #n power module is abnormal.	Please contact service personnel for assistance.
56	INV #n Over Heat Warning	The fans are abnormal.	1. Check if any foreign matter blocks the fans or not. If yes, remove the foreign matter. 2. Contact service personnel for assistance.
57	INV #n Over Heat Shutdown	The fans are abnormal.	1. Check if any foreign matter blocks the fans or not. If yes, remove the foreign matter. 2. Contact service personnel for assistance.
58	INV #n DC Bus Over Shutdown	The #n power module is abnormal.	Please contact service personnel for assistance.
59	INV #n DC Bus Under Shutdown	The #n power module is abnormal.	Please contact service personnel for assistance.
60	PFC Fuse Open	The #n power module is abnormal.	Please contact service personnel for assistance.
61	Battery Fuse Open	The #n power module is abnormal.	Please contact service personnel for assistance.
62	Charger Fuse Open	The #n power module is abnormal.	Please contact service personnel for assistance.
63	INV #N Output Fuse Open	The #n power module is abnormal.	Please contact service personnel for assistance.
64	Output Relay Fault	The #n power module is abnormal.	Please contact service personnel for assistance.

No.	Alarm Message	Possible Cause	Solution
65	PM Repair Switch Open	The #n power module's switch is in the OFF status.	<ol style="list-style-type: none"> <li>1. Please turn on the #n power module's switch.</li> <li>2. If the alarm message still exists after the solution mentioned above has been executed, please contact service personnel.</li> </ol>
66	Over OTP Auto Recover Limit	The #n power module activates its own abnormal protection mechanism to re-start automatically more than 3 times.	Please contact service personnel for assistance.
67	Over DC Bus OVP Auto Recover Limit	The #n power module activates its own abnormal protection mechanism to re-start automatically more than 3 times.	Please contact service personnel for assistance.
68	Over OCP Auto Recover Limit	The #n power module activates its own abnormal protection mechanism to re-start automatically more than 3 times.	Please contact service personnel for assistance.
69	INV Volt Abnormal	<ol style="list-style-type: none"> <li>1. The output to the connected loads is abnormal.</li> <li>2. The #n power module's output voltage is too high or too low.</li> </ol>	Please contact service personnel for assistance.
70	PWM Carrier Fault	<ol style="list-style-type: none"> <li>1. The system's internal communication cable is loose.</li> <li>2. The circuit board has abnormalities.</li> </ol>	Please contact service personnel for assistance.
71	INV PLL Ref Bus Abnormal	<ol style="list-style-type: none"> <li>1. The system's internal communication cable is loose.</li> <li>2. The circuit board has abnormalities.</li> </ol>	Please contact service personnel for assistance.


No.	Alarm Message	Possible Cause	Solution
72	Emergency Pwr Of	The EPO button is pressed.	<ol style="list-style-type: none"> <li>1. Please confirm if the EPO button is pressed or not. If yes, restart the UPS in accordance with the normal start-up procedures after the relevant abnormalities are eliminated.</li> <li>2. If the alarm message still exists, please contact service personnel for assistance.</li> </ol>
73	Load on manual bypass	The manual bypass breaker or switch is turned on.	<ol style="list-style-type: none"> <li>1. Please confirm if the manual bypass breaker or switch is turned on or not. If yes, restart the UPS in accordance with the normal start-up procedures after the relevant abnormalities are eliminated.</li> <li>2. If the alarm message still exists, please contact service personnel for assistance.</li> </ol>
74	Charger Volt Abnormal	The charger is abnormal.	Please contact service personnel for assistance.
75	Charger Current Abnormal	The charger is abnormal.	Please contact service personnel for assistance.
76	Charger Over Heat warning	The fans are abnormal.	<ol style="list-style-type: none"> <li>1. Check if any foreign matter blocks the fans or not. If yes, remove the foreign matter.</li> <li>2. Contact service personnel for assistance.</li> </ol>
77	Charger Over Heat Shutdown	The fans are abnormal.	<ol style="list-style-type: none"> <li>1. Check if any foreign matter blocks the fans or not. If yes, remove the foreign matter.</li> <li>2. Contact service personnel for assistance.</li> </ol>



**NOTE:**

If the alarm still exists after the above possible causes are eliminated, please contact your dealer or customer service.





## Technical Specifications

Model		HPH	
UPS Capacity		160kVA*1/ 150kW	200kVA/ 200kW
Input	Nominal Voltage	220/380 Vac, 230/400 Vac, 240/415 Vac (3Φ4W + G)	
	Nominal Current	278A, 266A, 255A	371A, 355A, 340A
	Voltage Range	176 ~ 276 Vac (full load)	
	Current Harmonic Distortion	$\leq 3\%$ *2	
	Power Factor	$> 0.99$	
	Frequency Range	40 ~ 70 Hz	
Output	Voltage	220/380 Vac, 230/400 Vac, 240/415 Vac (3Φ4W + G)	
	Nominal Current	243A, 232A, 222A	303A, 290A, 278A
	Voltage Harmonic Distortion	$\leq 0.5\%$ (linear load)	
	Frequency	50/60 Hz	
	Overload Capability	$\leq 125\%: 10$ minutes ; $\leq 150\%: 1$ minute : $> 150\%: 1$ second	
	Short-circuit Current (RMS)	1050A, 85ms	
Display		10" touch panel	
Interface	Standard	External battery temperature dry contact x 4, External switch/ breaker status dry contact x 4, Output dry contact x 6, Input dry contact x 4, Parallel port x 2, USB type A x 2, USB type B x 1, RS-232 port x 1, MODBUS port x 1, BMS (RJ45) x 1, Ethernet x 1, Parallel communication card slot x 1, SMART slot x 1, REPO x 1	
Efficiency	Online Mode	up to 96.5%	
	ECO Mode	99%	
Battery	Nominal Voltage	$\pm 240$ Vdc	
	Charge Voltage	$\pm 272$ Vdc (adjustable from 204 Vdc to 312 Vdc)	

Model		HPH	
UPS Capacity		160kVA <sup>*1</sup> / 150kW	200kVA/ 200kW
Battery	Battery Q'ty Configuration	30 ~ 46 PCS (default: 40 PCS)	
	Protection of Battery Deep Discharge	Yes	
Compliance	IEC Pollution Degree (PD)	PD 2	
	Over Voltage Category (OVC)	OVC III	
	Type of System Earthing	TN-S, TN-C, TN-C-S	
Environment	Operating Altitude	1000 meters (without derating)	
	Operating Temperature	0 ~ 40°C	
	Relative Humidity	95% (non-condensing)	
	Audible Noise	< 70 dBA <sup>*3</sup>	
	Ingress Protection (IP) Class	IP20	
Others	Parallel Redundancy	Yes (up to 8 units)	
	Remote Emergency Power Off	Yes	
	Battery-start	Yes	
Physical	Dimensions (W x D x H)	600 x 1100 x 1600 mm	
	Weight	340 kg	376 kg

**NOTE:**

- <sup>\*1</sup>: The power rating is adjustable from 160kVA (default) to 150kVA. Only qualified service personnel can perform such modification.
- <sup>\*2</sup>: When input vTHD is < 1%.
- <sup>\*3</sup>: < 70% load, at a distance of 1 meter in front of the UPS.
- Please refer to the rating label for the safety rating.
- All specifications are subject to change without prior notice.





Seller warrants this product, if used in accordance with all applicable instructions, to be free from original defects in material and workmanship within the warranty period. If the product has any failure problem within the warranty period, Seller will repair or replace the product at its sole discretion according to the failure situation.

This warranty does not apply to normal wear or to damage resulting from improper installation, operation, usage, maintenance or irresistible force (i.e. war, fire, natural disaster, etc.), and this warranty also expressly excludes all incidental and consequential damages.

Maintenance service for a fee is provided for any damage out of the warranty period. If any maintenance is required, please directly contact the supplier or Seller.



**WARNING:**

The individual user should take care to determine prior to use whether the environment and the load characteristic are suitable, adequate or safe for the installation and the usage of this product. The User Manual must be carefully followed. Seller makes no representation or warranty as to the suitability or fitness of this product for any specific application.

No. 501326390101

Version : V 1.1

Release Date : 2023\_08\_11

## - Global Headquarter

### Taiwan

Delta Electronics Inc.  
39 Section 2, Huandong Road, Shanhua District,  
Tainan City 74144, Taiwan  
T +886 6 505 6565  
E [ups.taiwan@deltaww.com](mailto:ups.taiwan@deltaww.com)

## - Regional Office

### U.S.A

Delta Electronics (Americas) Ltd.  
46101 Fremont Blvd. Fremont, CA 94538  
T +1 510 344 2157  
E [ups.na@deltaww.com](mailto:ups.na@deltaww.com)

### Australia

Delta Energy Systems Australia Pty Ltd.  
Unit 20-21, 45 Normanby Road, Notting Hill VIC 3168, Australia  
T +61 3 9543 3720  
E [ups.australia@deltaww.com](mailto:ups.australia@deltaww.com)

### South America

Delta Electronics Brasil Ltda.  
Estrada Velha Rio-São Paulo, 5300 – Eugênio de Melo – CEP 12247-001  
São José dos Campos-SP-Brasil  
T +55 12 39322300  
E [ups.brazil@deltaww.com](mailto:ups.brazil@deltaww.com)

### Thailand

Delta Electronics (Thailand) Public Co.,Ltd.  
909 Soi 9, Moo 4, E.P.Z., Bangpoo Industrial Estate, Tambon Prakasa,  
Amphur Muang-samutprakarn, Samutprakarn Province 10280, Thailand  
T +662 709-2800  
E [ups.thailand@deltaww.com](mailto:ups.thailand@deltaww.com)

### China

Delta GreenTech (China) Co., Ltd.  
238 Minxia Road, Pudong, Shanghai, 201209 P.R.C  
T +86 21 5863 5678  
+86 21 5863 9595  
E [ups.china@deltaww.com](mailto:ups.china@deltaww.com)

### South Korea

Delta Electronics (Korea), Inc.  
1511, Byucksan Digital Valley 6-cha, Gasan-dong, Geumcheon-gu,  
Seoul, Korea, 153-704  
T +82-2-515-5303  
E [ups.south.korea@deltaww.com](mailto:ups.south.korea@deltaww.com)

### Singapore

Delta Electronics Int'l (Singapore) Pte Ltd.  
4 Kaki Bukit Ave 1, #05-04, Singapore 417939  
T +65 6747 5155  
E [ups.singapore@deltaww.com](mailto:ups.singapore@deltaww.com)

### India

Delta Electronics India Pvt. Ltd.  
Plot No. 43, Sector-35, HSIDC, Gurgaon-122001, Haryana, India  
T +91 124 4874 900  
E [ups.india@deltaww.com](mailto:ups.india@deltaww.com)

### EMEA

Delta Electronics (Netherlands) BV  
Zandsteen 15, 2132MZ Hoofddorp, The Netherlands  
T +31 20 655 09 00  
E [ups.netherlands@deltaww.com](mailto:ups.netherlands@deltaww.com)

### Japan

Delta Electronics (Japan), Inc.  
2-1-14 Shibadaimon, Minato-Ku, Tokyo, 105-0012, Japan  
T +81-3-5733-1111  
E [jpstps@deltaww.com](mailto:jpstps@deltaww.com)

### UK

Delta Electronics (UK) Ltd.  
Eltek House Cleveland Road, Hemel Hempstead Industrial Estate,  
Hemel Hempstead, Hertfordshire, HP2 7EY  
T +44 1442 219355  
E [sales.gb@eltek.com](mailto:sales.gb@eltek.com)



5013263901